


Kiitos, että hankit Hima tuotteen!

Thank you for purchasing Hima product!

# Hima Läp



- A. Kiinnitä harmaat kitkatarrat tason molempien päätyihin, kierrepultin molemmille puolelle.
  - B. Kiinnitä taso (1.) jalkalevyihin (2.) työntämällä tason kierrepultit jalkalevyjen läpi siten, että jalkalevyjen kaiverretut urat jävät tason puolelle ja tason päädyt uppoavat uriin. Kiristä puiset sormiruuvit kierrepultteihin. Käytä samaa korkeutta molemmilla puolilla.
  - C. Voit säätää tason kaltevuutta löysäämällä sormiruuvit. Kiristä ruuvit, kun taso on halutussa kaltevuudessa.
- 
- A. Attach the grey friction stickers to both ends of the top, on both sides of the threaded bolt.
  - B. Attach the top (1.) to the footplates (2.) by inserting the threaded bolt through the footplate so that the engraved grooves on the footplates are in the same side as the top and the end of the top sink into the grooves. Tighten the wooden thumbscrews to the threaded bolts. Use the same height on both sides.
  - C. You can adjust the inclination of the top by loosening the thumbscrews. Tighten the screws when the level is at the desired inclination.