




STEP 1
Open the bonnet
Remove the plastic engine cover



STEP 2
Locate the Fuel Rail Sensor based on your instructions
Unhook it and connect the original style plugs to those of the Power Module



STEP 3
Locate the Boost Sensor
Unhook it and connect the original style plugs to those of the Power Module



STEP 4
Refit the plastic engine cover
Installation complete. Test Drive Time!