



- ADCC NOT AVAILABLE WHEN USING WIFI OR BLUETOOTH
- *PWM AT BOOT
 - IO0-ADC2_CH1, TOUCH1, RTC_GPIO11, CLK_OUT11, EMAC_RXD2
 - IO1-BOOT0, CLK_OUT13, EMAC_RXD2
 - *HIGH AT BOOT
 - IO2-ADC2_CH2, TOUCH2, RTC_GPIO12, HSPWP, HS2_DATA0, SD_DATA0
 - IO3-BOOT0, CLK_OUT12
 - IO4-ADC2_CH0, TOUCH0, RTC_GPIO10, HSPHD, HS2_DATA1, SD_DATA1, EMAC_TX_ER
 - *PWM AT BOOT
 - IO5-VSPICLK, HS1_DATA0, EMAC_RX_CLK
 - IO6.7.8.9.10.11-INTERNAL FLASH
 - IO12-ADC2_CH5, TOUCH5, RTC_GPIO15, MTDI, HSPD, HS2_DATA2, SD_DATA2, EMAC_TXD3
 - IO13-ADC2_CH6, TOUCH6, RTC_GPIO16, MTKC, HSPID, HS2_DATA3, SD_DATA3, EMAC_RX_ER
 - IO14-ADC2_CH6, TOUCH6, RTC_GPIO16, MTMS, HSPICLK, HS2_CLK, SD_CLK, EMAC_TXD2
 - IO15-ADC2_CH6, TOUCH6, MTDO, HSPICB, RTC_GPIO13, HS2_CH0, SD_CH0, EMAC_RXD3
 - IO16-HS1_DATA4, U2RXD, EMAC_CLK_OUT
 - IO17-HS1_DATA5, U2TXD, EMAC_CLK_OUT_180
 - IO18-VSPICLK, HS1_DATA7
 - IO19-VSPID, U0CTS, EMAC_TXD0
 - IO21-VSPHD, EMAC_TX_EN
 - IO22-VSPWP, U0RTS, EMAC_TXD1
 - IO23-VSPID, HS1_STROBE
 - IO25-DAC_1, ADC2_CH8, RTC_GPIO6, EMAC_RXD0
 - IO26-DAC_2, ADC2_CH9, RTC_GPIO7, EMAC_RXD1
 - IO27-ADC2_CH7, TOUCH7, RTC_GPIO17, EMAC_RX_ER_BV
 - IO32-XTAL_32K_P, ADCL_CH4, TOUCH4, RTC_GPIO8
 - IO33-XTAL_32K_N, ADCL_CH5, TOUCH5, RTC_GPIO9
 - IO34-ADCL_CH6, RTC_GPIO8
 - IO35-ADCL_CH7, RTC_GPIO9
 - IO36-ADCL_CH8, RTC_GPIO9
 - IO39-ADCL_CH3, RTC_GPIO3