

ARES

1/2" DRIVE IMPACT DRIVER SET

OPERATOR'S MANUAL



NEED HELP?

(800) 340-1442

www.arestool.com

customerservice@arestool.com

Don't forget to register your product!

Get to Know Your Manual Reversible Impact Driver

The ARES 1/2-inch Drive Manual Reversible Impact Driver allows you to loosen frozen bolts, rusted body panel fasteners, and corroded brake calipers with just a few strikes of a hammer and without causing damage. With eight interchangeable bits in Standard and Long lengths to choose from with Precision-Milled Tips for exact fit, you'll save yourself the enormous hassle of having to drill and tap many of even the most stubborn fasteners. Thanks to the double-layer anti-slip handle, you'll also be able to keep a firm and comfortable grip on this tool during prolonged use.

Set Includes:

- 1/2-inch drive Manual Impact Driver
- Bit chuck
- 5/16" and 3/8" Slotted Head and #2 and #3 Phillips Head Standard length screwdriver bits
- 5/16" and 3/8" Slotted Head and #2 and #3 Phillips Head Long screwdriver bits
- Convenient storage case

ARES

1/2" MANUAL REVERSIBLE IMPACT DRIVER



SET INCLUDES:

- 1/2-inch impact driver
- 1/2-inch drive 5/16-inch hex bit chuck
- 4pc Slotted Bits (5/16- and 3/8-inch in Standard length and Long)
- 4pc Phillips bits (#2 and #3 in Standard length and Long)
- Storage case



For use with
**IMPACT SOCKETS
AND ON NUTS,
BOLTS, AND OTHER
FASTENERS**

Supplies Needed:

1. Hammer
2. Gloves
3. Eye Protection
4. Manual Impact Driver and Provided Bits (1/2 drive Impact Sockets not provided)

Directions:

Read these instructions carefully before using this Manual Impact Driver.

1. Choose the correct bit or 1/2 drive socket for the job.
2. Insert the bit or place the socket over the nut, bolt or screw that you intend to loosen.
3. Ensure that you have a very firm grip on the tool and strike the smooth end of the Impact Driver.
4. While applying pressure, keep turning the Impact Driver in the direction that you want the screw or bolt turned.
5. Continue to strike and turn the driver until the nut, screw or bolt is loosened or fastened.
6. Tighten a nut, bolt or screw in the same manner, and by applying a turning force in the opposite direction.

Notes:

Read these notes carefully before using this Manual Impact Driver.

1. Always make sure to remove dirt from the screw slot in order to prevent damage to the screw head.
2. In order to loosen the screw or bolt, the direction should be clockwise, otherwise counter clockwise.
3. The tip of the tool is removable which exposes a 1/2 drive adapter for use with all 1/2 drive impact sockets.

Maintenance and Safety:

1. Remove dust, moisture and other contaminants with a clean brush, or soft, lint free cloth.
2. Do not use any abrasive materials that could damage the tool.
3. When tool is not in use, store the tool in the provided case, in a clean dry area.

1/2" DRIVE IMPACT DRIVER SET

OPERATOR'S MANUAL

You are backed by the ARES Tool Performance Assurance!

ARES TOOL warrants this product to be free from defects in materials and workmanship under normal use and service. A defective product may be returned for a free replacement within 90 days from the date of purchase, provide that product is returned immediately after discovery of defect. This warranty shall be valid only when proof of purchase (receipt) showing the date of purchase accompanies the defective product.

Exclusions:

These warranties exclude blades, bits, punches, dies, bulbs, fuses, batteries, and other consumables which must be replaced under normal use and service. These warranties shall not apply to any product or part which is used for a purpose for which it is not designed, or which has been repaired or altered in any way so as to affect adversely its performance or reliability, nor shall these warranties apply to any product or part which is subject to misuse, neglect, accident, or wear/tear incident to normal use and service.