




RESCUE TECH USER MANUAL








How To Connect Using Local Remote



How To Connect LCI Level Up Towable Only

1. Locate controller



2. Disconnect controller



3. Connect to Rescue Tech





4. Select Hydraulic Leveling then select which jacks and what direction they need to move.

5. Choose function desired



How To Connect LCI In Wall Slide (Schwintek/SlimRack)

1. Locate controller



2. Disconnect controller



3. Connect to Rescue Tech



Rescue Tech

Slideout

Awning

Hydraulic Leveling

4. Select Slideout then select a direction to move.

5. Choose function desired



How To Connect LCI Ground Control 3.0 (Towable)

1. Locate controller



2. Disconnect jack or jacks from controller



3. Connect jack or jacks to Rescue Tech



Rescue Tech

Slideout

Awning

4. Select
Electric Leveling
then select a
direction to
move.


5. Choose function desired




How To Connect to Motor Coach Electric Steps (This Adapted)

(This Adapter is sold separately)

1. Locate motor plug under the steps



2. Disconnect motor plug




3. Connect to step adapter to step motor



4. Plug extension harness into Rescue Tech



5. Select
Electric Leveling
then select a
direction to
move.



6. Choose function desired



How To Connect to Equalizer hydraulic towable and coach (This Adapter is.

(This Adapter is sold separately)

1. Locate pump harness white & black plugs to the pump



2. Disconnect plugs




3. Connect Equalizer adapter to the pump harness



4. Plug Equalizer harness into Rescue Tech



5. Select Hydraulic Leveling then select a direction to move.



6. Choose function desired



How To Connect to Motor Coach Level Up Hydraulic (This Adapter is sold separately)


1. Locate pump harness gray plug to the pump



2. Disconnect plug




3. Connect LCI Coach adapter to the pump harness



4. Plug extension harness into Rescue Tech



5. Select Hydraulic Leveling then select a direction to move.



6. Choose function desired

