




INSTALL TOOL INTO VISE




INSTALL JACKSHAFT INTO TOOL




INSTALL SPROCKET




INSTALL SCREWS FOR SPROCKET




TORQUE BOLTS




FLIP TOOL OVER




INSTALL SPROCKET SIDE INTO FIXTURE



INSTALL PULLEY



INSTALL SCREWS



TORQUE SCREWS