

ASSEMBLY INSTRUCTIONS

Please read the instruction before installation.
We always recommend the installation by a licensed electrician.

ASSEMBLY:



1. Carefully remove all parts from box.
2. Hang Chain (A) 3 pcs to Top (C) and Frame (B).
3. Insert bulb (G) 4 E12, Max 60 Watt (NOT INCLUDED)

INSTALLATION: Basic installation may not be applicable in all settings. Consult a professional electrician for installations with unique wiring applications.


WARNING: RISK OF SHOCK. DO NOT EXCEED MAXIMUM WATTAGE RATING.

JESSIE PENDANT JESSIE-PEN

Please see images below in coordination with instructions.



RO SHAM BEAUX



RO SHAM BEAUX

FOR PRICING & CURRENT LEAD TIME, PLEASE VISIT OUR WEBSITE AT
RO-SHAM-BEAUX.COM OR EMAIL CUSTOMERSERVICE@RO-SHAM-BEAUX.COM