



1. When you connect LED light with the LED control, please make sure the plugs remain arrow to arrow



2. Before you using the remote controller, please remove the transparent plastic, which is designed to disconnect the battery



3. Remote controller should be aim at the black receiver unit when you switch colours, you can also fix the control box on the nearby wall with 2 screws, for more convenient using

