

LEITNER

H E A D S E T S



PREMIUM DONGLE HEADSETS



CONTENTS

Getting to know your...

Controls.....	3
FocusLight.....	4
Audio signals	5

Setting up with your...

Computer.....	6
---------------	----------


How to...

Adjust volume & mute.....	7
Pair your headset to the dongle.....	8


Health and Safety Instructions	9
--------------------------------------	----------

GETTING TO KNOW YOUR HEADSET CONTROLS

- A Speaker Volume Up & Mute
- B Speaker Volume Down & Mute
- C FocusLight
- D Headset ON/OFF



- E Battery
- F Battery Door



WHAT'S IN THE BOX

Headset
USB-A Dongle
Lithium-Ion Battery
USB-A to USB-C Adapter

Type C-to-A USB Cord
Travel Bag
Travel Clip
Battery Door

GETTING TO KNOW YOUR FOCUSLIGHT



On a call	●
Ringling	⚡
Muted	●
Headset and dongle pairing	⚡
Headset battery below 20%	⚡
Headset and dongle not paired	⚡

While charging

Less than 20% battery	⚡
20% to 80% battery	⚡
80% to 100% battery	●



Solid



Flashing

GETTING TO KNOW YOUR AUDIO SIGNALS

SOUNDS	WHAT IT MEANS
1 click	Volume up/down
1 chime	Volume max/min reached
2 beeps (5 minute repeat)	Mute is on
1 beep	Mute is off
2 beeps (60 sec repeat)	Low Battery ≤30 minutes remaining
2 beeps (repeating)	Out of range

When you walk out of range, you'll hear warning beeps in the headset. If the headset disconnects, the call will not drop. The headset will automatically reconnect when you are back in range.

NOTE: If you do not move back in range within 5 minutes, the call will disconnect.

SETTING UP WITH YOUR COMPUTER

- 1 Plug the USB dongle into your device.
- 2 If your computer doesn't recognize the device after a minute, go to your sound settings and select "Leitner Headset" as both your default microphone and default speakers.
- 3 To wake up your headset from sleep mode, press and hold the ON/OFF button until the FocusLight flashes purple, then release. Once it stops flashing you can press the ON/OFF button again to turn the headset on.
- 4 Charge your headset with the included USB cable (we recommend charging for at least 4 hours before first use).



HOW TO

ADJUST VOLUME & MUTE

TO ADJUST LISTENING VOLUME:

While the headset is on, click the volume control buttons on the headset to raise **A** or lower **B** the volume.

The headset will beep each time the volume is adjusted.

TO MUTE THE MICROPHONE:

Press and hold either of the volume control buttons (**A** or **B**) for 1 second.

While muted, the FocusLight will turn purple and the headset will beep every 5 minutes.

To unmute, press and hold either volume control button for 1 second.



HOW TO

PAIR YOUR HEADSET TO THE DONGLE

- 1 Ensure dongle is securely connected to your device.
- 2 With your headset off, press and hold the pairing button **B** until it begins to flash.
- 3 Press and hold the ON/OFF button **A** until the FocusLight flashes blue or purple, then release immediately.
- 4 The FocusLight will flash purple. Once it stops flashing, pairing is complete.



HEALTH AND SAFETY

It might seem a bit silly, but we're required to tell you these safety instructions about your Leitner headset. Please keep these instructions for your reference. When using this product, these basic safety precautions and warnings should be followed to reduce the risk of fire, electrical shock, injury to persons, and damage to property.

Operating, charging and storage temperatures are 32 °F to 104 °F (0 °C to 40 °C).

General Warnings

Battery model: 402035P-250mAh (SHEN ZHEN ZNL BATTERY CO., LTD)

- Never allow children to play with the product; small parts may be a choking hazard.
- Do not disassemble the product as this may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock or fire when the product is subsequently used.
- Do not insert anything into the product because this may cause damage to the internal components or cause personal injury.
- Avoid contact with liquids. Do not locate this product near water, for example, near a bathtub, or sink, in a wet basement, or near a swimming pool.
- Discontinue use of product if the product overheats, has a damaged cord or plug,

if the product has been dropped or damaged, or if the product has come into contact with liquids.

- This product should never be placed over or near a heat source and should not be placed in locations which do not have proper ventilation.
- If you experience skin irritation after using this product, discontinue use.

Headset Battery Warnings

- The headset is equipped with a replaceable battery. To reduce the risk of fire or injury to persons read and follow these instructions.
- Do not dispose of the battery in a fire. The battery may explode. Check your local laws for disposal instructions.
- Do not open or mutilate the battery. There may be corrosive materials which can cause damage to eyes or skin and may be toxic if swallowed.
- Never charge the battery where the temperature may fall below 32 °F (0 °C) or rise above 104 °F (40 °C).

***RECYCLING:** Your battery used in the headset must be recycled or disposed of properly. Contact your local recycling center for proper disposal of your headset battery.*

To Protect Your Hearing

- Set the volume control in a low position before putting your headset on your ear and use as low volume as possible.
- Avoid turning up the volume to block out noisy surroundings.
- Limit the amount of time you use headsets at high volume levels.
- Turn the volume down if the sound from the headset prevents you from hearing people speaking near you.



For live product support

1-800-432-3738

Mon-Fri 9am-6:30pm Eastern Time

www.leitnerheadsets.com