











PART LIST

TWO ADULTS NEEDED FOR ASSEMBLY

#1  TOP 1 PC	#2  BASKET 1 PC	#3  BASE 1 PC	#4  TOP POLE 1 PC	#5  BOTTOM POLE 1 PC
#6  BOLT MBX65MM	#7  BOLT MBX55MM	#8  Allen Tool	#9  BOLT MBX6MM 4 PCS	#10  Allen Tool 1 PC

Assembly Instructions

- Step 1: Assemble the bottom pole #5 to the base #3 and tighten with bolt #6 . Attach bolt #9 and tighten it.
- Step 2: Assemble the basket #2 to the top of bottom pole with bolt #6 .
- Step 3: Insert the top pole #4 to the top of bottom pole #5 and tighten with bolt #7 and . Attach bolt #9 and tighten it.
- Step 4: Cross the round ring at the bottom of top #1 to the pole #4 and tighten the top #1 to pole with bolt #6 .Attach bolt #9 and tighten it.
- Then you can start to play now.

Assembly Instructions

