



STAINLESS STEEL RELIEF VALVES

#36
0-500 PSI



#18
0-1000 PSI



NOTE: TO CHANGE THE POP OFF SET POINT REMOVE THE PLASTIC CAP AND TURN THE SET SCREW CLOCKWISE TO INCREASE THE PRESSURE AND COUNTER-CLOCKWISE TO DECREASE THE PRESSURE. REPLACE THE PLASTIC CAP.