SECOND EDITION





CATALOG NO. 31L

9900 14700

LIST OF PARTS

Catalog No. 31 L

Second Edition

LIST OF PARTS

Styles in Classes 9900 14700

The parts listed in this catalog are furnished at list prices for repairs only

Copyright 1939
By
Union Special Machine Co.
Rights Reserved In All Countries

Union Special Machine Company Chicago U.S.A.

Printed in U.S.A.



Africa

BULAWAYO, SO. RHODESIA, FEDERATION OF RHODESIA and NYASALAND, Berzack Bros. Ltd., 16 14th Avenue. (Textile Machines).
CASABLANCA, MOROCCO, Etablissements Geissmann & Fils, 34 Blvd. de la Gare.
JOHANNESBURG, UNION OF SOUTH AFRICA, South African Scale Co., (Pty.) Ltd., P.O. Box 1463, 32 Von Brandis St., for bag closing machines. Branches also at Bloemfontein, (53 Zaston St.), Capetown, (Box 779), Durban, (22 Aliwal St.), East London (53A Cambridge St.) Pietermaritzburg, Porz Elizabeth, (Box 611), Pretoria, Vereeninging and Worcester.

Pietermaritzburg, Pors Elizabeth, (Box 611), Pretoria, Vereeninging and Worcester.
JOHANNESBURG, UNION OF SOUTH AFRICA, Berzack Bros. Ltd., Berbro Hause, 135/7 Pritchard St. Branches also at 487 West St., Durban; 78 Darling St., Capetown; 58 Queen St., Port Elizabeth. Textile machines.
MAURITIUS, Hall, Geneve, Langlois, Ltd., Port Louis, P.O. Box 77.
SALISBURY, SO. RHODESIA, FEDERATION OF RHODESIA and NYASALAND, So. African Scale Co., Carner of Forbes and Angwa Sts., Bog Closing Machines.

Asia CALCUTTA, INDIA, Don Watson & Co., Ltd., 19

British Indian St.

DACCA, PAKISTAN, Roberts & McLean & Co.,
Ltd., 91 Nawabpur Rd., Bag closing and Bag
seaming machines.

seaming machines.

DEIHI 6, INDIA, Munshi Ram Bs. C., P.O. Bax
1114, Kashmere Gate. Above Keventers.

HONGKONG, G. R. Coleman Co. (Hongkong) Ltd.,
Room 308, Bank of Canton Bidg., 6 Des Voeux
Road, Central.

KARACHI 2, PAKISTAN, Universal Trading Corp.,
Textile Machines, 29 Zeenat Mansion, McLeod
Road, P.O. Box 4635.

OSAKA, JAPAN, Mima Sewing Machine Mfg. Co.
29, 1-chrome, Ebi-kami, Fukushima—KU.

SEOUI, KOREA, Uebersee-Handel A. G., Iwang
Wha Moon, P.O. Box 268.

TAIPEI, TAIWAN, G. R. Coleman, Hongkong, Ltd.,
78 Po Ai Road.

TOKYO, JAPAN, Iwase Sewing Machine Co., Ltd.,
39, 1-chrome, Kamezawa-cho, Sumida—KU.

Australia

Australia

BRISBANE, AUSTRALIA, Capron, Carter (Pty.) Ltd., Rm. 55—Rex Bldg., Wickham St., Valley. MELBOURNE, VICT., AUSTRALIA, Capron, Carter (Pty.) Ltd., 78 A'Beckett St. SYDNEY, N.S.W., AUSTRALIA, Capron, Carter (Pty.) Ltd., 86 Liverpool St.

British West Indies

KINGSTON, JAMAICA, B. W. I., Mr. Morris E. Parkin, 102 King St.

Canada

■ Canada
Union Special Machine Co. of Canada, Ltd.
CALGARY, ALTA., 1809 24th Ave., N.W. N. W.
Holt. Tel. 891690.

MONTREAL 14, QUE., 40 Moliere St., Clyde F.
Amey, Tel. Victoria 2575.
QUEBEC, P. Q., Ave. Des Pins Ouest. Lucien
Bouchard. Tel. 3-8126.
★TORONTO 2, ONT., 135 Peter St. S. J. Storey,
Agr. Tel. Empire 6-2939.
WINNIPEG, MAN., Room 201, Whitia Bidg.,
Frank Thierman. Tel. 934933.
■ Europe

Europe

the same

AMSTERDAM, THE NETHERLANDS, N. V. Machine-handel C. & H. Verbeek, Kloveniersburgwal 77. Also offices in: Rotterdam, Sittard, Groningen, Enschede, Eindhoven. ATHENS, GREECE, Michel D. Dimoulis, Rue Deka,

BARCELONA, SPAIN, Rapida, S. A. Avino S

BARCELUNA, SPAIN, Rabida, S. A. Avino Y.
BERGEN, NORWAY, Jac. Jacobsen A/S, Bjornsongst 24.
BORAS, SWEDEN, Rud. Nystrom & Co., A/B, Lilia
Bannerigatan 6.
BRUSSELS, BELGIUM, Union Special Machine Corporation of America, 23 Rue Philippe de Champagne. Henri Deloof, Mgr.

COPENHAGEN, DENMARK, Rothenborg Special-maskiner for Sy-Industrian A/S, Nikolaj Plads Also offices in: Herning, Kolding, Odense,

23. Also offices in therming, Rolang, Science, Silkeborg, Riisakov.

DUBLIN, EIRE, Machines, Ltd., 24 Upper Abbey St. Textile Machines.

DUNDEE, SCOTLAND, Thomas C. Keay, Ltd., 15

Baltic St. Bag Closing and Bag Making.

HELSINKI, FINLAND, Suomen Koneliike O/Y, Vil-

HELSINKI, FINLAND, Suomen Koneliike O/Y, Vilhonkatu 9.
LEICESTER, ENGLAND, Union Special Machine Co., Ltd., 25 Bede St. Braunstone Gate, A. B. Fitzpatrick, Mgr. Textile Machines.
LONDON, E. C. I, ENGLAND, Union Special Machine Co., Ltd., Parksworth House, 30, City Road. Textile Machines.
MALMO, SWEDEN, Rud. Nystrom & Co., A/B Vargatan 10-A.
MILANO. ITALY. Giovanni Conti y Ninati. Piaz-

Vargatan 10-A.

MILANO, ITALY, Giovanni Conti y Nipoti, Piazzale Marengo 6.

NOTTINGHAM, ENGLAND, Mr. W. Wilkes, Plantation Road, Wellaton. Textile Machines.

OPORTO, PORTUGAL, Rost & Janus, Succrs., Rua Bargo de Forrester, 914.

OREBRO, SWEDEN, Rud. Nystrom & Co., A/B Skebacksvagen 17-19.

OSLO, NORWAY, Jac. Jacobsen A/S, Kr. Augustsgate 19 (Tullingarden).

PARIS, FRANCE, Cie. des Machines Union Special de France, 91 Avenue de la Republique, Georges Linotte, Mgr.

de France, 91 Avenue de la Republique, Georges Linotte, Mgr.
STOCKHOLM, SWEDEN, Rud. Nystrom & Ca., A/B, St. Nygaten 10-12.
STUTTGART, GERMANY, Union Special Maschinenfabrik, G.m.b.h., Schwabstrasse 33, A. W. Krieger, Managing Director.
VIENNA, VI, AUSTRIA, Firma Nahschuster, Mariahilferstr, 51.
ZURICH, 9/47, SWITZERLAND, M. L. Bourquin, Albisriederstrasse 226.

Latin America

Union Special International, Inc.

BARRANQUILLA, COLOMBIA, C. Ceballos & Cia., Ltda., Almacenes "Carceco," Banco Comercial, Anticqueno, OF. 401.
BOGOTA, COLOMBIA, C. Ceballos & Cia., Ltda., Avenida Caraccas 17-18.

BUENOS AIRES, ARGENTINA, Kay, Grandjean & Cia., Bartolome Mitre 760.
CALL, COLOMBIA, C. Ceballas & Cia., Ltd., Calle

CALI, COLOMBIA, C. Cepanas a Sian, 4, No. 9-21.

4, No. 9-21.

CARACAS, VENEZUELA, H. Blohm, S.A., Dr. Paul A. Charro 29.

CIUDAD TRUJILLO, DOMINICAN REPUBLIC, Luis Dominguez, Apartado 57, Hostos esa. El Conde.

GUADALAJARA, JAL., MEXICO, Talieres Perez Zozaya, S. A. Hidalgo 45 y 47.

GUATEMALA CITY, GUATEMALA, Cia. Agro Commercial S.A., 8a Ave. Sur. 10-43. Bag Clasing Machines.

Machines.
HAVANA, CUBA, Antilla Yarn & Supply Co., S. A.
Factoria 70, Textile, Bag Seaming, and Shoe Machines

Nachines.

HAVANA, CUBA, Mr. Miguel A. Vilato, Apartado
No. 124, Bag Closing Machines.

LIMA, PERU, A. y F. Wiese, S.A., Esa, Nunez y
Filipinas.

MANAGUA, NICARAGUA, Hentgen & Co., Ltd., Aportado 14. 5 A. Colle, N. O. 214. MEDELLIN, COLOMBIA, C. Ceballos & Cio., Ltda.,

MEDELIIN, COLOMBIA, C. Ceballos & Cio., Ltda., Carrera Junin 44-34.

MEXICO, D.F., MEXICO, Perez Zaragoza, S.A., Regina 26.

MONTERREY, N.L., MEXICO, Talteras Perez Zoraya, S.A., Apartado 197, Cuahtemac Norte 335.

MONTEVIDEO, URUGUAY, Carlos Dighiera e Hiios, Convencion 1424.

PORTO ALEGRE, RIO GRANDE DO SUL, BRAZIL, Casa de Maquinas Falk, Ltda., Rua Hoffman 533. Bag Closing and Bag Making Machines.

PORTO ALEGRE, RIO GRANDE DO SUL, Maquinas de Costura Panambra, S.A., Rua Sigueira de Campos 1172. Textile Machines.

RECIFE, PERNAMBUCO, Maquinas de Costura Panambra, S.A., Av. Guararapez 154. Textile Machines.

EPRESENTA

RIO DE JANEIRO, D.F., Maquinas de Costura Panambra, S.A., Rua Alexandre Mackenzie 117. Textile Machines.

SAN JOSE, COSTA RICA; Champion Co., Ltda., APDO. 2742.

SAN JUAN, PUERTO RICO, Abarca Warehouse, Inc., P.O. Box 2352. SAN LUIS POTOSI, S.L.P., MEXICO, Talleres Perez

SAN LUIS POTOSI, S.L.P., MEXICO, Talleres Perez Zozaya, J. de los Reyes 80.

SAN SALVADOR, EL SALVADOR, Vairo Hermanos, Colonia Vairo.

SANTIAGO, CHILE, Lowenstein & Stewart, S.A.C., P.O. Box 2195, Calle Santo Domingo 1140.

SAO PAULO, BRAZIL, Casa de Maquinas Falk. Itda., Av. Duque de Caxias 610. Bag Closing & Bag Making Machines.

SAO PAULO, BRAZIL, Maquinas de Costura Panambra S.A. Rug Brigadiero Tobios 388. Taxombra S.A. Rug Brigadiero Tobios 388. Taxombra S.A. Rug Brigadiero Tobios 388.

ambra, S.A., Rua Brigadiero Tobias 388. Tex-tile Machines

Near East

BAGHDAD, IRAQ, Sons of O. O. Agopian, P.O.

Box 121. BEIRUT, LEBANON, Sons of O. O. Agopian, P.O.

Box 1165.
CAIRO, EGYPT, Mr. A. Kavaidjian, 4, Midan El-Hami, Kosr el Nil Bridge.
DAMAS, SYRIA, Elias Aractingi & Fils, Sidi Amoud.

ISTANBUL, TURKEY, David ve Varber ve Seriki, Hamdi Bey Gecidi 36, 38, 40, Posta Kutusu 385. TEL AVIV, ISRAEL, L. Taube, Ltd., 15 Lilienblum

New Zealand

Sole Distributors—H. A. Tuck & Co., Ltd.
AUCKLAND, 171 Albert St., C. 1. (Head Office
WELLINGTON, Ford Bldg., Courtenoy Place.
CHRISTCHURCH, (Sub-Agents) Glendermid, Ltd.,
78 Lichfield St. DUNEDIN, (Sub-Agents) Glendermid, Ltd., 18 Dowling St.

Pacific Islands

CEBU, THE PHILIPPINES, Atkins, Kroll and Ca.,

Inc., Textile Machines.
HONOLULU, HAWAII, Commercial Sewing Machine Service, Ltd., 732 Ilaniwai St. Textile Machines

HONOLULU, HAWAII, H. S. Gray Company, P.O. Box 3016, 759 Puuloa Rd. Bag Closing Machines.

MANILA, PHILIPPINE ISLANDS, Atkins, Kroll & Co., Inc., 124 Myers Bldg., Port Area. Textile Machines.

MANILA, PHILIPPINE ISLANDS, Earnshaws Docks

& Honolulu Iron Works Co., Corner of Tacoma
and 2nd Sts., Port Area. Bag Closing Machines.

United States

ALLENTOWN, PA., 1512 Catalina Ave., Box 542, L. D. Cassell. Tel. Hemlock 4-3900.

*ATLANTA, GA., 81 Peachtree Pi., N.W., M. O. Moulton, Mgr. Tel. Atwood 2733, 2734.

BALTIMORE 15, MD., P.O. Box 2505 R. B. Foster. Tel. Sar. 7-8499.
BELLEVILLE, N. J., 18 Preston St., D. C. Jenkins. Tel. Plymouth 1-0304.

Tel: Plymouth 1-0304.

★BOSTON 17, MASS., 179 Lincoln St., Wm. E. Palm, Mgr. Tel. Liberty 2-0147-48.

★CHICAGO 10, ILL., 404 N. Franklin St., O. A. Ullrick, Mgr., Tel. Superior 7-6920.

★CINCINNATI 25, O., 3372 Central Pkwy. A. E. Brauch, Mgr. Tel. Kirby 5558.

CLEVELAND 11, OHIO, 11902 Milligan Ave., David G. Lee. Tel. Clearwater 1-3462. COLUMBIA, S. C., 319 Howard St., C. A. Page,

Tel. 6-8806 COMMERCE, GA., State St. J. T. Hanley. Tel.

CONYNGHAM, PA., Box 46, Robert S. Vogt. Tel.

Sunset 8-5556.

DALIAS 2, TEXAS, P.O. Box 5013. Emmett Richards. Randolph 5722.

DENVER 10, COLO., 1801 South Marion St. L. E. Carter, Tel. Spruce 7-7060.

DETROIT 21, MICH., 16630 Ward Ave. John F. Lux, Tel. University 3-4948.

GREENSBORO, N. C., P.O. Box 226. W. D. Harrod. Phones 3-7648

GREENSBORO, N. C., P.O. Box 226. W. D. Harrod. Phone: 3-7648.
GREENVILLE, S. C., 119 Phillips Lane, M. M. Ambrose, Tel. 3-4647.
INDIANAPOLIS 1, IND., 3731 N. Tacoma Ave. B. L. Rogers. Tel. Liberty 6-2277.
JACKSON, MISS., 327 Eastview St. J. A. Boyette. Tel. 5-1976.

JOHNSON CITY, N. Y., 471 Main St., J. J. Lafler, Tel. 7-3994.

tel. 7-3994.

KANSAS CITY 41, MO., P.O. Box 824, T. O. Biggers, Tel. South 5030.

LATHAM (TROY), NEW YORK, 19 Aragon Ave., J. R. LeTourneur, Tel. State 5-6663.

LNCHBURG, VA., P.O. Box 1075. C. D. Mairs. Tel. 3-1215.

★LOS ANGELES 15, CAL., 119 E. Pico Bivd. P. M. Mason, Mgr. Tel. Richmond 7-9187, 7-5 88.
MEMPHIS, TENN., 4695 Dunn Rd., R. J. Lindhorst, Tel. Mutual 5-6750.

Tel. Mutual 5-6750.

MIAMI 37, FLA., 2101 Northwest 1st Ave., H. L. Simon, Tel. 82-0323.

MINNEAPOLIS, MINN., 2800 Texas Ave., St. Louis Park, Minn. Leonard Koehler. Tel. Midway 6236.

NASHVILLE 12, TENN., 1602 South Observatory Drive. W. J. Brauch. Tel. Cypress 2-5123.

NEW ORLEANS, LA., 59 W. Claiborne Square, Chalmette, La., L. A. Van Hooser. Tel. Edgewood 1-3106.

**NEW YORK 16 N.Y. 114 E. 27th St. W. C.

*NEW YORK 16, N.Y., 116 E. 27th St. W. G. Booth, Mgr. Tel. Murray Hill 9-1266, 9-1267, 9-1268.

**PHILADELPHIA 7, PA., 1316 Arch St. B. W. Merz, Mgr. Tel. Locust 7-1023.

PITTSBURGH 26, PA., 521 Brookline Blvd., Richard Marsh, Tel. Locust 3-3589.

PLANT CITY, FLA., 214 N. Gordon St. J. C. Margan. Tel. 3-2681

PORTLAND 7, ORE., P.O. Box 843, Marvin H. Corns. Capital 3-7500.
RAYNHAM, MASS., P.O. Box 141. W. P. Godek. Tel. Tauton 2-5149.

RUTHERFORD, N. J., 246 Sylvan St., Richard Whitson. Tel. Geneva 8-2178.

*ST. LOUIS, MO., 1517-21 Olive St., Z. X. Bennett, Mgr. Tel. Chestnut 1-2368. SALT LAKE CITY, UTAH, 1215 E. 13th South St.

L. F. Rosvall.

SAN ANTONIO, TEXAS, P.O. Box 201, H. E. Pearson. Tel. Pershing 2-2884.

SAN FRANCISCO 7, CALIF., 1275 Mission St. R. J. Vail. Tel. Underhill 1-1580.

SEATTLE, WASH., 808 Motor Pl. Paul Lockett. Tel. Seneca 8083.

TUPELO, MISS., 831 Strauss St., Lloyd Baldwin. Tel. 1859-J.

WAKEFIELD, MASS., 195 North Ave., H. Haber-

man Jr., Tel. Crystal 9-0455.

YORK, PA., 444 South George St. Richard L. Smith. Tel. York 8-5592.

FOREWORD

The one dominating idea back of "Union Special" is to build the best industrial sewing machines in the world.

All parts are made to gauges with exceedingly close limits. Repairs can be made with facility, as all parts are readily accessible, and are 100% interchangeable.

It is our constant aim to furnish carefully prepared information that will enable the customer to secure all possible economies and advantages from the use of Union Specials. On the pages which follow will be found illustrations and descriptions of the parts for styles in Classes 9900, 14700.

Additional catalogs, containing information relative to these machines, and which will be furnished on request, are listed below.

Catalog No. 29

List of Transmitter Parts and Miscellaneous Accessories

Catalog No. 45

Catalog No. 45 A

Price List of Needles

Form 357

Engineering Department Adjusting Instructions. Specify the Style number of the machine for which the adjusting in-

structions are required

In all manufacturing centers will be found Union Special representatives, who will co-operate with those who desire in planning and estimating their requirements.

UNION SPECIAL MACHINE COMPANY

Engineering Department

IDENTIFICATION OF MACHINES

Each Union Special carries a style number which is stamped in the name plate on the machine. Style numbers are classified as standard and special. Those which are standard have one or more letters suffixed but never contain the letter "Z". Example: 9900 S. Style numbers containing the letter "Z" are special. When only minor changes are made in a standard machine a "Z" is merely suffixed to the respective standard style number. Example: 9900 SZ.

Styles of machines similar in construction are grouped in the catalog under a class number, which differs from the style numbers in that it contains no letters. Example: 9900.

STYLES OF MACHINES IN CLASS 9900

- Flat Bed One Needle Machines, Bed 13 Inches Long, Double Locked Zigzag Stitch Type 404, Lateral Throw of Needle Adjustable from Zero to 3/16 Inch
- 9900 A For attaching labels, button-hole patches and button patches to garments and sundry operations; hinged presser foot with open front, feed surface on both sides of needle, Type 101 needle.
- 9900 E For seaming miscellaneous leather and cloth; abutted edge seam, Type FSa-1, with tape on underside, two-section bottom presser foot, feed surface on both sides of needle, Type 701 needle.
- 9900 C For purl stitching collars and fronts of knitted undergarments; non-differential feed, Type 101 needle.
- 9900 S For binding awnings and similar articles; selvage edge English binding attachment, Type 130 needle, standard width of binding 9/16 inch.
- 9900 Y For binding operations on knitted and woven fabrics; selvage edge English binding attachment, Type 101 needle, standard widths of binding 5/8 and 3/4 inch.
- 9900 Z A special style, similar to the standard styles in Class 9900, but differing in some of its component parts.
- 9900 AG For felling the edge of coat collars; Type 106 needle.

STYLES OF MACHINES IN CLASS 9900 (Cont'd)

- 9900 AH For purl stitching collars and fronts of knitted undergarments and shaping ends of collars; non-differential feed, fixed knife engagement upper trimming mechanism, Type 101 needle.
- 9900 AJ Fitted with differential feed mechanism; otherwise same as 9900 Q.
- 9900 AK For closing heavy shoes, hunting boots and similar articles; upper and under feed, Type 701 needle.
- 9900 AP For making self scallops on straps and hems of flat and warp knitted undergarments made from cotton, wool, rayon and silk; Type 101 needle.
- 9900 AQ For attaching knitted binding strips, split tube borders and bands to flat and warp knitted silk and rayon garments; body of fabric can be simultaneously gathered or left plain, long length strip cut parallel with the wale, offset differential feed, Type 101 needle, standard finished width of binding, split tube border or band, 1/4, 1/2, 1, 1 1/2 and 2 inches.
- 9900 AR For attaching laces with straight or irregular headings to light weight knitted and woven undergarments of every description; lapped seam, under trimming mechanism, Type 101 needle.
- 9900 AS For felling ready made waistbands to trousers, hand felling effect, one operation, waistband used in long lengths, power driven roller feed, adjustable guide to take waistbands ranging from 2 3/16 to 4 inches wide, Type 109 needle.

STYLES OF MACHINES IN CLASS 14700

- Flat Bed Single Needle Dual Stitch Machines, Straightaway Type 401 and Zigzag Type 401, Bed 13 Inches Long, Upper and Under Feed
- 14700 D For closing all weights of shoes; presser foot without tongue, Type 701 needle.
- 14700 E For closing extra heavy weight shoes; presser foot without tongue, Type 701 needle.
- · 14700 Z A special style, similar to the standard styles in Class 14700, but differing in some of its component parts.

APPLICATION OF CATALOG

This catalog applies only to the standard styles of machines as listed. It can also be applied with discretion to the special machines in Classes 9900 and 14700.

NEEDLES

TYPE NUMBERS AND SIZES

Each needle has a type number and size number. The former denotes the kind of shank, point, length, groove, finish, and other details. The latter denotes the largest diameter of the blade, measured in thousandths of an inch midway between the shank and eye, and is stamped in the needle shank. Collectively the type number and size number is the complete symbol.

To have orders promptly and accurately filled, the empty package, a sample needle, or the type and size number should be given. See marks on packages. An intelligent order would read as follows: "1000 Needles Type 106 Size .OhO."

The type number of the standard needle for each style of machine is listed in the description of the various styles.

The type numbers of the needles most commonly used in the styles of machines covered by this catalog are listed below. Set opposite each type number is the definition of the needle and sizes available.

Type No.	Description					
101	Round shank, round point, extra short, double groove, nickel plated-sizes 019, 022, 025, 027, 029, 032, 034, 036, 038, 040, 042, 044, 046, 049, 054					
101 A	Same as Type 101, except plain finish- size 040					
101 G	Same as Type 101, except chromium plated- sizes 032, 036, 040					
103	Round shank, round point, extra short, double groove, long blade, nickel plated- sizes 027, 032, 044					
104	Round shank, round point, extra short, double groove, spotted, nickel plated-sizes 036, 040, 042, 044, 049					
106	Round shank, round point, extra short, double groove, ball eye, nickel plated-sizes 025, 027, 029, 032, 034, 036, 038, 040, 042, 044, 049					

NEEDLES (Cont'd)

Type No.	Description
106 G	Same as Type 106, except chromium plated- sizes 029, 032, 036, 038, 040, 044
106 H	Same as Type 106, except ball point- size 040
106 GH	Same as Type 106, except ball point, chromium plated- sizes 036, 040
108	Round shank, round point, extra short, double groove, ball eye, spotted, nickel plated- sizes 032, 036, 038, 040, 042, 044, 049, 054
108 G	Same as Type 108, except chromium plated- sizes 032, 036, 040, 044, 049, 054
108 н	Same as Type 108, except ball point-sizes 036, 040
108 GH	Same as Type 108, except ball point, chromium plated-sizes 036, 040, 044
109	Round shank, round point, extra short, double groove, ball eye, government, nickel plated-sizes 027, 032, 036, 040, 044
109 G	Same as Type 109, except chromium plated- sizes 036, Oul
109 НА	Same as Type 109, except ball point, chromium plated- size 040
130	Round shank, round point, short, double groove, ball eye, government, spotted, nickel plated-sizes 032, 036, 040, 044, 049, 054, 060, 067
130 G	Same as Type 130, except chromium plated- sizes 040, 044, 049, 054, 060
701	Round shank, flat point, extra short, double groove- sizes 027, 029, 032, 034, 036, 038, 040, 042, 044, 049, 054, 060
701 G	Same as Type 701, except chromium plated- size 038

NEEDLES (Cont'd)

APPLICATION OF TYPE NUMBERS

The styles of machines covered by this catalog are listed below. Set opposite each style number is the type number or numbers of the needle generally used. Type numbers are arranged numerically, as the variety of the materials sewed on each machine makes it impractical to show a preference.

Machine Style No.	Type Nos. of Needles Used
9900 A	101, 101 A, 101 G, 103, 104, 106, 106 G, 106 H 106 GH, 108, 108 G, 108 H, 108 GH
9900 E	101, 701, 701 G
9900 Q	101, 101 A, 101 G, 103, 104
9900 S	130, 130 G
9900 Y	101, 101 A, 101 G, 103, 104
9900 AG	106, 106 G, 106 H, 106 GH, 108 G, 108 H, 108 GH,
9900 AH	101, 101 A, 101 G, 103, 104
9900 AJ	101, 101 A, 101 G, 103, 104
9900 AK	701
9900 AP	101, 101 A, 101 G, 103, 104
9900 AQ	101, 101 A, 101 G, 103, 104
9900 AR	101, 101 A, 101 G, 103, 104, 106, 106 G, 106 H, 106 GH, 108, 108 H, 108 GH
9900 As	109, 109 G, 109 HA
14700 D	701, 701 G
14700 E	701, 701 G

ORDERING REPAIR PARTS

PLATES

Grouped together according to scale will be found illustrations of parts similar in appearance and, to some extent, component parts that go together in the same subdivision of the mechanism.

When a given design of part is made in two or more sizes, only one illustration is usually shown. In ordering these pieces, it is necessary that the size be specified.

-8-

ORDERING REPAIR PARTS (Cont'd)

LIST OF PARTS

Turning from the plates to the list of parts, the description of each part and its principal uses will be found. Always check the symbol against its description before ordering. It is not necessary to furnish the plate number.

When a part is used or can be used in all machines covered by this catalog, no specific use is mentioned in the

description.

For convenience in ordering, minor parts such as screws, nuts and similar articles are repeated after each major

(-) A dash in the "plate number" column of the list of

parts denotes the absence of an illustration.

(‡) A double dagger in the "symbol to order by" column denotes that the component parts cannot be furnished separately.

IDENTIFYING PARTS

Where the construction permits, each part is stamped with its part number. Some of the smaller parts are stamped with an identification letter to distinguish them from parts similar in appearance.

All part numbers represent the same part, regardless of

the catalog in which they appear.

SUPPLIES

All supplies, including taps, reamers, belting, belt hooks, belt fasteners, belt pliers, screw drivers, whenches and powdered oil stone will be promptly furnished.

USE GENUINE NEEDLES AND REPAIR PARTS


Success in the operation of these machines can be secured only by the use of genuine Union Special Needles and Repair Parts as furnished by the Union Special Machine Company, its subsidiaries and authorized distributors. Obviously, it is to our interest to maintain the reputation of Union Specials by furnishing the very best goods obtainable. They are designed according to the most approved scientific principles, and are made with the utmost pre-cision. The maximum efficiency and durability are assured.

Genuine needles are put up in packages marked at the top "Trade 'UNION SPECIAL' mark". Genuine repair parts are stamped with a reproduction of the well known two padlocks with a link connecting the shackles. Both trade marks are symbolic of superlative excellence. All other needles and parts are bogus.


TERMS

Prices are strictly "net cash" and are subject to change without notice. Express and freight shipments are forwarded at the buyer's risk, f.o.b. shipping point. Parcel post shipments are insured unless otherwise directed. A charge is made to cover the postage and insurance.


Plate 1 - Full Size




9924




9924A




9924W




9924Y



14024



9928K



9928T

Plate 2 - Full Size




Plate 3 - Full Size




Plate 4 - Full Size




Plate 5 - Full Size



Plate 6 - Full Size

1059	2 80	91 A 2	9 22716	2230	22743	89
73 A	ij 79077	150	ਊ 187A	6 04	22 560	605
88 2	22561	•	704 7	•	5 86 B	187B
138	2 2565	C 3163	9 225	664 227	68 87	77
87 U	79048	96	98	25CC	88 A	22813
	98A	22570		22525	531	90
73	90A		91	7		
72	134	66 A 22	585 2	2524	12986B	57WD
22586	A 2256	SO B 99	225	91 8	1 94	93A
97	B6A 225	97A HS65	P-4 22	632F-2	+ 22734	22 747







Plate 9 - Full Size






Plate 11 - Full Size



Plate 12 - Full Size





Plate 13 - Full Size






Plate 15 - Full Size




Plate 16 - One-half Size




Plate 17 - One-half Size




Plate 18 - One-half Size




Plate 19 - One-half Size




Plate 20 - One-half Size




Plate 21 - One-half Size





Plate 22 - One-half Size



Plate 23 - One-half Size






Plate 25 - One-half Size




Plate 26 - One-third Size




Plate 27 - One-fourth Size




Plate 28 - One-fourth Size





Plate 29 - One-fourth Size






Plate 31 - One-fourth Size




Plate 32 - One-fourth Size




Plate 33 - One-eighth Size







Plate 34 - One-eighth Size















Plate 35 - One-eighth Size



				I OF PARIS	
Symbol to Order By	plate	s illus	trating	last column refer only to the the parts and are not to be fer to pink insert for prices.	Plate No.
2 A	9900 9900) E, 99) A H, 9	00 Q, 900 AK	left, for Styles 9900 A, 9900 S, 9900 Y, 9900 AG, , 9900 AP, 9900 AQ, 9900 AR, , 14700 E	17
2 U	Cloth	Plate ew No.	Cover	Latch, for Style 9900 AQ	17
5 6 B 6 E	Swingi Looper	ng Hea Avoid	d Rock Eccen	Shaft Collar (screw No. 95) tric Fork Shoe (screw No. 94) tric Fork (clamp screw No.	9
7 G	85, Feed B	set so locker.	rew No	. 72) tyles 9900 A, 9900 E, 9900 Q.	23
7 H	9900	AR (s	crew N	9900 AG, 9900 AH, 9900 AP, 0. 88)	29
•	9900	Q, 99 AP, 9	00 S, 900 A R	9900 Y, 9900 AG, 9900 AH, (clamp screw No. 22596)	29
8	diam	Rocker meter . DO D, 1	407 in	5 3/16 inches long, standard ich, for Styles 9900 AK,	20
8-408				standard diameter plus .001	_
8-409	a.	u ·	11	standard diameter plus .002 inch	_
8-410	H	Ħ	п	standard diameter plus .003 inch	_
8-413	, ti	ti	R	standard diameter plus .006 inch	_
8-416	н	#	"	standard diameter plus .009 inch	-
8-419	#	**	H	standard diameter plus .012	_
8-422 8 A	" Feed R	" ocker 9	" Shaft.	standard diameter plus .015 inch	<u> </u>
O A	dard 9900	diamet E, 990	er .40	or inch, for Styles 9900 A, 9900 S, 9900 Y, 9900 AG,	20
8 A- 408	1	Rocker			20
8 A- 410	41	tı	. 16	standard diameter plus .003	
8 A-413	n n	er er	a	standard diameter plus .006	_
8 A-416	н	11	Ħ	standard diameter plus .009	_
8 A-419		ŧŧ	11	standard diameter plus .012	_
8 A- 422	H	ŧŧ	11	standard diameter plus .015	-
	<u> </u>				<u> </u>

			4317	/r ranis	
Symbol to Order By	plates	illustra	ating t	ast column refer only to the the parts and are not to be er to pink insert for prices.	Plate No.
10	9900 E	9900) Q, 9	Sponge, for Styles 9900 A, 9900 S, 9900 Y, 9900 AG, (screw No. 94)	23
30.4	Feed Bar				23 23
10 A	reed Dar	Front			25
10 X	म स	*1		Sponge, for Style 9900 AH	
			(scr	rew No. 94)	23
11	H H		, for	Styles 9900 A, 9900 E,	
		9900	AH.	9900 AK, 9900 AP, 9900 AR,	
1					30
15	B	14100		14700 E- 0 1 - 1 - 1 - 1	20
15	reed Ura	mk rii	ık (sr	nim No. 1248, clamp screw	
ł	No. 22	2569 , z	nut No	o. 7947)	11
WA15	Stop Wat	ch			14
16	Feed Cra		ak Fer		
17	1000 010		ıd		13 8
	40 0		-		. 0
18				t-,	9 12
19	n ((screw No. 77)	12
OI-19	Pressure	Pump	Cil (Can, 1 1/2 pints capacity	35
20	Feed Cra	ınk Stı	id Was	sher; also for Nos. 9970 A,	
	0070 F	, к <u>и</u> з	035 -		9
21	Food Cr	nole Tin	ソノノ	n; also for Nos. 6956 A,	,
21	1 660 OL) /~~~	um Ma	. 77)	17
25.0					13
25 C		-	ucu 10	ong, for cloth plate attach-	_
	ments-				7
25 S				r stud washer; also for Nos.	
	14703.	23450	O B. 2	23450 D, 23450 E	7
25 T				oth plate slide	7
25 CC				late cover on Style 9900 AQ	6
28 C					Ь
20 U				iriving shaft pin on Style	
		900 A			6
31	Looper F	Rock Si	naft,	3 1/8 inches long, standard	
	diamet	er .40	07 inc	ch, for Style 9900 AR	20
31-408	Looper F	lock Sl	naft.	standard diameter plus	
	_		•	.001 inch	
31-410	#	lt.	'n	standard diameter plus	
) <u>-</u>				.003 inch	
31-413	**	fł.	#1	standard diameter plus	_
J 1 -41 J					
~~ ! ~ /	ì _	••	**	.006 inch	
31-416	H H	16	##	standard diameter plus	
				.009 inch	
31 - 419	#1	Ħ	н	standard diameter plus	
				.012 inch	
31-422) #	Ħ	HE	standard diameter plus	
) 	1			.015 inch	
3 0	1 11	Ħ	¥		
32				1 1/8 inches long, standard	3.0
, _		_		diameter 407 inch	19
32 - 408	**	ti	11	standard diameter plus	
				.001 inch	-
32 - 410	1 11	н	H	standard diameter plus	
	1			.003 inch	-
	<u>L</u> _				

Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
32-413	Looper Rock Shaft, standard diameter plus .006	
32-416	" " standard diameter plus .009	_
32 - 419	" " standard diameter plus .012	_
32-422	" " standard diameter plus .015	
T32	Screw, for feed clutch support on Style 9900 AS	8
36 G	Looper Connecting Rod Ball Stud Washer; also for No. 11654	9
37 L	Tension Release Connecting Rod Nut, left thread, for styles in Class 14700	9
37 R	Tension Release Connecting Rod Nut, right thread, for styles in Class 14700	9
38 V	Looper Avoid Eccentric, for Style 9900 AS (spot screw No. 96)	11
40 41 A	Frame Looper Thread Guide, lower, right Hand Lifter, for Styles 9900 Q, 9900 S, 9900 Y, 9900 AG, 9900 AH, 9900 AP, 9900 AQ,	10
42 A 43	9900 AR, 9900 AS (stud No. 86) Hand Lifter Screw Pin Feed Lift Eccentric, for Styles 9900 A,9900 E, 9900 Q, 9900 Y, 9900 AG, 9900 AH, 9900 AJ,	15 7
43 X 47	9900 AK, 9900 AP, 9900 AQ, 9900 AS, 14700 D, 14700 E (spot screw No. 96)	11
48 50 D	14700; also for No. 9961 A Needle Lever Stud Washer Needle Bar (screw No. 88)	9 9 20
52 A	Needle Lever Thread Eyelet, for Styles 9900 A, 9900 Q, 9900 S, 9900 Y, 9900 AG, 9900 AH, 9900 AJ, 9900 AP, 9900 AQ, 9900 AR, 9900 AS; also intermittent needle thread nipper leadin eyelet for Styles 9900 A, 9900 E,	
53 A	9900 AK, 14700 D, 14700 E (screw No. 98 A) Needle Bar Thread Guide, for Styles 9900 A, 9900 Q, 9900 S, 9900 Y, 9900 AG, 9900 AH, 9900 AJ, 9900 AP, 9900 AQ, 9900 AR, 9900 AS, (screw No. 22768, washer No. 652 C-9)	
TA54 TA55	Hand Tally	25
56 57 W	Needle Clamp Nut Needle Bar Thread Nipper Assembly, for Styles 9900 Q, 9900 Y, 9900 AJ, 9900 AP, 9900 AQ; one each Nos. 57 WA, 57 WB, 57 WC, 57 WD, 22560	10

	T TIST OF TARTS
Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.
57 WA	Needle Bar Thread Nipper Collar (screw No. 22560) 10
57 WB	" Plate 10
57 WC	" " " Spring 14
57 WD	Needle Bar Thread Nipper Spring Stud; also for Nos. 9939 S, 15480 C, K45258 6
61 B	Presser Bar Connection, for Styles 9900 A, 9900 E, 9900 Q, 9900 S, 9900 Y, 9900 AG, 9900 AH, 9900 AJ, 9900 AP, 9900 AQ, 9900 AR (set screw No. 89, clamp screw
(0.5	No. 97)12
62 B	Presser Guide Bar, standard diameter .319
62 B-322	inch (set screw No. 22560 B) 20 Presser Guide Bar, standard diameter plus
02 B-722	.003 inch
62 B-325	" " standard diameter plus
02 0)2)	.006 inch
62 B-328	" " standard diameter plus
02 2)20	.009 inch
62 B-331	" standard diameter plus
02 0))-	.012 inch
62 B-334	" " standard diameter plus
64	* Spring Rest (screw No. 88) 21
64 A	" Regulating Screw 8
64 B	" Lock Nut 9
HS65 P-4	Needle Thread Tension Take-up Spring Stud,
	for Style 9900 AR 6
68 в	Main Shaft Sleeve, right 13
69 s	Spool Pin, 4 inches long, for thread stand 35
69 FD	Screw, square head, cup point, 5/16 inch
•	diameter, 18 threads per inch, 5/8 inch
	long, for thread stand seat 8
70	Looper Avoid Eccentric Sponge Holder and
	Sponge (screw No. 93) 23
70 A	Looper Avoid Eccentric Sponge; also for No.
	9945 12
72	Set Screw, for looper avoid eccentric fork 6
73 73 A	" " for looper 6
73 A	Screw, for looper needle guard; also for
m1	No. K47278 6
74	Screw, for swinging head control lever on
	Styles 14700 D, 14700 E 7
7 5	Clamp Screw, for cam gear segment arm on
	Styles 14700 D, 14700 E; also for Nos.
9 5 4	6956 A, 9951 AH, 14790 A 7
75 A	Screw, front, for loop retainer lever
70	connecting rod; also for No. 15879 A 7
77	Set Screw, fillister head, for upper needle
	lever link pin; also for Nos. 19, 21,
	A3849 C6

-48-

Symbol to order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
77 A	Screw, for loop retainer; also for Nos. 9925 AR, 15847 A	6
78	Set Screw, headless, for lower needle lever link	6
79	Clamp Screw, for needle rear guard on Style 9900 AS; also for No. 9939 A	7
80 81	Screw, for cloth plates	7
82 84 B	Screw, for regulating length of stitch Stitch Regulating Ferrule	7 9
85 86	Clamp Screw, for looper avoid eccentric fork; also for Nos. 6967 E, 9945	7
86 A 86 X	" " Stud, plus size threads (tap No. V113) Screw, for rock shaft plunger roller on Styles	7 6
87	14700 D, 14700 E Screw, for throat plates; also for Nos. 129, 9925,	7
87 U	14725, 21390 D, 21390 AS, K38616 Screw, for knife bar depresser cam on Style	6
88	9900 AR; also for No. A3830 A	6
A 88	15465 F, 21113 B, K44621, K47790 Screw, for cloth plate slide stop plate on Style	6
89	9900 Y	6
90	Screw, for looper thread nipper spring; also for Nos. 9950, 9972, 14741, 21390 E	6
91 91 A	Clamp Screw, for presser feet	6
93	9994, 9994 A	6
93 A	Screw, for lifter lever extension; also for Nos. 753, 9926 L, 9944, 9944 AG, 9944 AH, 9970 A, 9970 B, 14705 B, 14744 A, K44560	6
94	Screw, for looper avoid eccentric fork shoe; also for Nos. 10, 10 X, 908, 9932, 9939 N, 9946, 12835, 14736, 15447 G, K44622	6
95	Screw, for swinging head rock shaft collar; also for Nos. 9660 B, 9943 C, 9963, 15878 D, 41258 D	6
96	Spot Screw, for feed lift eccentrics; also for Nos. 38 V, 43 X, 9967 A, 14787 A, 15880 A, K47850	6
96 A	Spot Screw, for looper avoid eccentric on Styles 9900 A, 9900 E, 9900 Q, 9900 S, 9900 Y, 9900 AG, 9900 AH, 9900 AJ, 9900 AK, 9900 AP, 9900 AQ,	
	9900 AR, 14700 D, 14700 E	6

Symbol	The figures in the last column refer only to the	Plate
to	plates illustrating the parts and are not to be	No.
Order By	used in ordering.Refer to pink insert for prices.	
97	Screw, fillister head, for supporting feed	
	dog: also for Nos. 61 B. 103, 707, 9947.	
07.4	14742, 15872 A, 15872 B, 15872 L, 21390 F	6
97 A	Screw, for connecting rod ball joints; also for Nos. 9949, 9964, 11654	7
98	Screw, for tension thread eyelets; also for	•
	Nos. 482, 9967 A, K47850	6
98 A	Screw, for needle lever thread eyelets; also for Nos. 9966, 21632, 21632 B	6
100 в	Thread Stand Wire, 16 inches long (set screw	0
	No. 22632 F-24)	31
101 V	Looper Thread Take-up (spot screw No. 89)	10
103	" " Eyelet (adjusting	17
104	screw No. 97) Eyelet Spring (screw	1 1
	No. 93)	12
105-2 1/2	Thumbscrew, 2 1/2 inches long, for fastening	
105-3	machine to table	25 25
105-3 1/2	" 3 1/2 inches long	25
107	Tension Spring Ferrule	10
108	" Regulating Nut	9
109	" Disc, with contact surface 5/64 inch	
* · · · · · · · · · · · · · · · · · · ·	wide, for machines using needle threads the equivalent in size of	
	No. 50 and smaller	10
109 B	Tension Disc, with contact surface 1/8 inch	ļ
	wide, for machines using needle threads the equivalent in size of No. 40 and	
	larger	10
110-1	Tension Spring, .026 inch diameter wire, for	
110-2	looper threads Tension Spring, .028 inch diameter wire, for	14
110-2	needle threads	14
110-3	Tension Spring, .O40 inch diameter wire, for	
	needle threads; also for Nos. 14740,	1,1
111	Z1182 J	14
	9900 (screw No. 98)	10
V113	Tap, marked "Q-2" for plus size hand lifter	
114	stud	14
116	Wrench, 9/32 inch opening, for needle clamp	24
118	Thread Hook	24
118 3	Thread Tweezers	25
V118	Tap, marked "X-2" for plus size cloth plate screws	14
119	Stay Box Assembly, for Style 9900 E; one	**
,	each Nos. 119 A, 119 B, 119 C	33
119 A	Stay Box Fivot Stud	8
119 B	" " Cover	<u> </u>

	DIOT OF FARTS	
Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
119 C	Stay Box	
	Soldy Box Charle (at a some No. 91)	3.0
126	Cam Gear Stud (set screw No. 81)	19
129	Presser Guide Bar Washer (screw No. 87)	21
134	Screw, for cloth plate cover latch on Style	6
136	Screw, for upper knife bar shaft bearing on Style 9900 AH	7
137	Thread Controller Thread Eyelet, for Styles 9900 A, 9900 C, 9900 S, 9900 Y, 9900 AG, 9900 AH, 9900 AJ, 9900 AP, 9900 AQ, 9900 AR,	·
138	9900 AS Thread Controller Thread Eyelet Screw; also for	10
141	No. 21624	6
	9969, 14777	7
150	Stop Screw, for cloth plate slide; also for No. 9947	6
154	Needle Lever Euffer, wood fibre	11
156	" Ball Stud	8
	" " Thread Eyelet, right (screw No.98 A)	
158		10
161	Stop Collar, for binding holder assembly; also for No. 14775 (screw No. 88)	9
162	Needle Bar Connection	11
168	Presser Spring, for Styles 9900 A, 9900 E,	[
100	9900 S, 9900 AH, 9900 AJ, 9900 AK, 9900 AS,	
	14700 D, 14700 E	20
168 E	Presser Spring, for Style 9900 AR	20
	Comes for models through tonging malages on	20
187 A	Screw, for needle thread tension release on	ļ
	Styles 14700 D, 14700 E; also for Nos. A3902,	
	6956 н, 9930 д, 9930 м, 9930 д, 9930 ч, 14030,	[
	23215 AE, 23215 AF, 23223 K, 23223 L, 23223 R,	
	23223 S, 23450 C, K41276	6
187 B	Screw, for throat plate tongue on Style 9900 S	6
213	Looper Rocker, for Styles 9900 A, 9900 E, 9900 Q,	
	9900 S, 9900 Y, 9900 AG, 9900 AH, 9900 AJ,	
	9900 AK, 9900 AP, 9900 AQ, 9900 AR, 14700 D,]
	14700 E	18
227 C		10
2 23 C	Screw, for presser foot stripper blade on Style	6
01.0	9900 AQ	0 .
249	Nut, for swinging head control lever lock pivot	
	stud on Styles 14700 D, 14700 E	9
258	Loop Retainer Lever Ball Stud Nut, for Styles	•
	9900 A, 9900 E, 9900 Q, 9900 S, 9900 Y,	
	9900 AG, 9900 AH, 9900 AJ, 9900 AK, 9900 AP,	Į.
	9900 AQ, 9900 AR, 14700 D, 14700 E; also for	1
	No. 15879 E	9
267	Feed Driving Arm Supporting Shaft Collar, for	1 1
-01	Style 9900 AS	ا ا
260		9
269	Looper Connecting Rod Nut, left thread	9
303	Clamp Screw, for loop retainer lever fork; also	1
	for No. A3829	7
	£3	

	LIST OF PARTS	,
Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
1 320	Tension Release Connecting Rod Ball Joint,	_
• -	lower, for Styles 14700 D, 14700 E (screw	
325	No. 97 A)	18
325	Straightaway Stitch Locking Plunger Stand Thread Guide, for Styles 14700 D, 14700 E	17
330 A	Main Shaft Sleeve, left	21
330 A 380	Cloth Plate Swinging Extension Spring, for	ļ
	Style 9900 AQ (screw No. 22564)	14
413	Oil Can, complete	31
416 A	Lifter Lever Extension (screw No. 93 A)	28
420 421	" " Stud; also for No. 6948 B Chain, 38 inches long	8 24
421 C-34	Knife Depresser Lever Chain, 34 inches long,	-4
	for Style 9900 AR	24
422	Lifter Treadle (screw No. 22813)	28
423	# Base	25
424	" Pin (screw No. 22813)	19
426 A 426 C	Lever Spring Pin	13 14
454 A	Washer, for needle lever link pin clamp screw	144
	on styles in Class 9900; also for No. 14788	9
462	Cam Gear Segment Stud Nut	9
‡ 478	Swinging Head Link Shell Ball Stud (nut No.	
482	9937)	8
402	8 A, 9939 F (screw No. 98)	21
¥500-257	Expansion Reamer, for needle bars, size	
	.257 inch	30
Y502-319	for presser bars and presser	
VE 02-322	guide bars, size .319 inch	30
Y502 - 322 Y502 - 325	" size .322 inch	30 30
¥502-328	" size .328 inch	30
¥502 - 331	" size .331 inch	30
Y505-407	" for feed rocker shafts, size	
WEST LAS	.407 inch	30
Y505-410	3126 .410 111011	30
Y505-413 Y505-416	size .413 inch	30 30
Y506-530	Expansion Reamer, for swinging head rock shaft	٦
-,,,,-	and main shafts, size .530 inch	30
Y506-533	Expansion Reamer, size .533 inch	30
Y506-536	" size .536 inch	30
531	Screw, for feed rocker on Styles 9900 AJ,	
4 ol.	9900 AQ; also for No. 9939 P	. 6
604	Screw, for stationary knife holder on Style	6
605	Screw, for presser foot spring on Style 9900 E	L.
650-24	Stove Bolt, flat head, 1/4 x 3 inches, for	
->+	base plate	8
	F	- <u>-</u> -

	1	T
Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
650 X-18	Carriage Bolt, 5/16 x 2 1/4 inches, for	_
/ m	attaching "Electro Drives"	8
650 X-22		8
650 X ~3 2	" 5/16 x 4 inches	8
652-16	Washer, 1/4 inch	9
652-20	* 5/16 inch	<u> </u>
652 C-9	Shake-Proof Lock Washer, for needle bar	
- - ,	thread eyelets	
660-112	Spring and Catch, for tray No. 21379 A	9 14
660-159	Idle Pulley, set of two, for leading floor	1 ***
000-179		
	treadle lifter chain away from transmitter	00
202	on American Safety Table installations	28
707	Swinging Head Link (clamp screw No. 97)	18
713	Cam Gear Segment Link Screw, front	7
714	Cam Gear Segment Link Screw Lock Nut	9
753	Adjustable Cone, for strip holder on Style	1.
_	9900 AS (screw No. 93 A)	24
Y800 -	Taper Reamer, for lever end of needle lever	l
	stud	30
Y801	Taper Reamer, for frame end of needle lever	[_
	stud	30
Y802	Taper Reamer, for needle lever link pin and	
1002	feed crank link pin	30
820	Screw, for straightaway stitch locking plun-	ارا
0-4	ger stand on Styles 14700 D, 14700 E; also	
	for Nos. 9959 AG, 9959 AH	8
900	Cloth Plate Slide, right, for Styles 9900 AK,	. Ŭ
700	14700 D, 14700 E	17
906	Knife Depresser Bracket Stop Screw (nut No.	1 + 1
700	907)	7
906 A	Upper Feed Dog Stop Screw, for Styles	!
700 A	9900 AK, 14700 D, 14700 E	7
907	Upper Feed Dog Stop Screw Lock Nut, for	'
301		1
	Styles 9900 AK, 14700 D, 14700 E; also for	
- 008	No. 906	9
908	Feed Bar Prong and Sponge, for Styles	7.7
1050	9900 AK, 14700 D, 14700 E (screw No. 94)	23
1059	Screw, for upper feed lift lever roll pin on	1
41070 4	Styles 9900 AK, 14700 D, 14700 E	6
‡1230 A	Needle Lever Connecting Rod Upper Bearing	
	(screw No. 22587)	18
1230 B	Needle Lever Connecting Rod Upper Bearing	l .
	Valve Spring	14
1230 C	Needle Lever Connecting Rod Tube (nut, left	
	thread No. 15430 C, nut, right thread No.	
	15430 D)	19
1230 D	Needle Lever Connecting Rod Upper Bearing	\
-	Valve (valve screw No. 22586 A)	13
1248	Feed Crank Link Shim, leather	1~9
		′
	L	<u> </u>

Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
1275 A	Needle Lever Stud, taper bearing, standard diameter, for Styles 14700 D, 14700 E (nut No. 47, washer No. 48, plug screw No.22586 B)	19
1275 E		19
1275 F	Needle Lever Stud, plus size on LEVER section, viz: .001, .002, .003, .006 inch; specify plus amount. Example: 1275 F-003 represents	19
1275 Н	Needle Lever Stud, plus size equal on EACH section, viz: .001, .002, .003, .006 inch; specify plus amount. Example: 1275 H-003 represents a stud plus .003 inch on EACH	
1275 J	Needle Lever Stud, plus size unequal on each section, viz: (.001, .002) (.001, .003) (.001, .006) (.002, .001) (.002, .003) (.002, .006) (.003, .001) (.003, .002) (.003, .006) (.006, .001) (.006, .002) (.006, .003) (.012, .001) (.012, .002) (.012, .003) (.012, .006) (.018, .001) (.018, .002) (.018, .003) (.018, .006). Specify plus amounts, arranged FRAME section first and LEVER section last. Example: 1275 J-003-006 represents a stud plus .003 inch on FRAME section and .006 inch on LEVER section, 1275 J-006-003 represents a stud plus .006 inch on FRAME section and .003 inch on LEVER section (screw No. 22586 B) Needle Lever Stud Felt No. 15430 L. Note: Before lapping the bearing of a needle lever and a needle lever stud remove the felt from the stud and replace it after the lapping compound has been washed out.	19
1276	Needle Lever Stud, cone bearing, for styles in Class 9900 (nut No. 47, washer No. 48)	19
1280 1286	Needle Lever Ball Clamp Bolt Nut; also for No. 15745 B Needle Lever Link Pin Assembly; also for Nos.	9
	15446 D, 15872 B; one each Nos. 1286 A, 1286 B, 12964 C, 22560	13
1286 A 1286 B	Needle Lever Link Pin (set screw, upper No. 77, clamp screw No. 22826) Needle Lever Link Pin Spring	13 14
1332	Lifting Plunger Screw Pin, for Styles 14700 D,	7
1346	Tension Post, 1 11/16 inches long; also for No. 21182 J	10

Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
1347	Tension Post Ferrule; also for No. 21182 J	10
1349	" Spring, .036 inch diameter wire, for needle threads	14
1361 A	Presser Spring Pin; also for No. 14740	13
1362	Main Shaft Sleeve Pin	13
1859	Needle Rear Guard Holder, for Style 9900 AS	
	(screw No. 22528)	16
3336	Knife Depresser Spring, for Style 9900 AR Throat Plate Cloth Guide, for Style 9900 AR	14
A3828 A	(screw No. 22716)	2
A3828 B	Stationary Knife Holder, for Style 9900 AR	_
	(screw No. 604)	10
A3828 E	Throat Plate, for Style 9900 AR (screw No. 87)	2
A3829	Feed Dog, for Style 9900 AR (screw No. 303)	3
A3830 A	Penetrating Knife, for Style 9900 AR (screw No. 87 U)	10
A3849 C	Stationary Knife, for Style 9900 AR (screw	-0
	No. 77)	10
A3864 A	Presser Foot, for Style 9900 AR (clamp screw No. 91)	4
A3902	Cloth Guard, for Style 9900 AR (screw No.	
AZ003	187 A)	15
A 3991 A 4043	Knife Depresser Bracket, for Style 9900 AR	
******	(screw No. 22517)	22
4937	Swinging Head Control Lever Lock Pivot Stud,	1
631 7	for Styles 14700 D, 14700 E	7
5143	Differential Feed Bar, for Styles 9900 AJ,	23
5144	9900 AQ	رع
) 	Styles 9900 AJ, 9900 AQ	9
5156 A	Feed Rocker, for Styles 9900 AJ, 9900 AQ (screw	
	No. 531)	23
5157 A	Feed Rocker Arm, for Styles 9900 AJ, 9900 AQ (screw No. 22548)	21
5630	Cloth Plate Slide, left, for Style 9900 AJ	17
6013	Looper Rocker, for Style 9900 AS	118
6015 B	Needle Lever, for styles in Class 9900	28
6037	Looper Connecting Rod (nut, right thread, No.	
4/070	18, mut, left thread, No. 269)	20
‡ 6038	Looper Connecting Rod Ball Joint, left, for Styles 9900 A, 9900 E, 9900 Q, 9900 S,	
	9900 Y, 9900 AG, 9900 AH, 9900 AJ, 9900 AK,	1
	9900 AP, 9900 AQ, 14700 D, 14700 E (screw No.	1
	97 A)	11
‡ 6038 в	Looper Connecting Rod Ball Joint, left, for	
4/070	Style 9900 AS (screw No. 97 A)	11
1 6039	Looper Connecting Rod Ball Joint, right (screw	1
	No. 97 A, ball stud washer No. 36 G, nut No. 18)	11
	44/	1

Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
6042	Needle Lever Ball Clamp Bolt, for Styles	
6042 A	14700 D, 14700 E (nut No. 1280) Needle Lever Ball Clamp Bolt Washer	8 9
6060	Main Shaft Bushing, left, for Styles 9900 A, 9900 E, 9900 Q, 9900 S, 9900 Y, 9900 AG, 9900 AH, 9900 AJ, 9900 AK, 9900 AP, 9900 AQ, 9900 AS, 14700 D, 14700 E) 11
6090 A	Needle Lever Stud Sleeve, for styles in Class 9900	
6091	Needle Lever Nut, front, hexagonal, for styles in Class 9900	19
6091 A	Needle Lever Nut, rear, cylindrical, for styles in Class 9900	9
6092	Needle Lever Stud Sleeve Key, for styles in Class 9900	9
6093	Needle Lever Cone, for styles in Class 9900 (set screw No. 88)	13 11
6215	Needle Lever, for styles in Class 14700	28
6402 F	Cloth Plate Slide, right, for Style 9900 Y (thumbscrew No. 25 T)	17
6606	Feed Lift Cam, for Style 9900 S (spot screw No. 96)	11
6939	Needle Lever Ball Clamp Bolt, for styles in Class 9900 (nut No. 1280)	8
6948 A	Knife Depresser Lever, for Style 9900 AR (screw No. 22585)	16
6948 в	Knife Depresser (stud No. 420)	23
6948 D	" Cam Stud	7
6956 A	Knife Bar, for Style 9900 AR (adjusting screw No. 75)	23
6956 В	Depresser Cam, for Style 9900 AR (screw No. 87 U)	15
69 56 ¢	<pre>" " Spring, for Style 9900 AR</pre>	14
6956 н	Adjusting Screw Retaining Spring (screw No. 187 A)	14
6967 E	" " Carrier, for Style 9900 AR (clamp screw No. 85)	23
6967 F	" Carrier Supporting Screw Bushing, for Style 9900 AR	13
6967 L	" " Carrier Fork Link, for Style	21
6968 в	" Eccentric Fork Felt, for Style 9900 AR	
7446 а	Looper Rock Shaft, 3 3/32 inches long, standard diameter .407 inch, for Styles 9900 A, 9900 E, 9900 Q, 9900 S, 9900 Y, 9900 AG, 9900 AH, 9900 AJ, 9900 AP, 9900 AQ, 9900 AR, 9900 AS, 14700 D,	
7446 л -	Looper Rock Shaft, standard diameter plus OOl inch	19

Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
7446 A-410	Looper Rock Shaft, standard diameter plus	
7446 A-413	.003 inch	_
7446 A-416	.006 inch	
7446 A-419	" " standard diameter plus	
7446 A-422	.012 inch	_
7638 A	.015 inch	17
7939	Tension Release Connecting Rod, for styles in Class 14700 (nut, left thread, No. 37 L,	-,
. •	nut, right thread, No. 37 R)	20
7947	Feed Crank Link Nut	- 9
8842 8843		2 2 22
9 25 5	Cam Gear Segment Stud Washer	9
9263	# # #	8
9264	" " " Ferrule	21
9660 B	" " " Link Forked Arm Collar, for	
	styles in Class 14700	
001.6	(screw No. 95)	9
9846 A	Screw Stud, for retractable gauge on Style	7
9901	Cloth Plate, for Styles 9900 A, 9900 E,	7
, ,,	9900 Q, 9900 S, 9900 Y, 9900 AG, 9900 AK	
	(screw No. 80)	33
9901 B	Cloth Plate, for Style 9900 AR (screw No.80)	33 33
9901 AH	for Style 9900 AH (screw No. 80)	33 33
9901 AS 9902	for Style 9900 AS (screw No. 80)	<i>3</i> 3
7702	Cloth Plate Slide, right, for Styles 9900 A, 9900 E, 9900 Q, 9900 AG, 9900 AJ, 9900 AP	
9902 B		17
9902 R	" " right, for Style 9900 S	17
),,u= 1.		17
9902 A H	Cloth Plate Slide, right, for Style 9900 AH	
9903 E	Cloth Plate Guide, for Style 9900 E (screw	17
0007 D		16
9903 R	Cloth Plate Slide Extension Guide, for Style 9900 S (screw No. 22561)	15
9904	Cast-off Wire, for styles in Class 9900 (screw No. 22524)	5
9905	Feed Dog, for Styles 9900 A, 9900 E (screw	
	No. 93)	3 3
9905 н	" " for Style 9900 Q (screw No. 93)	3
9905 J	" " for Styles 9900 AG, 9900 AP,	
9905 W	14700 D (screw No. 93)	3 3
	1	

Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
9905 Y	Feed Dog, for Style 9900 Y (screw No. 93)	3
9906	Feed Lift Eccentric, for Style 9900 AR (spot screw No. 96)	11
9907	Looper, with guard, for Styles 9900 A, 9900 E, 9900 S, 9900 AG, 9900 AK, 14700 D, 14700 E (guard No. 9910, guard screw No. 73 A)	5
9907 P	Looper, with guard, for Styles 9900 Q, 9900 Y, 9900 AJ, 9900 AP, 9900 AQ (guard No. 9910,	
9907 A H	guard screw No. 73 A)	5
9908	Looper, without guard; otherwise same as No.	5
9908 P	without guard; otherwise same as No.	
9908 AD	without guard, for Style 9900 AR	5 5
9908 AH	" without guard; otherwise same as No. 9907 AH	_
9908 AS	without guard, for Style 9900 AS Looper Set Screw No. 73	5
9910	Looper Needle Guard, marked "W" for Styles 9900 A, 9900 E, 9900 C, 9900 S, 9900 Y, 9900 AG, 9900 AJ, 9900 AK, 9900 AP, 9900 AQ,	
9910 A H	14700 D, 14700 E (screw No. 73 A)	5
9911	9900 AH (screw No. 73 A) Loop Retainer, marked "AC" for Styles 9900 A, 9900 E, 9900 Q, 9900 S, 9900 Y, 9900 AH, 9900 AJ, 9900 AK, 9900 AP, 9900 AQ, 9900 AR,	5
9920	14700 D, 14700 E (screw No. 77 A) Presser Foot, for Style 9900 A (screw No. 91)	2 4
9920 G	" " for Styles 9900 Q, 9900 AG (screw No. 91)	4
9920 Y	Presser Foot, for Style 9900 Y (spring No. 15480 C, spring screw No. 57 WD, clamp	
9920 AC	screw No. 91)	4
9920 AE 9920 AS	Presser Foot, for Style 9900 S (screw No. 91) for Style 9900 AS (screw No.	4
9921	Eccentric Pulley (set screw No. 22597 A, spot	4
9922	screw No. 22597)	18
9922 AH		31

Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
9924	Throat Plate, for Styles 9900 A, 9900 E (screw No. 87)	1
9924 A	Throat Plate, for Style 9900 Q (screw No. 87, tongue No. 9930 A, tongue screw No. 187 A)	1
9924 W	Throat Plate, for Style 9900 S (screw No. 87, tongue No. 9930 S, tongue Screw No. 187 B)-	1
99 2 4 Y	Throat Plate, for Style 9900 Y (screw No. 87, tongue No. 9930 Y, tongue screw No. 187 A)	1
9924 AS	Throat Plate, for Style 9900 AS	2
9925	Throat Plate Needle Rear Guard, marked "AI" for Styles 9900 A, 9900 E, 9900 Q, 9900 S, 9900 Y, 9900 AG, 9900 AH, 9900 AK, 9900 AP (screw No. 87)	5
9925 AR	Needle Rear Guard, for Style 9900 AR (screw No. 77 A)	5
9925 AS	" " for Style 9900 AS (screw No. 79)	5
9926 K	Lower Feed Dog, for Styles 9900 AK, 14700 E (screw No. 93)	3
9926 L	Upper Feed Dog, for Style 9900 AK (screw No. 93 A)	İ
9926 P	Feed Dog. for Style 9900 AH (screw No. 93)	3 3
9927 N	Presser Foot, for Styles 9900 AK, 14700 E (screw No. 91)	4
9927 Q	Presser Foot, for Style 9900 AG (clamp screw No. 91, yielding spring guide No. 9994, guide screw No. 91 A, guide support No. 9994 A, guide support screw No. 91 A)	4
9927 R	Presser Foot, for Style 9900 AH (clamp screw No. 91)	4
9928 к	Throat Plate, for Styles 9900 AK, 14700 E (screw No. 87, tongue No. 9930 M, tongue	_
9928 т	Throat Plate, for Style 9900 AH (screw No. 87,	1
9930 A	tongue No. 9930 Q, tongue screw No. 187 A) Throat Plate Tongue, for Styles 9900 Q, 9900 AJ	2
9930 M	(screw No. 187 A)	2
9930 Q	Throat Plate Tongue and Stationary Knife, for Style 9900 AH (screw No. 187 A)	2
9930 s	Throat Plate Tongue, for Style 9900 S (screw No. 187 B)	2
9930 Y	Throat Plate Tongue, for Style 9900 Y (screw No. 187 A)	2
9931	Feed Bar, for Styles 9900 A, 9900 E, 9900 Q, 9900 S, 9900 Y, 9900 AG, 9900 AH, 9900 AP	_
9931 B	(screw No. 88)	26 29
9932	Lower Feed Bar Shoe, for Styles 14700 D,	-/
//J -	14700 E (screw No. 94)	23
	-50-	

Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
9933	Presser Spring, for Styles 9900 Q, 9900 Y,	
0071	9900 AG, 9900 AH, 9900 AJ, 9900 AP, 9900 AQ Thread Controller Rack (screw No. 22519)	26
9934	Swinging Head	21 29
9935 9936	" " Link Shell Ball Stud Washer	
9937	" Link Shell Ball Stud Nut; also	9
7771	for Nos. 15403 R, 22567	9
9939	Feed Clutch Shaft, for Style 9900 AS (pin set	′
	screw No. 28 C)	19
9939 A	Feed Clutch Disc, right, for Style 9900 AS	
	(screw No. 79)	21
9939 B	Feed Clutch Driving Sleeve	21
9939 C	" Lever, for Style 9900 AS (screw	.
9939 D	No. 93)	21 23
9939 E	" Rock Shaft Arm, right, for Style 9900 AS	رع
//// -	(screw No. 93)	21
9939 F	" Rock Shaft, 7 1/8 inches long, for Style	
	9900 AS (collar No. 482, collar screw	
	No. 98)	29
9939 G	" Rock Shaft Arm, left, for Style 9900 AS	
9939 н	(screw No. 93)	21
7777 11	93)	29
9939 J	Feed Clutch Support, for Style 9900 AS	[-/
	(screw No. T32)	29
9939 K	Flexible Shaft, for Style 9900 AS	19
9939 L	Presser Bar Connection and Roller Support, for	
0070 11	Style 9900 AS	15
9939 N	Presser Foot Shank Bracket, for Style 9900 AS (screw No. 94)	16
9939 P	Lower Feed Roll, for Style 9900 AS (screw No.	10
7777 +	531)	11
9939 Q	Lower Feed Roll Shaft, for Style 9900 AS	
9939 R	Presser Foot Shank, for Style 9900 AS (pin No.	
	21, pin set screw No. 77)	16
9939 S	Presser Foot Spring, for Style 9900 AS (stud	1
0070 5	No. 57 WD)	. 4
9939 T	Needle Rear Guard Holder Block (screw No. 22548)	22
9939 V	Upper Feed Roll, knurled (screw No. 22560)	11
9939 W	Roller Feed Universal Joint, left, for Style	
7757 "	9900 AS	13
9939 X	Roller Feed Universal Joint, right, for Style	-
·	9900 AS	13
9939 Y	Roller Feed Universal Joint Intermediate	1
	Shaft, for Style 9900 AS	13
9939 Z	Feed Driving Arm, upper, for Style 9900 AS	21
9939 AA	* * Supporting Shaft, for	
	Style 9900 AS	20
	_60-	

9939 AB 9940 Style 9900 AS (screw No. 14076)	Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate
9940-531 9940-533 9940-536 " " " standard diameter plus .001 inch standard diameter plus .002 inch standard diameter plus .005 inch standard diameter plus .005 inch standard diameter plus .006 inch standard diameter plus .006 inch	9939 AB		
9940-531 9940-536 9940-536 9940-536 9940-536 9940-537 9940-537 9940-538 " " " standard diameter plus .003 inch standard diameter plus .006 inch standard diameter plus .006 inch 200 inch	9940	Swinging Head Rock Shaft, standard diameter	Ť
9940-533 9940-536 " " " standard diameter plus .005 inch standard diameter plus .006 inch standard diameter plus .006 inch standard diameter plus .006 inch 20943 D 9942 Swinging Head Rock Shaft Arm, right, for styles in Class 9900 (screw No. 22517) 26 Cam Gear Pinion (screw No. 95) 21 Cam Gear Housing, for Styles 9900 A, 9900 E, 9900 A, 9900 F, 9900 A, 9900	9940-531	" " " standard diameter	
9940-536 9940-539 " " " standard diameter plus .006 inch standard diameter plus .009 inch 200 inch 210 inch	9940-533	" " standard diameter	-
9940-539 " " " " " " Standard diameter plus .009 inch 26 9942 Swinging Head Rock Shaft Arm, right, for styles in Class 9900 (screw No. 22517) 26 9943 C Cam Gear Pinion (screw No. 95) 21 2944 Cam Gear Housing, for Styles 9900 A, 9900 E, 9900 Q, 9900 S, 9900 Y, 9900 AG, 9900 AJ, 9900 AG, 9900 AF, 9945 " " Fork, including shoes (clamp screw No. 85) 29 9945 " " Fork Shoe (screw No. 93 A) 29 9946 " " Fork Shoe (screw No. 94) 23 9947 " " Segment (attaching screw No. 22548, stop screw, upper, No. 150, stop screw, lower, No. 97) 26 9948 " " Segment Shaft, standard diameter .407 inch 20 9948 " " Segment Shaft, standard diameter plus .005 inch 20 9948 " " Segment Shaft, standard diameter plus .005 inch 26 9948 " " Segment Link (screw, front, No. 713, screw, rear, No. 97 A) 26 9948 " " Segment Link (screw No. 90) 12 19949 " " Segment Link (screw, front, No. 713, screw, rear, No. 97 A) 26 " " Segment Link (screw No. 90) 12 19950 " " Segment Link Stop (screw No. 90) 12 19951 AH Upper Knife, for Style 9900 AH (screw No. 75) 10 9952 AH " Knife Bar, for Style 9900 AH (screw No. 75) 10	9940-536	" " standard diameter	-
9942 Swinging Head Rock Shaft Arm, right, for styles in Class 9900 (screw No. 22517) 26 9943 C Cam Gear Pinion (screw No. 95) 21 2944 C Cam Gear Housing, for Styles 9900 A, 9900 E, 9900 Q, 9900 S, 9900 Y, 9900 AG, 9900 AJ, 9900 AK, 9900 AF (screw No. 93 A) 29 9944 AG Cam Gear Guard, front, for Style 9900 AH (screw No. 93 A) 29 9945 " Fork, including shoes (clamp screw No. 85) 26 9946 " Fork Shoe (screw No. 94) 27 9947 " Segment (attaching screw No. 22548, stop screw, upper, No. 150, stop screw, lower, No. 97) 26 9948 " Segment Shaft, standard diameter .407 inch 20 9948-408 " Segment Shaft, standard diameter plus .001 inch 20 9948-410 " Segment Shaft, standard diameter plus .003 inch 26 9948-410 " Segment Shaft, standard diameter plus .003 inch 26 9948-410 " Segment Shaft, standard diameter plus .003 inch 26 9948-410 " Segment Shaft, standard diameter plus .005 inch 26 9948-410 " Segment Shaft, standard diameter plus .005 inch 26 9948-410 " Segment Shaft, standard diameter plus .005 inch	9940-539	" " standard diameter	
9943 Swinging Head Rock Shaft Arm, right, for styles in Class 9900 (screw No. 22517) 26 (28 Gear Pinion (screw No. 95) 21 (28 Gear Pinion (screw No. 95) 22 (29 Gear Pinion (screw No. 95) 29 (29 Gear Pinion (screw No. 95) A) 29 (29 Gear Pinion (screw No. 93 A) 29 (29 Gear Guard, front, for Style 9900 AH (screw No. 93 A) 29 (29 Gear Pinion (screw No. 93 A) 29 (2	9941	" " " Arm, left (screw No.	_ 54
Cam Gear Pinion (screw No. 95) 21	9942	Swinging Head Rock Shaft Arm, right, for	
Cam Gear Housing, for Styles 9900 A, 9900 E, 9900 Q, 9900 S, 9900 Y, 9900 AG, 9900 AJ, 9900 AK, 9900 AF (screw No. 93 A) 29 9944 AG 9944 AH """ rear, for Style 9900 AH (screw No. 93 A) 29 9945 ""Fork, including shoes (clamp screw No. 85) 29 9946 ""Fork Shoe (screw No. 94) 26 9947 ""Segment (attaching screw No. 22548, stop screw, upper, No. 150, stop screw, lower, No. 97) 26 9948 ""Segment Shaft, standard diameter .407 inch 20 9948-408 "Segment Shaft, standard diameter plus .001 inch 20 9948-410 "Segment Shaft, standard diameter plus .003 inch 26 9948-413 "Segment Link (screw, front, No. 713, screw, rear, No. 97 A) 26 9950 ""Segment Link Stop (screw No. 90) 12 9951 AH 9952 AH "Knife Bar, for Style 9900 AH (screw No. 75) "Knife Bar, for Style 9900 AH (screw No. 93) 22		Cam Gear Pinion (screw No. 95) 2	21
9944 AG Cam Gear Guard, front, for Style 9900 AH (screw No. 93 A) 29 9944 AH " " rear, for Style 9900 AH (screw No. 93 A) 29 9945 " Fork, including shoes (clamp screw No. 85) 26 9946 " Fork Shoe (screw No. 94) 26 9947 " Segment (attaching screw No. 22548, stop screw, upper, No. 150, stop screw, lower, No. 97) 26 9948 " Segment Shaft, standard diameter .407 inch 20 9948 " Segment Shaft, standard diameter plus .001 inch 20 9948 " Segment Shaft, standard diameter plus .003 inch 26 9948 " Segment Link (screw, front, No. 713, screw, rear, No. 97 A) 26 9949 " Segment Link (screw front, No. 713, screw, rear, No. 97 A) 26 9950 " Segment Link Stop (screw No. 90) 12 9951 AH Upper Knife, for Style 9900 AH (screw No. 75) Whife Bar, for Style 9900 AH (screw No. 93)		Cam Gear Housing, for Styles 9900 A, 9900 E, 9900 Q, 9900 S, 9900 Y, 9900 AG, 9900 AJ,	
9944 AH " " rear, for Style 9900 AH	9944 AG	Cam Gear Guard, front, for Style 9900 AH	•
9945 9946 9947 "Fork Shoe (screw No. 94)	9944 AH	" " " rear, for Style 9900 AH	Ť
9946 9947 " "Segment (attaching screw No. 22548, stop screw, upper, No. 150, stop screw, lower, No. 97) 26 9948 " "Segment Shaft, standard diameter .407 inch 20 9948-410 " "Segment Shaft, standard diameter plus .001 inch	9945	" Fork, including shoes (clamp screw	
# Segment (attaching screw No. 22548, stop screw, upper, No. 150, stop screw, lower, No. 97) 26 9948	99116		
9948 " " Segment Shaft, standard diameter .407 inch 20 9948-408 " " Segment Shaft, standard diameter plus .001 inch		" " Segment (attaching screw No. 22548, stop screw, upper, No. 150, stop	-
9948-408 " " Segment Shaft, standard diameter plus OOl inch	9948	" Segment Shaft, standard diameter .407	
9948-410 " " Segment Shaft, standard diameter plus .003 inch	9948-408	" " Segment Shaft, standard diameter plus	20
9948-413 " " Segment Shaft, standard diameter plus .006 inch	9948-410	" Segment Shaft, standard diameter plus	
9949 " " Segment Link (screw, front, No. 713, screw, rear, No. 97 A)	9948-413	" " Segment Shaft, standard diameter plus	
9950 9951 AH Upper Knife, for Style 9900 AH (screw No. 75) " Knife Bar, for Style 9900 AH (screw No. 75) " Knife Bar, for Style 9900 AH (screw No. 93)	9949	" Segment Link (screw, front, No. 713,	→ 54
9951 AH Upper Knife, for Style 9900 AH (screw No. 75) 10 9952 AH Knife Bar, for Style 9900 AH (screw No. 93)	9950	" Segment Link Ston (screw No. 90) 1	
9952 AH		Unper Knife, for Style QOOO AH (screw No. 75)	
		" Knife Bar, for Style 9900 AH (screw	-
9900 E, 9900 Q, 9900 S, 9900 Y, 9900 AG, 9900 AH, 9900 AK, 9900 AP, 9900 AR, 14700 D, 14700 E (clamp screw No. 22518, set screw No. 88)	9953	Loop Retainer Rocker, for Styles 9900 A, 9900 E, 9900 Q, 9900 S, 9900 Y, 9900 AG, 9900 AH, 9900 AK, 9900 AP, 9900 AR, 14700 D, 14700 E (clamp screw No. 22518, set screw	

to	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
	op Retainer Holder, for Styles 9900 A, 9900 E, 9900 Q, 9900 S, 9900 Y, 9900 AG,	
9956 Loc 9957 A 9957 B 9958 Loc	9900 AH, 9900 AK, 9900 AP, 9900 AR, 14700 D, 14700 E (screw No. 22528)	12 20 18 19
((screw No. 22548)	26
((screw No. 22548)	22
9959 AH Upp	9900 AH (screw No. 820)	29
9960 B Loc	Style 9900 AH (screw No. 820)	22 26
9961 A 9961 B	" " Stud (nut No. 47) " Cone (screw No. 89)	19 18
9962 B 9963	Fork (clamp screw No. 303) Eccentric (spot screw No.	19
	81, set screw No. 95) op Retainer Lever Connecting Rod (screw,	18
9965 Log 9966	front, No. 75 A, screw, rear, No. 97 A) pp Retainer Lever Ball Stud (nut No. 258) " " Washer (screw No. 98 A)	26 8 9
	oper Rocker Frame (set screw, left, No. 88, set screw, right, No. 98, spot screw No. 96)	23
9968 Ne	edle Lever Link	18 16
9970 A Nee	edle Thread Take-up, for Styles 9900 A, 9900 E, 9900 Q, 9900 S, 9900 AJ, 9900 AK, 9900 AP, 9900 AQ, 9900 AR, 9900 AS (screw No.	
	63 A, washer No. 20)	17
((screw No. 93 A, washer No. 20) esser Bar, standard diameter .319 inch, for	17
	Styles 9900 A, 9900 E, 9900 Q, 9900 S, 9900 Y, 9900 AG, 9900 AH, 9900 AJ, 9900 AK, 9900 AP,	20
9971-322 Pre	9900 AR, 14700 D, 14700 E	20
9971 - 325 9971 - 328	standard diameter plus .006 inch standard diameter plus .009 inch	_
9971-320	standard diameter plus .009 inch-	_
9971-334	" standard diameter plus .015 inch	—
9971 AS	" standard diameter .319 inch, for Style 9900 AS	20
9972 Cas	st-off Wire Cuard (screw No. 90)	12

Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
9973	Looper Thread Take-up Eyelet Stand (screw	
9974 A	No. 22596)	26 4
9975 A	Stay Guide, lower section, for Style 9900 E (screw No. 25 C)	15
9975 B 9988 N 9993	Stay Guide, upper section (screw No. 25 C) Main Shaft Bushing, left, for Style 9900 AR Presser Foot Tongue, for Styles 9900 AG, 9900 AP (screw No. 91 A)	15 11 4
9994	Presser Foot Yielding Spring Guide, for Style 9900 AG (screw No. 91 A)	15
9994 A	Presser Foot Yielding Spring Guide Support, for Style 9900 AG (screw No. 91 A)	15
10314	Looper Avoid Eccentric, for Styles 9900 A, 9900 E, 9900 Q, 9900 S, 9900 Y, 9900 AG, 9900 AH, 9900 AJ, 9900 AK, 9900 AP, 9900 AQ, 9900 AR, 14700 D, 14700 E (spot screw No. 96 A)	11
10349	Cam Gear Segment Link Ball Stud (nut No. 12538)	8
11638 M	Needle Lever Cone Adjusting Nut, for styles in Class 9900	9
‡ 11654	Tension Release Connecting Rod Ball Joint, upper, for Styles 14700 D, 14700 E (screw No. 97 A, nut No. 18, washer No. 36 G)	18
12350 12538	Cam Gear Stud Washer (screw No. 25 S) * * Segment Link Ball Stud Nut	9
12835	Feed Bar Shoe, for Styles 9900 A, 9900 E, 9900 Q, 9900 S, 9900 Y, 9900 AG, 9900 AH, 9900 AJ, 9900 AK, 9900 AP, 9900 AQ, 9900 AR (screw No. 94)	12
12934 A	Clutch Operating Link Front Stud Nut, for Style 9900 AS	9
12957 E	Swinging Head Control Lever Lock Pivot Stud Spring Washer, for Styles 14700 D, 14700 E; also for No. 15403 R	9
12964. C	Needle Lever Link Pin Ball	9
12986 B	Stop Screw, for rock shaft plunger guide bar on Styles 14700 D, 14700 E	6
12987 A	Looper Rocker Cone Adjusting Nut	9
12997 A	Screw Stud, for front and rear end of clutch operating link on Style 9900 AS (nut No. 12934 A)	7
14024	Throat Plate, for Styles 9900 AG, 14700 D (screw No. 87, tongue No. 14030, tongue	_
14030	screw No. 187 A)	2
14076	Screw, for feed driving arm supporting shaft link on Style 9900 AS	7
ISee Page	9 -63-	

Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
14544	Feed Bar Shaft, for Styles 9900 AJ, 9900 AQ	13
14675	Knife Bar Carrier Shoe, for Style 9900 AR (screw No. 22570)	12
14701 F	Cloth Plate, for Style 14700 D (screw No. 80) Edge Guide, for Styles 9900 Q, 9900 AJ, 9900 AK,	33
14703	14700 D, 14700 E (screw No. 25 S)	16
14704	Cast-off Wire, for Styles 14700 D, 14700 E (screw No. 22524)	5
14705 B	Upper Feed Dog, for Style 14700 D (screw No.	
14720 B	93 A)	3
14725	91)	4
	Styles 14700 D, 14700 E (screw No. 87)	5
14731	Feed Rocker, for Styles 9900 AK, 14700 D, 14700 E (screw No. 88)	29
14732	Feed Bar, for lower feed on Styles 9900 AK, 14700 D (screw No. 88)	29
14733	Upper Feed Bar, for Styles 9900 AK, 14700 D,	
14734	14700 E	29
14735	14700 E (screw No. 22528)	29
	14700 D, 14700 E (screw No. 93)	12
14736	Upper Feed Bar Shoe, for Styles 9900 AK, 14700 D, 14700 E (screw No. 94)	12
14737	Upper Feed Lift Lever, for Styles 9900 AK,	29
14738	14700 D, 14700 E Upper Feed Lift Lever Roller, for Styles	
14739	9900 AK, 14700 D, 14700 E	9
	9900 AK, 14700 D, 14700 E (screw No. 1059)	13
14740	Upper Feed Lift Lever Spring Holder, for Styles 9900 AK, 14700 D, 14700 E (spring No. 110-3,	
14741	screw No. 93, dowel pin No. 1361 A)	22
	9900 AK, 14700 D, 14700 E (screw No. 90)	12
14742	Presser Bar Connection, for Styles 9900 AK, 14700 D, 14700 E (set screw No. 89, clamp	
14744 А	screw No. 97)	12
	(screw No. 93 A)	29
14760 B	Swinging Head Control Lever, for Styles 14700 D. 14700 E (screw No. 74)	31
14760 C	Swinging Head Control Lever Bushing, for Styles	
14760 D	14700 D, 14700 E Swinging Head Control Lever Lock, for Styles	9
14775	14700 D, 14700 E	31 21
14775 A	" Plunger Spring, for Styles 14700 D.	
	14700 E (washer No. 28577)	14

-64-

Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
14777	Straightaway Stitch Locking Plunger, for Styles 14700 D, 14700 E (screw No. 141)	21
14777 A	Straightaway Stitch Locking Plunger Coiled Spring, for Styles 14700 D, 14700 E	14
14778 A	Straightaway Stitch Locking Plunger Sleeve,	·
14778 B	for Styles 14700 D, 14700 E	13
14778 C	Straightaway Stitch Locking Plunger Stand	29
14786	Rock Shaft Plunger, for Styles 14700 D,	13
14787	Rock Shaft Plunger Roller, for Styles 14700 D,	21
14787 A	14700 E (screw No. 86 X) Rock Shaft Plunger Guide Bar, for Styles 14700 D, 14700 E (set screw No. 96, stop	9
14788	screw No. 12986 B)	13
	Rock Shaft Plunger Spring, for Styles 14700 D, 14700 E (washer No. 454 A)	14
14789	Rock Shaft Plunger Arm, for Styles 14700 D, 14700 E (clamp screw No. 22517)	21
14790 A	14700 D, 14700 E (clamp screw No. 75,	21
14792	collar No. 9660 B) Needle Thread Tension Release, for Styles 14700 D, 14700 E (screw No. 187 A)	12
14792 D	Needle Thread Tension Release Lever, for Styles 14700 D, 14700 E (pivot stud No. 22557)	29
14793	Tension Thread Eyelet, for Styles 14700 D, 14700 E (screw No. 98)	17
15403 R	Retractable Gauge, complete, for Style 9900 AH (stud No. 9846 A, spring washer No. 12957 E,	
15430 C	Needle Lever Connecting Rod Tube Nut, left	16
15430 D	Needle Lever Connecting Rod Tube Nut, right thread	9
15430 L	Needle Lever Connecting Rod Tube Felt; also for Nos. 1275 A, 1275 E, 1275 F, 1275 H,	19
‡ 15430 m	Needle Lever Connecting Rod Lower Bearing (screw No. 22587)	18
15446 с	Differential Feed Adjusting Stud, for Styles	
15446 р	9900 AJ, 9900 AQ (nut No. 5144)	12
15447 G	22743) Feed Bar Prong and Sponge, for Styles 9900 AJ,	12
->++1	9900 AQ (screw No. 94)	23
tone Dage	-65-	

Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
15465 F	Looper Rocker Cone (screw No. 88, adjust-	
15480 C	ing nut No. 12987 A)	11 4
15745 B 15832	Looper Rocker Cone Stud (nut No. 1280) Upper Knife Bar Rock Shaft, for Style	13
15847 A	9900 AH	20 12
15872 A	Upper Knife Bar Carrier for Style 9900 AH (clamp screw No. 97)	22
15872 В	Upper Knife Bar Carrier Link (clamp screw No. 97)	22
15872 C	" " " " Ferrule	9
15872 D	" " " " " Stud	Ź
15872 E	" " Lifting Lever (screw No.	
15872 G	22743)	22 22
15872 H	" " Locking Lever Plunger (nut	22
15872 J	No. 21185)	8
17012 0	Spring	14
15872 K	" " Carrier Shaft, round	19
15872 L	" " Carrier Shaft, slabbed	1 77
15873 A	(screw No. 97) " " Shaft Bearing, left (screw	13
15878 D	No. 136)	22
17070, 0	(spot screw No. 81, set screw	10
\$15879 A	No. 95)	18
	(screw No. 75 A) " " Eccentric Connecting Rod Ball	18
15879 E	Stud (nut No. 258)	8
15880 A	Bar Rock Shaft Arm, right(clamp screw No.93, set screw No.96)	22
15936 B	Cloth Plate Swinging Extension, for Style 9900 AQ (stud No. 30036)	35
16192 A	Cloth Plate Slide Stop Plate, for Style	
16195 B	9900 Y (screw No. 88 A) Main Shaft Bushing, right	15 20
21102 D	Base, for tape reel assemblies Nos.21171 K,	
CTIVE D	21175 A (screw No. 22632 F-24)	35
21104 B-11	Thread Stand Rod, 11 inches long (set screw No. 22591)	32
21104 B-14	Tape Reel Support Rod, 14 inches long, for	
21104 B - 20	assembly No. 21171 K (screw No. 22509) Tape Reel Support Rod, 20 inches long, for assemblies Nos. 21171 K, 21175 A (screw No. 22632 F-24)	32 32
		<u> </u>

0-1-1	The distance in the last column water and to the	
Symbol .	The figures in the last column refer only to the	Plate
to	plates illustrating the parts and are not to be	No.
Order By	used in ordering. Refer to pink insert for prices.	ļ
03.3.01. C	Mana Paol Current Red Connection for aggregation	
21104 C	Tape Reel Support Rod Connection, for assembly No. 21171 K (screw No. 22509)	25
01117 4	Thread Stand Wire Extension, 6 inches long	رعا
21113 A		20
01117 5	(set screw No. 22632 F-24)	20
21113 B	Thread Stand Wire Coupling (set screw No. 88)	13
21114 A	" Base (screw No. 22591)	35
21130 A-2	" Seat, two spools (set screw No.	77
01115	69 FD)	33 25
21145	Cone, wood, for thread stand	25
21169 D	Binding Holder Assembly, for Styles 9900 S,	
	9900 Y; one each Nos. 88, 161, 21169 E,	
	21169 F. Specify component parts in order-	-1
011/0 8	ing	34
21169 E	Binding Holder Disc, 8 inches diameter, in-	-1
011/0 5	cluding pin, for assembly No. 21169 D	34
21169 F	Binding Holder Base, for assembly No. 21169 D	34
21171 K	Tape Reel Assembly, upper, for Style 9900 AS;	
	one each Nos. 753, 21102 D, 21104 B-14,	1
•	21104 B-20, 21104 C, 21177 A, 21220 C,	ľ
	21385 D; two each Nos. 21178 A, 21217 A,	•
	22728; three No. 93 A. Specify component	z I.
01105 4	parts in ordering	34
21175 A	Tape Reel Assembly, lower, for Style 9900 AS; one each Nos. 753, 21102 D, 21104 B-20,	
	21177 A, 21217 A, 21218, 22728; two each	[
	Nos. 93 A, 21178 A. Specify component	
	parts in ordering	34
21177 A	Spring Collar, including wing screw No.	/ +
-++11 4	22647 K-16, for tape reel assemblies Nos.	
	21171 K, 21175 A	25
21178 A	Disc, 11 inches diameter, for tape reel	_
	assemblies Nos. 21171 K, 21175 A; also strip	
	holder supplementary disc for strip holder	
	assembly No. 21192 P	33
21182 J	Strip Tension Assembly, for Styles 9900 S.	1
	9900 Y; one each Nos. 21182 K, 21182 L,	
	21182 M, 21217, 22620 H-20; two each Nos.	
	107, 108, 110-3, 1346, 1347	28
21182 K	Strip Tension Plate, outer	-
21182 L	" " inner	-
21182 M	" " Support (set screw No.	Ì
	22620 H-20)	{
21185	Upper Knife Bar Locking Lever Plunger Nut, for	
	Style 9900 AR	9
21192 A	Strip Holder Disc, 8 inches diameter, includ-	
	ing pin, for assembly No. 21192 P	34
21192 F	Strip Holder Base, for assembly No. 21192 P	35
		l
	·	
	· · · · · · · · · · · · · · · · · · ·	

Symbol to Order By The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices. 21192 P Strip Holder and Pin Tension Assembly, ball bearing, height adjustable for guiding a vertical strip from 1/2 to 5 inches wide on Style 9900 AQ; one each Nos. 21192 A, 21192 F, 21192 Q, 21192 R, 22728. Specify component parts in ordering, and also an assembly drawing No. PL 52. When installing, bore a 5/8 inch diameter hole and fasten the base to either the upper or under surface of the table, depending on the maximum width of strip that will be used————————————————————————————————————
plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices. 21192 P Strip Holder and Pin Tension Assembly, ball bearing, height adjustable for guiding a vertical strip from 1/2 to 5 inches wide on Style 9900 AQ; one each Nos. 21192 A, 21192 F, 21192 Q, 21192 R, 22728. Specify component parts in ordering, and also an assembly drawing No. PL 52. When installing, bore a 5/8 inch diameter hole and fasten the base to either the upper or under surface of the table, depending on the maximum width of strip that will be used————————————————————————————————————
21192 P Strip Holder and Pin Tension Assembly, ball bearing, height adjustable for guiding a vertical strip from 1/2 to 5 inches wide on Style 9900 AQ; one each Nos. 21192 A, 21192 F, 21192 Q, 21192 R, 22728. Specify component parts in ordering, and also an assembly drawing No. PL 52. When installing, bore a 5/8 inch diameter hole and fasten the base to either the upper or under surface of the table, depending on the maximum width of strip that will be used
21192 P Strip Holder and Pin Tension Assembly, ball bearing, height adjustable for guiding a vertical strip from 1/2 to 5 inches wide on Style 9900 AQ; one each Nos. 21192 A, 21192 F, 21192 Q, 21192 R, 22728. Specify component parts in ordering, and also an assembly drawing No. PL 52. When installing, bore a 5/8 inch diameter hole and fasten the base to either the upper or under surface of the table, depending on the maximum width of strip that will be used————————————————————————————————————
bearing, height adjustable for guiding a vertical strip from 1/2 to 5 inches wide on Style 9900 AQ; one each Nos. 21192 A, 21192 F, 21192 Q, 21192 R, 22728. Specify component parts in ordering, and also an assembly drawing No. PL 52. When installing, bore a 5/8 inch diameter hole and fasten the base to either the upper or under surface of the table, depending on the maximum width of strip that will be used————————————————————————————————————
bearing, height adjustable for guiding a vertical strip from 1/2 to 5 inches wide on Style 9900 AQ; one each Nos. 21192 A, 21192 F, 21192 Q, 21192 R, 22728. Specify component parts in ordering, and also an assembly drawing No. PL 52. When installing, bore a 5/8 inch diameter hole and fasten the base to either the upper or under surface of the table, depending on the maximum width of strip that will be used————————————————————————————————————
vertical strip from 1/2 to 5 inches wide on Style 9900 AQ; one each Nos. 21192 A, 21192 F, 21192 Q, 21192 R, 22728. Specify component parts in ordering, and also an assembly drawing No. PL 52. When install- ing, bore a 5/8 inch diameter hole and fasten the base to either the upper or under surface of the table, depending on the maximum width of strip that will be used
on Style 9900 AQ; one each Nos. 21192 A, 21192 F, 21192 Q, 21192 R, 22728. Specify component parts in ordering, and also an assembly drawing No. PL 52. When install- ing, bore a 5/8 inch diameter hole and fasten the base to either the upper or under surface of the table, depending on the maximum width of strip that will be used
21192 F, 21192 Q, 21192 R, 22728. Specify component parts in ordering, and also an assembly drawing No. PL 52. When installing, bore a 5/8 inch diameter hole and fasten the base to either the upper or under surface of the table, depending on the maximum width of strip that will be used————————————————————————————————————
component parts in ordering, and also an assembly drawing No. PL 52. When installing, bore a 5/8 inch diameter hole and fasten the base to either the upper or under surface of the table, depending on the maximum width of strip that will be used
assembly drawing No. PL 52. When installing, bore a 5/8 inch diameter hole and fasten the base to either the upper or under surface of the table, depending on the maximum width of strip that will be used
ing, bore a 5/8 inch diameter hole and fasten the base to either the upper or under surface of the table, depending on the maximum width of strip that will be used
fasten the base to either the upper or under surface of the table, depending on the maximum width of strip that will be used
under surface of the table, depending on the maximum width of strip that will be used
the maximum width of strip that will be used
21192 Q Strip Holder Pin Tension, eight pins 5 inches long, for assembly No. 21192 P (set screw No. 22728)
21192 Q Strip Holder Pin Tension, eight pins 5 inches long, for assembly No. 21192 P (set screw No. 22728)
long, for assembly No. 21192 P (set screw No. 22728)
No. 22728)
21192 R Strip Holder Ball Bearing, 7/32 inch diameter, for assembly No. 21192 P 9 21201 Screw Driver, 9/64 inch round blade, length overall 7 5/8 inches
ter, for assembly No. 21192 P 9 21201 Screw Driver, 9/64 inch round blade, length
21201 Screw Driver, 9/64 inch round blade, length overall 7 5/8 inches
overall 7 5/8 inches
overall 11 1/4 inches 32 Screw Driver, 13/64 inch round blade, length overall 15 1/2 inches 32 21204 Screw Driver, 9/32 inch round blade, length
Screw Driver, 13/64 inch round blade, length overall 15 1/2 inches 32 Screw Driver, 9/32 inch round blade, length
overall 15 1/2 inches 32 Screw Driver, 9/32 inch round blade, length
21204 Screw Driver, 9/32 inch round blade, length
21204 Screw Driver, 9/32 Inch round brade, rength
overall 15 inches 32
21205 A Screw Driver, 3/8 inch round blade, length
overall 14 inches 32
overall 14 inches 32 21206 Screw Driver Wrench 32
21207 Screw Driver, 7/64 inch round blade, length
overall 2 1/2 inches 24
21208 Screw Driver Set. three detachable blades 32
21217 Strip Tension Base, for assembly No. 21182 J
(screw No. 22620 H-20) 31
21217 A Tape Reel Axle Support, for tape reel assem-
blies Nos. 21171 K, 21175 A (fillister head
screw No. 93 A, thumbscrew No. 22728) 15
Tape Reel Axle, length overall 10 inches, for assembly No. 21175 A (thumbscrew No. 22728)
21220 C Tape Reel Axle, length overall 13 1/16 inches, for assembly No. 21171 K (thumb-
screw No. 22728)
screw No. 22728)
21231 Thread Meter, for recording the consumption
of thread in 1/10 yards as it passes into
the sewing machine31
21233 N Connector, with "BX" cable, for D.C.
"Electro Drives"
21233 P Connector, with "BX" cable, for single and
three phase A.C. "Electro Drives"
/0

Symbol	The figures in the last column refer only to the	Plate
to	plates illustrating the parts and are not to be	No.
Order By	used in ordering. Refer to pink insert for prices.	1.00
	sense as as as as as as as as a princ 103010 101 011008"	!
21233 R	Light Fixture Assembly, including bulb and	
	blue lens, machine mounting, for machines	
	driven by "Electro Drive"	l
01077 0	Tich Made a to a black to the book to the	_
21233 S	Light Fixture Assembly, including bulb and	
	clear lens	
21233 T	Light Fixture Assembly, including bulb, but	
	without lens	_
21236	Belt Plier, for 3/8 inch and smaller round	
	belt	32
21252		
21252	Lifter Lever Casting (stud No. 420)	28
21260	Emery Cord, 3/64 inch diameter, grade No.	
	120, fifty yard spool	
21260 A	" " 3/64 inch diameter, grade No.	
	150, fifty yard spool	L
21260 B	" " 1/32 inch diameter grade No	
21200 0	1/)2 Inch diameter, grade No.	
010/0 0	180, fifty yard spool	_
21260 C	" ".025 inch diameter, grade No.	
	200, fifty yard spool	_
21260 D	" Tape, 3/32 inch wide, grade No. 180.	
	fifty yard spool	
21260 E	" Cord, .018 inch diameter, grade No.	
	200, fifty yard spool	
22262		
21261	Leather Belt, flat, 1 inch wide, 63 inches	
	long, includes belt fastener No. 21350	
21262	Leather Belt, round, 9/32 inch diameter, 44	
	inches long, includes wire belt hook	
	No. 21351	
21350	Belt Fastener, malleable iron, for 1 inch	
	flat belt	a 1.
21751		14
21351	Belt Hook, wire, for 9/32 inch round belt	14
21355	Chair Leg Extension, 4 inches long	24
21355 A	" " 6 inches long	24
21362	Drive Bushing, 25/32 inch long, external	•
•	diameter .407 inch, for upper presser bar	
	bearing	17
217/7		13
21363	Drive Bushing, 1 3/16 inches long, external	
	diameter .407 inch, for lower presser bar	
	bearing	13
21369 - 3	Clamping Bolt, includes wing nut No.	
	21369 A and washer No. 28577, for trays	
	Nos. A3991, 21377 AG	24
21369 A		
	Wing Nut, for clamping bolt No. 21369-3	
21369 B	Clamp Bolt Plate	_
21371 Q	Table Drawer	
21371 BT-42	Blank Table Top, 48" x 16" x 1 3/4"	_
21371 BT-48		-
21371 BT-54	1 • • • • • • • • • • • • • • • • • •	l <u></u>
	(
21371 BT-60	, —	
21375 A	Pulley Guard	33
21377 AG	Tray, for Style 9900 AS	35

2.0

Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
21379 A	Tray, for Styles 9900 A, 9900 E, 9900 Q, 9900 S, 9900 Y, 9900 AG, 9900 AH, 9900 AJ, 9900 AK, 9900 AP, 9900 AQ, 14700 D, 14700 E	35
21384 A 21385 D	Leather Plug, for cloth plate screw holes Lead-in Axle, for tape reel assembly No. 21171 K (screw No. 93 A)	34
21388 21388 N	Wrench, for 3/8 inch hexagon nuts double end, 3/16 and 5/16 inch openings	24 24
21388 R 21390	" double end, 3/8 and 1/2 inch openings Needle Thread Intermittent Nipper Assembly, for Styles 14700 D, 14700 E; one each Nos. 87, 90, 97, 21390 A, 21390 B, 21390 D, 21390 E,	24
21390 A	21390 F, 22564 and two No. 21390 AT Needle Thread Intermittent Nipper Spring, front	22
21390 В	(screw No. 22564) Needle Thread Intermittent Nipper Spring, rear	22
21390 D	(screw No. 22564) Needle Thread Intermittent Nipper Spring Support, for Styles 14700 D, 14700 E (screw	22
21390 E	No. 87) Needle Thread Intermittent Nipper Spring	22
21390 F	Operating Block (screw No. 90) Needle Thread Intermittent Nipper Spring	12
•	Operating Block Support (screw No. 97 on Styles 14700 D, 14700 E, screw No. 22585 on Styles 9900 A, 9900 E, 9900 AK)	22
21390 AS	Needle Thread Intermittent Nipper Spring Support, for Styles 9900 A, 9900 E, 9900 AK	22
21390 AT	(screw No. 87)	13
21390 AU	Needle Thread Intermittent Nipper Assembly, for Styles 9900 A, 9900 E, 9900 AK; one each Nos. 90, 21390 A, 21390 B, 21390 E, 21390 F, 21390 AS, 21390 AT, 22564, 22585; two No. 87	-
21394	Utility Grinder, including emery wheel, 5 inches diameter, 1/4 inch face, round belt	22
2139 4 G	drive, recommended speed 3000 R.P.M Emery Wheel, 5 inches diameter, 1/4 inch face, 3/8 inch hole, grade "M" emery 60	
21394 н	Emery Wheel, 5 inches diameter 1/2 inch face, 3/8 inch hole, grade "M" emery 60	_
21394 К	Utility Grinder, including emery wheel, 5 inches diameter, 1/2 inch face, round belt drive, recommended speed 3000 R.P.M	
21396 AG 21396 AT	Needle Thread Lubricator Felt Needle Thread Lubricator, attaches to lower presser bar lug in place of hand lifter,	_
	thread lubricated after entering tension (screw No.93)	16

Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
21610 A	Needle Bar Rolling Thread Guide, for Styles 9900 E, 9900 AK, 14700 D, 14700 E (screw No. 22768)	10
21624	Thread Controller Rolling Thread Guide, for Styles 9900 E, 9900 AK, 14700 D, 14700 E	10
21628 21629	(screw No. 138)	10 10 6
21632	Needle Lever Rolling Thread Guide, for Styles 9900 E, 9900 AK (screw No. 98 A)	10
21632 В	Needle Lever Rolling Thread Guide, for Styles 14700 D, 14700 E (screw No. 98 A)	10
21640 AC 21680 V	Pivot Screw, for tape reel on Style 9900 AP Base Plate	8 33
21681 21696	"T" Screw, for fastening machine to base plate Oil Drain Reservoir	25 31
21696 A 21698-2	" " Nipple Vibration Insulator, two inches long, for	32
21698-4	tables	25 25
21698-5	five inches long	25
21698-6	six inches long	25
22509	Note: Special lengths will be furnished on request. Part of the table leg is shown in the illustration for clarity. Set Screw, square head, cup point, 5/16 inch diameter, 1/2 inch long, 18 threads per inch, for tape reel assembly rods; also for No. 21104 C	8
22514	Screw, 7/16 inch long, for cloth plate attachments	7
22517	for swinging head rock shaft arm; also for Nos. A4043, 14789, 23450, 23450 A-	
22518	Clamp Screw, for loop retainer rocker	7
22519	Screw, for thread controller rack	777776
22519 A	for adjusting knife bar on Style 9900 AF	1 4
22521	" plus size, for cloth plate; tap No. V118	'l <i>[</i>
22524	101 CGSC-011 WILE	
22525	" .010 inch plus size, length overall 5/16 inch; otherwise same as No. 87	6
22528	for loop retainer holder; also for Nos. 1859, 14734	. 7
22539	Plug Screw, for main shaft oiling system	. 7
22548	Screw, for cam gear segment; also for Nos. 5157 A, 9939 T, 9958, 9958 A	. 7
22557	Pivot Stud, for needle thread tension release lever on Styles 14700 D, 14700 E	. 7
22560	Screw, for needle bar link pin spring; also for Nos. 57 WA, 9939 V	
22560 в	Set Screw, 15/64 inch long, for presser guide	- 6
	bar	

		
Symbol	The figures in the last column refer only to the	Plate
to	plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	No.
Order By	deed in oldering. weter to bing insert for 1.2538;	
22561	Screw, for cloth plate slide extension	
	guide on Style 9900 S	6
22564	" for needle thread intermittent	,
225/5 2	nipper spring; also for No. 380	6
22565 C	Adjusting Screw, for feed dog shank support	6
22567	Stop Screw, for swinging head control lever on Styles 14700 D, 14700 E (lock nut	
	No. 9937)	7
22569	Screw, for feed crank link	7 7
22570	for knife bar carrier shoe on Style	•
	9900 AR	6
22585	for differential feed dog on Styles	_
•	9900 AJ, 9900 AQ; also for Nos. 6948 A, 21390 F, K38614	
	6948 A, 21390 F, K38614	6
22586 A	for needle lever connecting rod upper	
0050(D	bearing valve	6
22586 В	Plug Screw, for needle lever stud on Styles 14700 D, 14700 E	6
22587	Screw, for needle lever connecting rod	0
22,01	bearing	7
22591	Set Screw, for thread stand rod	6
22594	Attaching Screw, for binder on Style 9900 S	7
22595	<pre>" for binder on Style 9900 Y</pre>	7
22596	Screw, for looper thread take-up eyelet	
	stand; also for No. 7 H	7
22597	Spot Screw, for eccentric pulley	7
22597 A	Set Screw, for eccentric pulley Set Screw, headless, cup point, 1/4 inch	6
22620 H-20	diameter, 5/16 inch long, 20 threads per	
	inch, for strip tension plate support on	
	assembly No. 21182 J	7
22632 F-24	Screw, square head, cup point, 3/16 inch	•
	diameter, 3/8 inch long, 24 threads per	
	inch, for thread stand wire; also for No.	
	21102 D	6
22647 K-16	Wing Screw, 1/4 inch long, for spring collar	
	on tape reel assemblies Nos. 21171 K,	8
22704	Screw, for feed clutch roller spring on	U
CE 1 04	Style 9900 AS	6
22716	" for throat plate cloth guide on Style	
•	9900 AR	6
22728	Thumbscrew, for assemblies Nos. 21171 K,	
	21175 A, 21192 P	8
22734	Screw, for knife bar carrier on Style 9900 AH	6
22743	Set Screw, for upper knife bar lifting lever	
2221.2	on Style 9900 AH; also for No. 15446 D	6
22747	Screw, for feed clutch triangular block on Style 9900 AS; also for No. K40415	4
22758 A		6
	Stud, for upper roller feed on Style 9900 AS -	7

-72-

		,
Symbol	The figures in the last column refer only to the	Plate
to	plates illustaring the parts and are not to be	No.
Order By	used in ordering. Refer to pink insert for prices.	
22768	Screw, for needle bar thread eyelet; also	
	for No. 21610 A	6
22794	Hinge Screw, for presser foot on Style	Ŭ
	9900 AS	7
22813	Set Screw, headless, for lifter treadle pin-	6
22826	Clamp Screw, for needle lever link pin on	-
	Styles in Class 9900	7
23215 AE	English Binder, adjustable, for use with 3/8	
	to 5/8 inch binding strip on Style 9900 Y	
	(attaching screw No. 22595, adjusting	- 4
07015 47	plate screw No. 187 A)	16
23215 AF	English Binder, adjustable, for use with 3/4	·
	to 15/16 inch binding strip on Style	
	9900 Y (attaching screw No. 22595, adjust- ing plate screw No. 187 A)	1.0
23215 AY	English Binder, non-adjustable, for use with	16
Eyery Ar	9/16 inch binding strip on Style 9900 S	
:	(attaching screw No. 22594)	16
23223 - 37/64	Binding Guide, non-adjustable, for use with	10
	37/64 inch binding strip on Style 9900 S	
	(attaching screw No. 25 C)	16
23223 B	Binding Guide Assembly, adjustable, for use	-
	with 3/8 to 5/8 inch binding strip on	
	Style 9900 Y (attaching screw No. 25 C)	16
23 22 3 C	Binding Guide Assembly, adjustable, for use	
•	with 3/4 to 15/16 inch binding strip on	
2 322 3 к	Style 9900 Y (attaching screw No. 25 C)	10
ZJZZJ K	Lead-in Guide, lower, for binding guide assembly No. 23223 C (screw No. 187 A)	15
23223 L	Lead-in Guide, upper, for binding guide	177
ב לבבר	assembly No. 23223 C (screw No. 187 A)	15
232 23 R	Lead-in Guide, lower, for binding guide	- 7
	assembly No. 23223 B (screw No. 187 A)	15
23223 S	Lead-in Guide, upper, for binding guide	[]
	assembly No. 23223 B (screw No. 187 A)	15
23279 D	Folder Threader	16
23408-1 \1/2	Folder, for making a 1 1/2 inch finished	
	width, using strip cut 3 1/2 inches wide	
071.00.0	on Style 9900 AQ (screw No. 25 C)	27
23408-2	Folder, for making a 2 inch finished width,	Ì
:	using strip cut 4 1/2 inches wide, on	22
23450	Style 9900 AQ (screw No. 25 C) Attachment Assembly, for guiding waist band	27
<i>- J</i> 4J∪	on Style 9900 AS; one each Nos. 23450 A,	
	23450 B, 23450 C, 23450 D, 23450 E; two	
	No. 187 A; five No. 25 S (screw No. 22517)	27
23450 A	Base, including cloth shelf and left curtain	-'
-2-2-	edge guide, for assembly No. 23450	<u> </u>
	(screw No. 22517)	27
		 - •
	<u> </u>	<u> </u>


Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
23450 B	Curtain Lining Guide, front, for assembly No. 23450 (screw No. 25 S)	27
23450 C	Garment Edge Guide, for assembly No. 23450 (screw No. 187 A)	27
23450 D	Curtain Edge Guide, right, for assembly No. 23450 (screw No. 25 S)	27
23450 E	Curtain Edge Folder, for assembly No. 23450	
28577	(screw No. 25 S) Washer, for lifting plunger spring on Style	27
28705	"Electro Drive", 1/2 H.P., A.C., 1 phase, 60 cycles, 105-115 volts, 3400 R.P.M	9
28705 D	"Electro Drive", 1/2 H.P., A.C., 1 phase, 60	
28707 В	cycles, 220 volts, 3450 R.P.M "Electro Drive", 1/2 H.P., A.C., 3 phase, 60 cycles, 210-230 volts, 3500 R.P.M	
28707 D	"Electro Drive", 1/2 H.P., A.C., 3 phase, 60	
28707 E	cycles, 440 volts, 3500 R.P.M "Electro Drive", 1/2 H.P., A.C., 3 phase, 60	_
28707 F	cycles, 440 volts, 1725 R.P.M "Electro Drive", 1/2 H.P., A.C., 3 phase, 60	
28708	cycles, 210-230 volts, 1725 R.P.M "Electro Drive", 1/2 H.P., D.C., 105-115 volts,	_
28708 A	3000 R.P.M	
29066 В	Needle Lever Connecting Rod Upper Bearing Assembly; one each Nos. 1230 A, 156 lapped	
00001. 7	together, 1230 B, 1230 D, 22586 A	11
29084 B	Eccentric Pulley Assembly; one each Nos. 9921, 15430 M lapped together	18
29115	Loop Retainer Lever Eccentric Assembly; one each Nos. 9963, 9964, 9965 lapped together	18
29122	Cam Gear Link Assembly; one each Nos. 9949, 10349 lapped together	18
29132 C	Upper Knife Eccentric Assembly, for Style 9900 AH; one each Nos. 15878 D, 15879 A,	
29158 J	15879 E lapped together Looper Rocker Assembly, for Styles 9900 A,	18
2,1,00	9900 E, 9900 Q, 9900 S, 9900 Y, 9900 AG, 9900 AH, 9900 AJ, 9900 AK, 9900 AP, 9900 AQ,	
	9900 AR, 14700 D, 14700 E; one each Nos. 213,	
	15465 F, 15745 B lapped together, 6038, 12987 A and two No. 88	18
29169 K	Looper Rocker Assembly, for Style 990C AS; one each Nos. 6013, 15465 F, 15745 B lapped to-	
oozol n	gether, 6038 B, 12987 A and two No. 88	18
29304 E	Needle Lever Cone Bearing Stud Assembly, for styles in Class 9900; one each Nos. 1276,	
	6090 A, 6093 lapped together and two each Nos. 88, 11638 M	19
	71.	1 - 7

-74-

Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate
29310 B	Loop Retainer Lever Assembly; one each Nos.	
29324	9960 B, 9961 A, 9961 B lapped together and two No. 89	18
29328	one each Nos. 9957 A, 9957 B	18
29402	each Nos. 6215, 1275 A lapped together Lifter Treadle Assembly; one each Nos. 422,	3 5
29728	423, 424, 22813	28
30036	9939 R, 22565 C	16 8
к38614	Main Feed Dog, for Style 9900 AJ (screw No. 22585)	
к38615	Differential Feed Dog, for Style 9900 AJ	3
к38616	(screw No. 22585)	3
к38927	(screw No. 87)	5
кџ0066	tongue No. 9930 A, tongue screw No. 187 A) Throat Plate, for Style 9900 AP (screw No. 87.	2
к40067	tongue No. K41276, tongue screw No. 187 A) Presser Foot, for Style 9900 AP (clamp screw No. 91, tongue No. 9993, folder No. K47278,	2
к40415	folder screw No. 73 A) Tape Reel, for Style 9900 AP (pivot stud No.	4
к40416	21640 AC, spring screw No. 22747)	33 33
41258	Cloth Plate, for Style 9900 AP (screw No. 80) Feed Clutch Roller, for Style 9900 AS	12
41258 A		14
41258 B		12
41258 D		21
41258 E		12
к41276	Throat Plate Tongue, for Style 9900 AP (screw No. 187 A)	2
к43933	Main Feed Dog, for Style 9900 AQ (screw No.	3
к43934	79048)	
к43935	9900 AQ (screw No. 25 C)	27
к43936	latch screw No. 134)	17
к47970 К44560	Cloth Plate, for Style 9900 AQ (screw No. 80) Cam Gear Cover, for Style 9900 AQ (screw No.	33
	93 A)	29

-75-

Symbol to Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
к44621	Feed Bar, for main feed on Styles 9900 AJ,	
кі4622	9900 AQ (screw No. 88)	23 12
КІ44626	Differential Feed Dog. for Style 9900 AQ (screw No. 22585)	3
к44953	Folder, for making a 1 inch finished width, using strip cut 2 1/2 inches wide, on Style 9900 AQ (screw No. 25 C)	
к45258	Presser Foot, for Style 9900 AQ (clamp screw No. 91, stripper blade No. K45929, stripper blade screw No. 223 C, yielding section stud No. 57 WD)	4
K45259	Throat Plate, for Style 9900 AQ (screw No.87)	2
K45266	Loop Retainer Holder, for Style 9900 AQ (screw No. 22528)	15
к45356	Folder, for making a 1/4 inch finished width, on Style 9900 AQ (screw No. 25 C)	27
K45929	Presser Foot Stripper Blade, for Style 9900 AQ (screw No. 223 C)	
к47278	Presser Foot Folder, for Style 9900 AP (screw No. 73 A)	
к47790	Loop Retainer Rocker, for Styles 9900 AJ, 9900 AQ (clamp screw No. 22518, set screw No. 88)	21
к47850	Looper Rocker Frame, for Style 9900 AR (set screw, left, No. 88, set screw, right, No.	
#J. 9090	98, spot screw No. 96)	23
кц8080 79041 - 1	Cloth Plate, for Style 9900 AJ (screw No. 80) Loop Retainer Shaft Support Pin, for Style	1 7
79048	9900 AR Screw, hexagonal head, for main feed dog on Style 9900 AQ =	6
79077	Screw, headless, for supporting main feed dog on Styles 9900 AJ, 9900 AQ	6
79079	Differential Feed Bar Guide, for Styles 9900 AJ, 9900 AQ	23
79085	Needle Thread Regulating Spring, for Style 9900 AR (stud No. HS 65 P-4)	14
79086	Needle Thread Tension Post, for Style 9900 AR	10
·		
	<u> </u>	<u></u>



WORLDWIDE SALES AND SERVICE

Union Special Corporation maintains sales and service facilities throughout the world. These offices will aid you in the selection of the right sewing equipment for your particular operation. Union Special Corporation representatives and service technicians are factory trained and are able to serve your needs promptly and efficiently. Whatever your location, there is a qualified representative to serve you.

Corporate Office:

One Union Special Plaza

Huntley, IL 60142 Phone: 708 • 669 • 5101 Fax: 708 • 669 • 1096

European Distribution Center:

Union Special GmbH Raiffeisenstrasse 3

D-71696 Möglingen, Germany

Tel: 49 • 07 141 • 247 • 0 Fax: 49 • 7141 • 247 • 100 Brussels, Belgium
Charlotte, N.C.
Commerce, CA
El Paso, TX
Hong Kong, China
Huntley, IL
Leicester, England
Lifle, France
Miami, FL
Milan, Italy
Mission, TX
Möglingen, Germany
Montreal, Quebec
Osaka, Japan

Other Representatives throughout all parts of the world.



