



THE EDGELOCK MACHINES FORTH-THREE THOUSAND SERIES

LIST OF PARTS FOR

STYLE 43200G STYLE 43200 G

Supplementary Catalog No. 75 N

Catalog No. 75 N applies only to machines with serial numbers higher than 293000 and includes all parts in Style 43200 G that are not included in Catalog No. 75 L.

CATALOG No. 75N

The Edgelock Machines

Forty-Three Thousand Series

Supplementary Catalog No. 75 N

List of Parts for Style 43200 G


Description of Style 43200 G

For hemming overalls, jackets, and similar garments, high throw, two needle bar bearings; stitching Type EFb-1, hem turned on under surface of fabric, Type 128 needle, stitch range 16 to 8 per inch, split hemming attachment and knee press for opening same, standard widths of hem 3/8 and 1/2 inch.

Copyright 1938
By
Union Special Machine Co.
Rights Reserved In All Countries

Union Special Machine Company U.S.A.

Printed in U.S.A.



"Electro Drive"

Table Top, drawer, stand, and treadle are shown only for clarity and are furnished separately.

Plate 1 - Full Size




Plate 2 - Full Size





Plate 3 - One-Half Size






Plate 5 - One-Half Size




Plate 6 - One-Fourth Size





Plate 7 - One-Eighth Size













	LIDI OF FARTO	
Symbol	The figures in the last column refer only to the	Plate
- ·		
to	plates illustrating the parts and are not to be	No.
Order by	used in ordering. Refer to pink insert for prices.	
-		
20 M	Washer, for knee press lever	2
T23	Screw, for presser foot spring	2
16.7 05.0		2
25 S	for hemmer	
25 CC	for belt guard, also for No. 43281 N	2
94	for needle thread tension disc	
• •	separator	2
222 D	for main oil reservoir cover	2
258	Nut, for knee press lever, also for No.	_
250		_
	35780 B	2
402	Lifter Lever Stop Pin	2
650 G-12	Machine Bolt, hexagonal head, 5/16 x 1 1/2	
	inches, for attaching "Electro Drive" to	
	helt teke up conceptur	2
(50.30	belt take-up assembly	-
652-12	Washer, 3/16 inch, for belt guard screws on	
	"Electro Drive" installations	
652 A-20	Lock Washer, 5/16 inch, for attaching	
· / · · · · · · · · · · · · · · · · · ·	"Electro Drive" to belt take-up assembly	_
666 50		2
666-50	Oil Cup, for main oil reservoir cover	2
666-79	Oil Cup Assembly, with sight feed and	
	signal stop	4
668-1	Porcelain Eyelet, for oil reservoir cover	Ż
668-7	Porcelain Insert, for tension thread eyelet	2
		~
668-12	Porcelain Insert Locking Ferrule, for ten-	۱_
	sion thread eyelet	2
668-14	Porcelain Insert Locking Ferrule, for oil	
·	reservoir cover	2
906	Screw, for feed bar guiding stud fork	2 2 2 2
		ا أ
9663	for throat plate support bracket	=
11638 F	for knee press lever	2
12873 A	Needle Bar Bushing	2
15037 A	Nut, for feed lift ball joint stud, also	l
	for No. 43242 N	2
151.90	Washer, for looper drive shaft arm ball	~
15488		٦
'	joint	2
21104 B - 5	Belt Take-up Hanger Pivot Shaft, 5 inches	١.
	long (set screw No. 22627 A)	6
21104 B-9	Thread Stand Rod, 9 inches long (screw	Ι,
 - /	No. 22509)	6
01040 11 350	"V" Belt, No. 2 size, 35 inches long	6
21262 H-350	INVESTIGATE AND E SIZE, DO INCHES TOUR	
21262 H-370	"V" Belt, 37 inches long	6
21262 H-390	"V" Belt, 39 inches long	6
21300 B-2 1/2		
, -,-	attaching belt take-up and hanger to	1
03703 *** 10	table top	-
21371 HM-48	Table Top, 48"x 16"x 1 3/4", for American	
	Safety Table installations	
21371 HM-54	Table Top, 54 inches long	
21371 HM-60	" " 60 inches long	l
21371 HN-48	40 x 10 x 1)/4 ; 101 E1ecoro	
	Drive" group installations	

Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
21371 HN-5/	Table Top, 54 inches long	
21371 HN-60	" 60 inches long	_
21371 HP-48	" 48"x 16"x 1 3/4", for open line	
21)(1 nr-40		
	shaft installations	
21371 HP-54)	
21371 HP-60	" " 60 inches long	_
21371 HQ	Cover Strip, wood, for oil drain	
21375 AP	Belt Guard, for "Electro Drive" pulley	7
21660 D	Knee Press Assembly; one each Nos. 20 M,	
_	258, 11638 F, 21661 F, 21664, 21677 A; two	
	No. 21661 G (specify component parts in	
	ordering)	_
01/41 F	Knee Press Lever (screw No. 69 FD, stud No.	
21661 F		6
01//1 0	11638 F, nut No. 258)	
21661 G	Knee Press Lever Connector (screw No. 95)	6
21677 A	" " Rod	ò
21680 AP	Base Plate, steel	6
21697 U	Belt Take-up and Hanger Assembly, for	
	"Electro Drive" installations; one each	Ì
	"Electro Drive" installations; one each Nos. 21104 B-5, 21697 V, 21697 W, 22627 A;	
	two each Nos. 22649 K-96, 28509 B; three	
	each Nos. 650 G-12, 652 A-20	7
21697 V	Belt Take-up Hanger, upper section	<u>.</u>
21697 W	" lower section	
22510	Cap Screw, square head, 1/4 inch diameter,	l.
22)10	5/8 inch long, 20 threads per inch, for	
	transmission treadle bracket	2
-00500		2
22528	Screw, for upper needle bar bearing bracket	5
22570 A	for hemmer mounting plate	2 2 2
22571 B	Plug Screw, for top oiler hole	1 2
22597	Spot Screw, for "V" belt pulley	2
22627 A	Set Screw, for belt take-up hanger pivot	
	shaft	2
22649 K-96	Adjusting Screw, square head, 5/16 inch	
	diameter, 1 1/2 inches long, 18 threads	I
	per inch, for belt take-up hanger (nut No.	<u> </u>
	28509 B)	2
22757	Screw, for looper avoid shaft bracket	2
22791 C	Screw Pin, for main shaft crank pin	2
	Screw, for needle bar bearing bracket oil	-
22799	·	9
angl a	reservoir cover	2
22849	Screw, for lower left side cover	
22863	Adjusting Screw, for feed dog holder	2
23364 AA	Hemmer Assembly; one each Nos. 91 A, 907,	[
•	23364 AB, 23364 AC, 23364 AD, 23364 AE,	
	23364 AF, 23364 AG, 23425 V, 28504; two	
	each Nos. 22593, 22711 (attaching screw	Į.
	No. 25 S)	4
23364 AB	Hemmer Base	4
23364 AC	Scroll, right (screw No. 22711)	Lī.
-JJ+ 110		4
	<u> </u>	ــــــــــــــــــــــــــــــــــــــ


Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
23364 AD 23364 AE 23364 AF 23364 AF 23364 AG 23425 V 28509 B 28575 B 28576 B 28577 28578 B 28585 B 28602 S-23 28602 S-24 28602 S-25 28602 S-26 28602 S-27	Hemmer Scroll, left (stop screw No. 91 A) " Operating Rod (nut No. 907) " Slide	444144 27 72 7 7 3 3 3 3 3 3 3
29477 GA	American Safety Table group installations Looper Avoid Connecting Rod Assembly; one each Nos. 29126 P, 18, 269, 22747, 41255 B, 43241 D, 43246 G. Assembly is set to gauge before shipment. The approximate distance between centers is 5 13/64 inches	<u> </u>
29477 GB	Feed Drive Eccentric Connecting Rod Assembly; one each Nos. 29126 S, 18, 269, 22747, 39241, 41255 B, 43241 D. Assembly is set to gauge before shipment. The approximate distance between centers is 4 9/32 inches	5


Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
29477 GC	Feed Lift Eccentric Connecting Rod Assembly; one each Nos. 29126 W, 18, 269, 43235 F, 43236 A. Assembly is set to gauge before shipment. The approximate distance between centers is 3 11/16 inches	5
35755 E 35780 В 39193	Washer, for feed lift ball joint stud Lifter Lever Extension (nut No. 258) Main Oil Reservoir Sight Gauge Assembly; one each Nos. 660-92, 660-93, 666-49, 39193 A,	5 2 5 2
39193 В 39 22 1	Main Oil Reservoir Sight Gauge Base Pulley, grooved, for "V" belt, working diameter 2 1/2 inches (spot screw No. 22597, set screw No. 22597 A)	
39241	Feed Drive Eccentric Connecting Rod (nut, right thread, No. 18, nut, left thread, No. 269)	5
‡43122	Main Shaft, including crank pin (crank pin No. 39161 G, crank pin set screw No. 22791 C)	6
43152	Needle Bar Cross Head Guide Block (screw No. 22585)	1
43154 43164 E	Needle Bar Link Needle Bar Link Thread Eyelet, for looper	5
43205 43208 G 43213 G	thread (screw No. 87 U)	1 1 1 3
\$43217 43221	Needle Bar, includes clamp nut No. 39151 (set screw No. 88)	5
43221 A	39221, 43221 A; three No. 22559 A Pulley Rim, for machines equipped with "V"	3
43227 G-3/8	belt drive (screw No. 22559 A) Presser Foot Assembly, for 3/8 inch hem; one each Nos. 43230 K-3/8, T23, 91, 22799 B,	1
43227 G -1/ 2	43230 L, 43230 M	1
43228 g 43230 k - 3/8	Throat Plate (screw No. 28) Presser Foot Bottom, for 3/8 inch hem (hinge	1
43230 к -1/2	Presser Foot Bottom, for 1/2 inch hem (hinge screw No. 22799 B)	1
43230 L	Presser Foot Shank	1
43230 M	Presser Foot Spring (screw No. T23)	ī
\$43234 G	Feed Bar, including tiltable feed dog holder	l ⁻
	No. 51134 G (set screw No. 89, feed dog	\
	holder adjusting screw No. 22863)	5
	-1/-	

-14-

Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
	used in ordering.Refer to pink insert for prices. Feed Bar Guiding Stud (nut No. 907, lock washer No. 652 C-9)	23531 4 15 2213 4 5 32 55 3
4 32 53 U-4	ing bracket	2
43253 U-5 43253 U-6 43253 U-8 43253 U-9 43255 B 43255 G	" .005 inch thick	2 2 2 2 2 3 3
43257 A 43257 H 43257 N 43257 U 43261 A	# Plunger	5 2 1 6

	LIST OF PARTS	
Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
43262 Ј	Side Cover, left (attaching screw No. 22848, porcelain insert No. 668-1, porcelain in-	7
‡43262 N	sert ferrule No. 668-14)	7 6
43264 G	Looper Thread Tube (screw, lower, No. 98 A,	4
‡43265 A	screw, upper, No. 376)	11
43280 B 43281 N 43282 A 43283 A 43283 B 43294 F 43457 B 51134 G	porcelain insert ferrule No. 668-14) Throat Plate Support (screw No. 376) Rear Cover (screw No. 25 CC) Hemmer Mounting Plate (screw No. 22570 A) Side Cover, lower, left (screw No. 22849) " " Gasket Presser Spring Feed Dog Holder, tiltable (nut No. 258 A, washer No. 6042 A)	44636361
•		
÷		
	l i	





WORLDWIDE SALES AND SERVICE

Union Special Corporation maintains sales and service facilities throughout the world. These offices will aid you in the selection of the right sewing equipment for your particular operation. Union Special Corporation representatives and service technicians are factory trained and are able to serve your needs promptly and efficiently. Whatever your location, there is a qualified representative to serve you.

CorporateOffice:

One Union Special Plaza Huntley, IL 60142 Phone: 847•669•5101 Fax: 847•669•1096

European Distribution Center:

Union Special GmbH Raiffeisenstrasse 3 D-71696 Möglingen, Germany Tel: 49•07141•247•0 Fax: 49•7141•247•100 Brussels, Belgium Charlotte, N.C. El Paso, TX Hong Kong, China Huntley, IL Leicester, England Lille, France Miami, FL Milan, Italy Möglingen, Germany Montreal, Quebec Osaka, Japan Santa Fe Springs, CA

Other Representatives throughout all parts of the world.



