


PARTS LIST

for

CONSEW


DISC FEED OVERSEAMING MACHINES

MODEL **760** SERIES



CONSOLIDATED SEWING MACHINE DIV.
CONSEW INTERNATIONAL LTD.


Ref. No.	Parts No.	Description	760	761	762	762H	763	764	765	771	772	773	775
1	7224	Looper (For two thread)	0	0	0	0	0	0	0	1	1	1	1
2	7222-A	Thread Guide Plate	0	0	0	0	0	0	0	1	1	1	0
3	7222-B	Thread Guide Plate	0	0	0	0	0	0	0	0	0	0	1
4	113-B	Thread Guide Plate Screw	0	0	0	0	0	0	0	1	1	1	1
5	4152	Thread Guide	1	1	1	1	1	1	1	0	0	0	0
6	129-A	Thread Guide Screw	1	1	1	1	1	1	1	0	0	0	0
7	4151	Spool Pin	1	1	1	1	1	1	1	0	0	0	0
8	4150	Cotton Stand Base w/Wood Screw	1	1	1	1	1	1	1	0	0	0	0
9	7255	Twéezers	1	1	1	1	1	1	1	1	1	1	1
10	AC 01	Screw Driver	1	1	1	1	1	1	1	1	1	1	1
11	AC 02	Screw Driver	1	1	1	1	1	1	1	1	1	1	1
12	AC 05	Oil	1	1	1	1	1	1	1	1	1	1	1
13	7104	Base Plate Oil Pipe	1	1	1	1	1	1	1	1	1	1	1
14	7254	Oil Bottle	1	1	1	1	1	1	1	1	1	1	1
15	AC 04	Oiler	1	1	1	1	1	1	1	1	1	1	1
16	7086	Spanner	1	1	1	1	1	1	1	1	1	1	1
17	AC 06	Wrench	1	1	1	1	1	1	1	1	1	1	1
18	7257	Threadle	1	1	1	1	1	1	1	1	1	1	1
19	7228	Threadle Lever	1	1	1	1	1	1	1	1	1	1	1
20	7248	Chain Hook Screw	1	1	1	1	1	1	1	1	1	1	1
21	7249	Chain	1	1	1	1	1	1	1	1	1	1	1
22	AC-14	Two Thread Cotton Stand Set	0	0	0	0	0	0	1	1	1	1	1
23	7250	Needle (AI×1)	5	0	0	0	0	0	0	0	0	0	0
"	7250	Needle (DC×3)	0	5	5	5	5	5	5	5	5	5	5




When ordering parts


you must state Model Number as well as parts number

Ref. No.	Parts No.	Description	760	761	762	762H	763	764	765	771	772	773	775
1	7001-A	Main Frame	1	1	0	0	0	0	0	1	0	0	0
"	7001-D	Main Frame	0	0	1	1	1	1	1	0	1	1	1
2	7003	Top Cover	1	1	1	1	1	1	1	1	1	1	1
3	4078	Top Cover Set Screw	2	2	2	2	2	2	2	2	2	2	2
4	7004	Front Cover	1	1	1	1	1	1	1	1	1	1	1
5	7111	Front Cover Screw	2	2	2	2	2	2	2	2	2	2	2
6	7002	Base Plate	1	1	1	1	1	1	1	1	1	1	1
7	7092	Base Screw	4	4	4	4	4	4	4	4	4	4	4







Ref. No.	Parts No.	Description	760	761	762	762H	763	764	765	771	772	773	775
1	7069-A	Main Shaft Bushing (Short)	1	1	1	1	1	1	1	1	1	1	1
2	7068-A	Main Shaft Bushing (Long)	1	1	1	1	1	1	1	1	1	1	1
3	7091	Main Shaft Bushing Screw	2	2	2	2	2	2	2	2	2	2	2
4	7005	Belt Wheel	1	1	1	1	1	1	1	1	1	1	1
5	131	Belt Wheel Screw	2	2	2	2	2	2	2	2	2	2	2
6	7006	Main Shaft	1	1	1	1	1	1	1	1	1	1	1
7	7007-A	Feed Eccentric	1	0	0	0	0	0	0	0	0	0	0
"	7007-B	Feed Eccentric	0	1	1	1	1	1	1	1	1	1	1
8	98-A	Feed Eccentric Set Screw	2	2	2	2	2	2	2	2	2	2	2
9	7008	Feed Connection	1	1	1	1	1	1	1	1	1	1	1
10	7087-A	Feed (Gear or Rocker) Shaft Screw	2	2	2	2	2	2	2	2	2	2	2
11	7088	Feed (Gear or Rocker) Shaft Screw Nut	2	2	2	2	2	2	2	2	2	2	2
12	7207	Feed Rocker Shaft	0	0	1	1	1	1	1	0	1	1	1
13	7206	Feed Rocker	0	0	1	1	1	1	1	0	1	1	1
14	4173	Feed Rocker Set Screw	0	0	1	1	1	1	1	0	1	1	1
15	7009-A	Feed Lever	1	1	1	1	1	1	1	1	1	1	1
16	7234	Feed Lever Screw	1	1	1	1	1	1	1	1	1	1	1
17	7235	Stitch Regulating Graduated Plate	1	1	1	1	1	1	1	1	1	1	1
18	7010	Stitch Regulating Stud	1	1	1	1	1	1	1	1	1	1	1
19	7016	Stitch Indicator	1	1	1	1	1	1	1	1	1	1	1
20	7013	Stitch Regulating stud Nut	1	1	1	1	1	1	1	1	1	1	1
21	7011	Stitch Regulating Block	1	1	1	1	1	1	1	1	1	1	1
22	7012-A	Feed Lever Washer	1	1	1	1	1	1	1	1	1	1	1
23	4068-A	Stitch Stud Nut	1	1	1	1	1	1	1	1	1	1	1
24	7014	Feed Dog Driving Screw	1	1	1	1	1	1	1	1	1	1	1




Ref. No.	Parts No.	Description	760	761	762	762H	763	764	765	771	772	773	775
1	7058	Looper Frame Fulcrum Pin	1	1	0	0	0	0	0	1	0	0	0
2	7100	Looper Frame Fulcrum Pin Nut	1	1	0	0	0	0	0	1	0	0	0
3	7062	Oscillating Cam	1	1	1	1	1	1	1	1	1	1	1
4	98-A	Oscillating Cam Set Screw	2	2	2	2	2	2	2	2	2	2	2
5	7059	Looper Oscillating Arm	1	1	1	1	1	1	1	1	1	1	1
6	7115	Looper Oscillating Arm Pinch Screw	2	2	2	2	2	2	2	2	2	2	2
7	7063	Looper Oscillating Roller	1	1	1	1	1	1	1	1	1	1	1
8	7060	Looper Cam Roller Stud	1	1	1	1	1	1	1	1	1	1	1
9	4031	Looper Cam Roller Stud Set Screw	1	1	1	1	1	1	1	1	1	1	1
10	7065-A	Looper Frame Eccentric	1	1	1	0	1	0	0	1	1	1	0
"	7065-C	Looper Frame Eccentric	0	0	0	1	0	1	1	0	0	0	1
11	98-A	Looper Frame Eccentric Set Screw	2	2	2	2	2	2	2	2	2	2	2
12	7056-A	Looper Shaft	1	1	1	1	1	1	0	1	1	1	0
13	7112	Looper Chuck Shell	1	1	1	1	1	1	1	1	1	1	1
14	7057-A	Looper Frame	1	1	0	0	0	0	0	1	0	0	0
"	7057-B	Looper Frame	0	0	1	1	1	1	1	0	1	1	1
15	7055	Looper	1	1	1	1	1	1	1	0	0	0	0
16	7230	Looper Frame Rocker (Rear)	0	0	1	1	1	1	1	0	1	1	1
17	7100	Looper Frame Rocker (Rear) Nut	0	0	1	1	1	1	1	0	1	1	1
18	7231	Looper Rocker Bracket (Rear)	0	0	1	1	1	1	1	0	1	1	1
19	7099	Looper Rocker Bracket Screw	2	2	4	4	4	4	4	2	4	4	4
20	4215	Looper Rocker Bracket Screw Washer	2	2	4	4	4	4	4	2	4	4	4
21	7084	Rocker Packing (0.1% _m 0.3% _m 0.5% _m) (Optional)	—	—	—	—	—	—	—	—	—	—	—
22	7066	Looper Frame Rocker (Front)	1	1	1	1	1	1	1	1	1	1	1
23	7102	Looper Frame Rocker (Front) Nut	1	1	1	1	1	1	1	1	1	1	1
24	7067	Looper Rocker Bracket (Front)	1	1	1	1	1	1	1	1	1	1	1
25	7077	Oil Cap	1	1	1	1	1	1	1	1	1	1	1




Ref. No.	Parts No.	Description	760	761	762	762H	763	764	765	771	772	773	775
1	7239	Thread Tension Nut	0	1	1	1	1	1	1	2	2	2	2
2	7238	Thread Tension Spring	0	1	1	1	0	1	1	2	2	0	2
3	7238-A	Thread Tension Spring	0	0	0	0	1	0	0	0	0	2	0
4	7237	Thread Tension Disc	0	2	2	2	2	2	2	4	4	4	4
5	7236	Thread Tension Post	0	1	1	1	1	1	1	2	2	2	2
6	7081	Thread Tension Guide	0	1	1	1	1	1	1	2	2	2	2
7	5155-A	Thread Guide Stud	1	1	1	1	1	1	1	2	2	2	2
8	5207	Thread Guide Stud Nut	1	1	1	1	1	1	1	2	2	2	2
9	7073	Thread Guide	1	1	1	1	1	1	1	1	1	1	1
10	113-B	Thread Guide Screw	1	1	1	1	1	1	1	1	1	1	1
11	7070-A	Needle Bar Bushing	1	1	1	1	1	1	0	1	1	1	0
12	7071	Needle Bar Bushing Nut	1	1	1	1	1	1	1	1	1	1	1
13	7098	Needle Bar Tension Plunger	1	1	1	1	1	1	1	1	1	1	1
14	7049	Needle Bar Tension Spring	1	1	1	1	1	1	1	1	1	1	1
15	7048	Needle Bar Tension Plunger Nut	1	1	1	1	1	1	1	1	1	1	1
16	7047	Needle Bar Tension Plate	1	1	1	1	1	1	1	1	1	1	1
17	7097	Needle Bar Tension Plate Screw	1	1	1	1	1	1	1	1	1	1	1
18	7045-A	Needle Bar	1	0	0	0	0	0	0	0	0	0	0
"	7045-B	Needle Bar	0	1	1	1	1	1	0	1	1	1	0
19	7250-A	Needle (AI×1)	1	0	0	0	0	0	0	0	0	0	0
"	7250-B	Needle (DC×3)	0	1	1	1	1	1	1	1	1	1	1
20	7046-A	Needle Clamp	1	1	1	1	1	1	1	1	1	1	1
21	7096	Needle Clamp Screw	1	1	1	1	1	1	1	1	1	1	1
22	7305	Balance Weight	1	1	1	1	1	1	1	1	1	1	1
23	7306	Balance weight Screw	1	1	1	1	1	1	1	1	1	1	1
24	7051	Needle Bar Yoke	1	1	1	1	1	1	1	1	1	1	1
25	108	Needle Bar Yoke Pinch Screw	2	2	2	2	2	2	2	2	2	2	2
26	7054-A	Needle Bar Yoke Eccentric	1	0	0	0	0	0	0	0	0	0	0
"	7054-B	Needle Bar Yoke Eccentric	0	1	1	1	1	1	1	1	1	1	1
27	98-A	Needle Bar Yoke Eccentric Set Screw	2	2	2	2	2	2	2	2	2	2	2




Ref. No.	Parts No.	Description	760	761	762	762H	763	764	765	771	772	773	775
1	7043-A	Needle Guard	1	0	0	0	0	0	0	0	0	0	0
"	7043-B	Needle Guard	0	1	1	1	0	0	0	1	1	0	0
2	7044-A	Needle Guard Screw	1	1	1	1	0	0	0	1	1	0	0
"	7044-A	Front Feed Disc Screw	0	0	0	0	1	1	0	0	0	1	0
3	7024-A	Rear Feed Disc	1	0	0	0	0	0	0	0	0	0	0
"	7024-B	Rear Feed Disc	0	1	1	0	0	0	0	1	1	0	0
"	7024-C	Rear Feed Disc	0	0	0	0	1	1	0	0	0	1	0
"	7024-D	Rear Feed Disc	0	0	0	1	0	0	0	0	0	0	0
4	7090	Rear Feed Disc Set Screw	2	2	2	2	2	2	0	2	2	2	0
5	7025-A	Front Feed Disc	1	0	0	0	0	0	0	0	0	0	0
"	7025-B	Front Feed Disc	0	1	1	1	0	0	0	1	1	0	0
"	7025-C	Front Feed Disc	0	0	0	0	1	1	0	0	0	1	0
6	7026	Front Feed Disc Bearing Roller	12	12	12	12	12	12	0	12	12	12	0
7	7027	Front Feed Disc Stud	1	1	1	1	1	1	0	1	1	1	0
8	7093	Front Feed Disc Stud Screw	1	1	1	1	1	1	1	1	1	1	1
9	7253	Front Feed Disc Washer	0	0	0	0	1	1	0	0	0	1	0
10	7028	Feed Disc Arm	1	1	1	1	1	1	0	1	1	1	0
11	7030	Feed Disc Arm Shaft (Upper)	1	1	1	1	1	1	1	1	1	1	1
12	7029	Feed Disc Arm Shaft (Lower)	1	1	1	1	1	1	1	1	1	1	1
13	7072	Feed Disc Arm Shaft Position Pin	2	2	2	2	2	2	2	2	2	2	2
14	7259	Feed Disc Arm Stopper	1	1	1	1	1	1	1	1	1	1	1
15	4068	Feed Disc Arm Stopper Nut	1	1	1	1	1	1	1	1	1	1	1
16	7031-C	Pressure Lever	0	0	1	1	1	1	1	0	1	1	1
17	7032-A	Pressure Lever Shaft	1	1	1	1	1	1	1	1	1	1	1
18	131	Pressure Lever Shaft Screw	1	1	1	1	1	1	1	1	1	1	1
19	7034	Pressure Lever Adjusting Screw	0	0	1	1	1	1	1	0	1	1	1
20	7035	Pressure Lever Adjusting Screw Nut	0	0	1	1	1	1	1	0	1	1	1
21	7033-A	Pressure Lever Spring	0	0	1	1	1	1	1	0	1	1	1
22	7258	Feed Disc Arm Rubber Cushion	1	1	1	1	1	1	1	1	1	1	1



Ref. No.	Parts No.	Description	760	761	762	762H	763	764	765	771	772	773	775
1	7031-A	Pressure Lever	1	1	0	0	0	0	0	1	0	0	0
2	7034	Pressure Lever Adjusting Screw	1	1	0	0	0	0	0	1	0	0	0
3	7035	Pressure Lever Adjusting Screw Nut	1	1	0	0	0	0	0	1	0	0	0
4	7033-A	Pressure Lever Spring	1	1	0	0	0	0	0	1	0	0	0
5	7022-A	Rear Feed Disc Shaft	1	1	0	0	0	0	0	1	0	0	0
6	5266	Rear Feed Disc Shaft Collar	1	1	0	0	0	0	0	1	0	0	0
7	132	Feed Disc Shaft Collar Set Screw	2	2	0	0	0	0	0	2	0	0	0
8	7021	Feed Gear (Small)	1	1	0	0	0	0	0	1	0	0	0
9	96	Feed Gear Set Screw	2	2	0	0	0	0	0	2	0	0	0
10	7038	Feed Gear Roller	8	8	0	0	0	0	0	8	0	0	0
11	7040	Feed Gear Roller Pin	8	8	0	0	0	0	0	8	0	0	0
12	7039-A	Feed Gear Roller Spring	8	8	0	0	0	0	0	8	0	0	0
13	7041-A	Feed Retaining Drum Plate	1	1	0	0	0	0	0	1	0	0	0
14	7108	Feed Retaining Drum Plate Shoulder Screw	1	1	0	0	0	0	0	1	0	0	0
15	7037	Feed Retaining Drum Cam	1	1	0	0	0	0	0	1	0	0	0
16	7095-A	Feed Retaining Drum Cam Set Screw	4	4	0	0	0	0	0	4	0	0	0
17	7036-A	Feed Retaining Drum Ring	1	1	0	0	0	0	0	1	0	0	0
18	7042-A	Feed Retaining Drum	1	1	0	0	0	0	0	1	0	0	0
19	98	Feed Retaining Drum Set Screw	2	2	0	0	0	0	0	2	0	0	0
20	7094-A	Ring Set Screw	4	4	0	0	0	0	0	4	0	0	0
21	7020	Feed Gear	1	1	0	0	0	0	0	1	0	0	0
22	96	Feed Gear Set Screw	2	2	0	0	0	0	0	2	0	0	0
23	7018	Feed Gear Cam	1	1	0	0	0	0	0	1	0	0	0
24	7095-B	Feed Gear Cam Set Screw	4	4	0	0	0	0	0	4	0	0	0
25	7036-A	Feed Gear Ring	1	1	0	0	0	0	0	1	0	0	0
26	7015-A	Feed Gear Plate	1	1	0	0	0	0	0	1	0	0	0
27	7017	Feed Gear Shaft	1	1	0	0	0	0	0	1	0	0	0
28	7304	Feed Gear Shaft Washer	1	1	0	0	0	0	0	1	0	0	0



Ref. No.	Parts No.	Description	760	761	762	762H	763	764	765	771	772	773	775
1	7205-A	Feed Rocker Shaft Crank	0	0	1	1	1	1	1	0	1	1	1
2	7252	Feed Rocker Shaft Crank Screw	0	0	2	2	2	2	2	0	2	2	2
3	7203-A	Feed Connection (Small)	0	0	1	1	1	1	1	0	1	1	1
4	1644	Feed Connection Screw	0	0	2	2	2	2	2	0	2	2	2
5	5275	Feed Connection Screw Washer	0	0	2	2	2	2	2	0	2	2	2
6	4068	Feed Connection Screw Nut	0	0	2	2	2	2	2	0	2	2	2
7	7022-B	Rear Feed Disc Shaft	0	0	1	1	1	1	1	0	1	1	1
8	7304	Feed Disc Shaft Washer	0	0	1	1	1	1	1	0	1	1	1
9	7041-B	Feed Plate	0	0	1	1	1	1	1	0	1	1	1
10	7037	Feed Cam	0	0	1	1	1	1	1	0	1	1	1
11	7095-A	Feed Cam Set Screw	0	0	4	4	4	4	4	0	4	4	4
12	7036-B	Feed Ring	0	0	1	1	1	1	1	0	1	1	1
13	4129	Feed Ring Set Screw	0	0	4	4	4	4	4	0	4	4	4
14	7042-B	Feed Drum	0	0	1	1	1	1	1	0	1	1	1
15	98	Feed Drum Set Screw	0	0	2	2	2	2	2	0	2	2	2
16	7038	Feed Roller	0	0	4	4	4	4	4	0	4	4	4
17	7040	Feed Roller Pin	0	0	4	4	4	4	4	0	4	4	4
18	7039-A	Feed Roller Spring	0	0	4	4	4	4	4	0	4	4	4
19	7307	Feed Disc Shaft Spring washer	0	0	1	1	1	1	1	0	1	1	1
20	8009	Feed Disc Shaft Spring	0	0	1	1	1	1	1	0	1	1	1
21	7303	Roller Clutch Bushing	0	0	1	1	1	1	1	0	1	1	1
22	129-A	Roller Clutch Bushing Set Screw	0	0	2	2	2	2	2	0	2	2	2
23	7301	Roller Clutch	0	0	1	1	1	1	1	0	1	1	1
24	7302	Roller Clutch Bracket	0	0	1	1	1	1	1	0	1	1	1
25	4184	Roller Clutch Bracket Set Screw	0	0	1	1	1	1	1	0	1	1	1



Parts for Models FS - 765 • 775

Ref. No.	Parts No.	Description	765	775
1	7405	Needle Bar Tension Post Support	1	1
2	129-A	Work Guide Set Screw	1	1
3	114-A	Needle Bar Bushing Set Screw	1	1
4	129-B	Needle Bar Tension Post Set Screw	1	1
5	7403	Needle Bar Bushing	1	1
6	7071	Needle Bar Bushing Nut	1	1
7	7404	Needle Bar Tension Post	1	1
8	7402	Needle Bar	1	1
9	7406	Looper Shaft	1	1
10	7401-A	Feed Disc Arm	1	1
11	7419	Front Feed Disc Stud	1	1
12	7418	Needle Guard	1	1
13	7408	Front Feed Disc Bearing	1	1
14	7407	Front Feed Disc (Small)	1	1
15	7420	Front Feed Disc Cap Screw	1	1
16	7414	Rear Feed Disc Cap Screw	1	1
17	7409	Rear Feed Disc	1	1
18	7410	Rear Feed Disc Gear	1	1
19	7412	Rear Feed Disc Bearing Roller	12	12
20	7411	Rear Feed Disc Stud	1	1
21	7413	Rear Feed Disc Stud Nut	1	1
22	7416	Rear Feed Disc Shaft Gear	1	1
23	129-B	Rear Feed Disc Shaft Gear Set Screw	2	2
24	7414	Idler Gear Cap Screw	1	1
25	5032	Idler Gear	1	1
26	7415	Idler Gear Stud	1	1
27	7417	Rear Feed Disc Gear Bracket	1	1
28	98	Gear Stud Set Screw	2	2

