


三菱工業用ミシン部品カタログ Industrial Sewing Machine Parts Catalog


Model LY2-3319

	目	次		CONTENTS	Page
Α	本 体	関 ほ	{	Arm bed & it's accessories	2
В	縫 機	構(I))	Sewing mechanism (I)	4
С	縫機構(Ⅱ)お	よび下送り機構	ţ	Sewing mechanism $\ (II)\ $ & feed rock lower shaft mechanism $\ \cdots$	6
D	送 り調	節機構	ŧ	Stitch length mechanism	8
Ε	上部水平	区 送 り機 構	ŧ	Upper feed rock shaft mechanism	10
F	上部上了	下 送 り機 楫	ŧ	Upper feed lifting rock shaft mechanism	12
G	押え	機	ţ	Presser foot mechanism	14
Н	糸 切	り機構		Knife actuating mechanism	16
J	タッチバック機構	および検出器機構	ŧ }	Touch back mechanism & detector mechanism	18
K	給 油	機 構	ŧ	Oil lubrication mechanism	20
L	付	属 品	1	Accessories	22
М	索	弓	l	Index ·····	24

ミシン用部品コードの採番基準 MITSUBISHI SPARE PARTS No. Designation system

注:※欄には英文字(A,B,···X,Y,Z)が入る。 Remarks:Alphabet(A,B,···X,Y,Z)should be taken at ※ mark.






注: 一般品についての機種形名は、その部品が最初に使用された機種形名を示します。従って長期に亘る場合は、機種の改廃が行われるため、当初の機種以外の機種で使用されている場合があります。 Sewing machine Models, of Standard Parts are indicated model of these parts are registered firstry. Parts are used for not only the indicated model, but also another models, in reason of New development, improvement after.


- パーツカタログご利用に際して Information on use of the parts catalog

- ・補用部品ご注文の際は、部品コードでご注文下さい。また、このパーツブックの管理番号と発行年月(表紙右下,例えば、P-216 200106)モデル機械番号を、合わせてご連絡頂ければ幸いです。
- ・一部の部品について、改良のため予告なしに変更になる場合がありますのでご了承下さい。
- ・このパーツカタログは2001年6月のデータにもとづいて作成されたものです。
- ・部品コード欄が、――となっている部品は、補給いたしません。ただし組コードが記載されているものは、組部品として補給いたしますので、組コードでご注文下さい。
- ・使用個数欄の英数字組合せ文字は、このモデル番号のサブ機械番号をしめしています。
- ・尚、本パーツブックの記載内容にお気付きの点がありましたら、お知らせ頂ければ幸いです。
- When ordering any spare part, please specify its part code. In addition, please specify the management number and issued date of this parts catalog (e. g.P-216 200106 indicated at bottorn right of the front cover) and the machine model number.
- · Some parts are subject to change due to modification without notice.
- This parts catalog is based the data as of Jun.2001.
- Any part marked-in the part code column will not be supplied. When a part has its assembly code, plase specify the
 assembly code because that part is supplied as an assembly part.
- Alphanumerical characters indicated in the required quantity column indicate the sub machine number of this model number.
- · Please write to us if you have any question on this parts catalog.



A 本体機構 ARM BED& IT'S ACCESSORIES


Fig. No.	変更 Mod	部品コード Parts.No.	部品名	Description	使用数 Amt. Reg.	
A01		MG33A0873		Oil shield plate·····	<u> </u>	
A02		M91109004		Screw 11/64(40)x8		
A03		M91305080		Rubber plug 13·····		
A04				Set screw 11/64(40)x5.5		
A05		MF36A1180		Thread guide (arm top)·····		
A06		M91116002		Screw 11/64(40)x8		
A07		M91106004		Screw 11/64(40) x8		
80A		MF03A0584		Thread take-up cover·····		
A09		M91101046		Pre-tension adjusting nut 11/64(40)·····		
A10		MF36A0245		Pre-tension spring		
A11		MF10A1555		· Tension discs for pre-tension·····		
A12		MF90A0553		· Pre-tension stud·····		
A13		MF00A0181		· Thread guide·····		
A14		M90909003		Screw 9/64 (40) x6		
A15		MG43A0181		· Thread guide·····		
A16		M91508001		· Set screw 15/64(28)x6·····		
A17		M91107002		Screw 11/64(40) x5.5		
A18		MG30A0601		· Cloth guide plate·····		
A19		MQ50A0181		· Thread guide·····		
A20		MF10A0709		· Thread tension regulator bushing·····		
A21		MF02A0187		· Thread take-up spring·····		
A22		M90204060		· Thread tension releasing pinφ2x28.4······		
A23		MF02A0553		Thread tension stud·····		
A24		MF10A0555		Thread tension discs		
A25	•	MM11A0556		· Thread tension releasing discs·····		
A26		MG52A0245		· Thread tension spring·····		
A27		MT60A0802		· Thumb nut revolution stopper·····		
A28		M91605045		Thumb nut 1/4(40)		
A29		M90901002		Screw 9/64 (40) x4		
A30		M90625053		Spring washer for leg 6		
A31		MG33A0426		Leg····		
A32		MG43A1181	<u> </u>	Thread guide·····	1	
A33		M90604002		Screw 3/32(56) x2. 2		
A34		MF10A0471		· Spring for slide plate·····		
A35				· Slide plate ·····		
A36		MF26B0101	ハリイタ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Needle plate (B2.6) · · · · · · · · · · · · · · · · · · ·	1	
A37		M91102011		Screw 11/64 (40) x8.5		
A38		M91182080		Rubber plug ϕ 11.8		
A39		M91106003		Screw 11/64(40)x20		
A40		MG35A1830		· Face plate·····		
A41		M90901080		Rubber plug ϕ 9.6		
A901	•	MF00E0550		Pre-tension assy. · · · · · · · · · · · · · · · · · · ·		
A902		MG34E0210		· Thread tension regulator complete		
A903		MG75E0470		Slide plate complete		



B 縫機構(I)

SEWING MECHANISM (I)


Fig.		部品コード	+ 0 - 5	December 1	使用数
No.	Mod	Parts. No.	部品名	Description	Amt. Reg ⊢
350		MF60A0742	76	·· Cap for needle bar bushing(upper)·····	- B1T
351		MF10A2740	77"	• Felt for needle bar bushing (upper) • • • • • • • • • • • • • • • • • • •	1
352		MF60A0663	ハロキ。 ロイヤルロエ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	•• Needle bar bushing (upper) •••••••	1
353			ハリホ・ブァダル・ノエ・・・・・・・・・	Needle par busning (upper) · · · · · · · · · · · · · · · · · · ·	1
354		MG50A0660		·· Needle bar ·····	
		MF20A0664		· Needle bar bushing (under) · · · · · · · · · · · · · · · · · · ·	
355		MG42A0181		· Tread guide for needle bar · · · · · · · · · · · · · · · · · · ·	
356		M90815002		·· Screw 1/8 (44) x4. 5····	
357		MG37A0128		· Needle DPX17#22 · · · · · · · · · · · · · · · · · ·	
358		M91513001		·· Set screw 15/64(28)x10·····	
359		M91106004		·· Screw 11/64(40)x8·····	
360		MF30A0325		·· Square block·····	
361		MG44E0662		·· Needle bar connecting link guide assy. · · · · ·	
362		M91606001		·· Set screw 1/4(40)x6·····	
363		MF60A1383		·· Crank assy. ·····	
364		M91802006		· Screw 9/32(28)x14·····	
366		MF60A0232		·· Bushing for arm shaft(left)·····	
367		MV88A0740		·· Felt·····	•
868		MG50A0740		·· Felt·····	
369		MF80A0352	カラークミタテ・・・・・・・・・・	·· Collar for arm shaft assy ······	1
370		M91602001		· Set screw 1/4(40) x4·····	
371		MG36A0230		· · Arm shaft · · · · · · · · · · · · · · · · · · ·	
372		M90320065		·· C-type stop ling 20·····	
373		MG33A0384		·· Crank rod assy ·····	
374		MF30E0280		· · Upper feed lifting cam·····	
375		M91506001		·· Set screw 15/64(28)x7·····	
376		MG34A0325		·· Square block····································	
377		MF60A1740		·· Felt·····	
378		MF60A0700		· Spring for feed cam·····	
379		MF60A2740		·· Felt·····	
80		MG33A0233		· · Bushing for arm shaft(right)·····	
81		M91610001		· Set screw 1/4(40) x7·····	
82		MF40A0331		Bevel gear for arm shaft	
83		MF40A0333		Bevel gear for vertical shaft(upper)	
84		MQ70A0521		·· Vertical shaft bushing assy. · · · · · · · · · · · · · · · · · · ·	
85		MQ50A0148		··· Oil wick·····	
86		MF60A0740		···Felt ······	
87					2
89		MG50A0520		·· Vertical shaft·····	
		MF67B0522		· Vertical shaft bushing assy. · · · · · · · · · · · · · · · · · · ·	
90		MF10A0332		·· Bevel gear for vertical shaft(lower)······	
91		MF40A0332		·· Bevel gear for hook shaft·····	
904		MG40E0580		·· Thread take-up lever assy. ·····	
905		MF01E0331		·· Bevel gear for arm shaft·····	
906		MF01E0332		·· Bevel gear for arm shaft·····	
907		MG33E0760	ヘンシンリンクミタテ・・・・・・・	· Upper feed lifting cam·····	1



C 縫機構(Ⅱ) および下送り機構


SEWING MECHANISM (II) & FEED ROCK LOWER SHAFT MECHANISM

Fig.		部品コード				使用数
No.	Mod	Parts. No.	部品	名	Description	Amt. Reg.
						B1T
C100		MG30A0278			Feed rock shaft crank(left)assy	1
C101		M91203002			Screw 3/16(28)x15·····	
C102		M91106004			Screw 11/64(40) x8·····	
C103		MG33A0283			Feed bar holder stud	
C104		M70535065	Eガタトメワ 5・・・・		E-type stop ring 5·····	1
C105		M90806002	ヒラネシ゛・・・・・・・		Screw1/8 (44) x6	2
C106		MF10A0104	オクリ・・・・・・・		Feed dog·····	1
C107		MG33A0281	オクリタ゛イ・・・・・・		Feed bar · · · · · · · · · · · · · · · · · · ·	1
C108		MG33A0285	オクリシ゛クメタル・・・・		Feed rock shaft bushing	4
C109		MG36A0284	オクリシ゛ク・・・・・・		Feed rock shaft	1
C110		M90904060	ピン・・・・・・		Pin	3
C111		M91603003			Screw 1/4(24)x16	
C112		MG35E0306	オクリクト゛ウウテ゛クミタ	·于······	Feed lifting & rock shaft crank assy	1
C113		M91516002	Łラネシ゛・・・・・・・		Screw 15/64(28) x8.5	2
C114		M91602001	トメネシ゛・・・・・・・		Set screw 1/4(40) x4	4
C115		MF80A0352			Collar for arm shaft assy	
C116		M91513001			Set screw 15/64(28) x10	
C117		M91502050	サ゛カ゛ネ・・・・・・		Washer ¢ 20.5	2
C118		M90315065	てか タトメワ ジ クヨウ	15	C-type stop ling 15·····	2
C119		MF60A0740	フェルト・・・・・・・		Felt····	1 .
C120		MG37B0452	シタシ゛クメタルミキ゛クミ	タテ・・・・・・	Rotating hook shaft bushing(right)assy	1
C121		M91110001			Set screw 11/64(40) x8.5	
C122		MF30A0352	カラークミタテ・・・・・		Thrust collar	1
C123		M91503001			Set screw 15/64(28) x4.5	
C124		MG36A0450	シタシ゛ク・・・・・・		Rotating hook shaft	1
C125		MF00A0453			Lower shaft bushing (middle) · · · · · · · · · · · · · · · · · · ·	
C126		MF00A0350			Thread trimmer cam assy	
C127		M91602020			Soket set screw 1/4(40)x10	
C128		MG50A0451			Rotating hook shaft bushing(left)	
C129		MG30A0700			Spring·····	
C130		M90801006	ヒラネシ゛ホ゛ウサキ・・・		Screw M3x0. 35x9. 5	1
C132		MG75A0120			Rotating hook complate	
C133		MF20A0229			Rotating hook positioner · · · · · · · · · · · · · · · · · · ·	
C134		M91118002			Screw 11/64 (40) x10 · · · · · · · · · · · · · · · · · · ·	
C135		MF25B0123	ボビン・・・・・		Bobbin····	1
C136		MF70E0276			Feed lifting rock shaft crank(left)assy	
C137		M91112002			Screw 11/64(40) x12	
C138		MG36A1284			Feed lifting rock shaft	
C139		M91204003			Screw 3/16(28) x12	
C140		MF70A0277			Feed lifting rock shaft crank(right)assy	
C908		MF25E1125			Bobbin case complate	



D 送り調節機構 STITCH LENGTH MECHANISM

Fig.	変更	部品コード			使用数
No.	Mod	Parts. No.	部 品 名	Description	Amt. Reg.
					B1T
D150		MG33A0744	フタマタロツト゛・・・・・・・・・	· Feed forked connecting rod·····	
D151		M90720063		· Set pin·····	
D152		MG33A0761	^>>>> f	· Eccentric pin·····	1
D153		MG33A0910	リンク・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Link····	1
D154		M91516002	ヒラネシ゛・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Screw 15/64(28) x8.5	3
D155		MG33A0530	ダンツキジク・・・・・・	· Set pin·····	1
D156		MF00A1910	リンク・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Link · · · · · · · · · · · · · · · · · · ·	1
D157	-	M70534065	En 9 5 4	E-type stop ring 4·····	1
D158		M90534060		Pin ¢5.5	
D159		M91502002	ヒラネシ゛・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Set screw 15/64(28)x12	1
D160		MG34A0291	オクリチョウセツカム・・・・・・・	· Feed regulator·····	1
D161		MF40A2708	ስ ታስ ፞ ネ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Spring holder·····	1
D162		M91110002	ヒラネシ゛・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Screw 11/64(40)x8	2
D163		MG50A0572	ツルマキハ゛ネ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Spring·····	1
D164		MN15A0708	ከ ታስ [*]	· Spring holder·····	1
D165		M91106004	プ ラマイネジ・・・・・・・・・・・	Screw 11/64(40)x8	2
D166		MG34A0708	ハ゛ネカケイタ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Spring holder·····	1
D167		MF10A0572	ツルマキハ゛ネ・・・・・・・・・	Spring	1.
D168		M91501007	マルヒラネシ゛ホ゛ウサキ・・・・・・・	Screw 15/64(28) x14.5	1
D169		MF60A0634		· Stitch length regulator · · · · · · · · · · · · · · · · · · ·	
D170		MG34A0530	ダンツキジク・・・・・・	· Set pin·····	1
D171		MF60A0633	ヌイメカケ゛ンシ゛ク・・・・・・・・	Reverse stitch lever shaft	1
D172		M95003053	バネザガネ・・・・・・・・	· Spring washer·····	1
D173		MF30A0632	ヌイメカケ゛ンレハ゛ー・・・・・・・	· Reverse swing lever·····	. 1
D174		M91515002	ヒラネシ゛・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Screw 15/64(28)x10	2
D175		M91207003	マルヒラネシ゛・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	- Screw 3/16(28) x6.5	. 1
D176		MF05A0572	ツルマキバネ・・・・・・・・・	· Spring·····	. 1
D177		MF06A0852		· Stopper pin·····	
D178		M91000085		· O-ring ¢10 1AP10A·····	
D179		MF85A0640	オクリチョウセツネシ゛・・・・・・・	· Stitch length regulator screw·····	• 1
D180		MF02A0245	エンスイバ・ネ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Coil spring·····	· 1
D181		MF06A0950	νν˙	· Releasing lever·····	• 1
D183		MF06A1631		· Dial for stitch length regulator·····	
D184		MG75A0841	メモリイタ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Stitch length indicating plate·····	• 1
D185		MF00A0257	オサエカ゛ネ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	- Bushing	- 1
D187		M71216002	ヒラネシ゛・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	- Screw 3/16(28)x18	• 1
D909		MG34E0640	オクリチョウセツネシ゛クミタテ・・・・・	· Screw bar assy. · · · · · · · · · · · · · · · · · · ·	. 1



E 上部水平送り機構 UPPER FEED ROCK SHAFT MECHANISM


Fig.	変更	部品コード			使用数
No.	Mod	Parts. No.	部 品 名	Description	Amt. Reg.
					811
E190		M90401061	テーパピン・・・・・	Taper pin·····	<u></u>
E191		MV88A0740		Felt	
E192		M91620045		Nut 1/4 (40) · · · · · · · · · · · · · · · · · · ·	
E193		MG33A0602		Feed arm·····	
E194		M90304053		Spring washer 3.5	
E195		M90910003		Screw 9/64 (40) x7·····	
E196		M91615015	ヒラネシ゛タ゛ンツキ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Hinged screw 1/4(40)x12	1
E197		MG30A0910	レンセツカン・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Walking foot connecting link	. 1
E198		M91601036		Screw ·····	
E199		MG30A0530	ダンツキジク・・・・・・・	Hinged pin·····	1
E200		M91506001		Set screw 15/64(28)x7	
E201		MG33A0950		Feed connecting lever·····	
E202		M90601050		Washer 6·····	
E203		M91604045		Nut 1/4(24) · · · · · · · · · · · · · · · · · · ·	
E204		MG30B0464		Feed griving rock shaft crank(left)	
E205		M91108001		Set screw 11/64(40)x5.5	
E206		MG50A1740		Felt····	
E207		MG33A1285		Feed driving shaft bushing	
E208		MG30E0410		Feed connecting slick block complete	
E209		MG36A0467		Feed driving shaft (upper) · · · · · · · · · · · · · · · · · · ·	
E210		M91603003		Screw 1/4(24)x16·····	
E211		MG30E0465		Feed driving rock shaft crank (right) assy	
E212		MG30B0954		Feed driving connecting link	
E213		M91803015		Hinged screw 9/32(28)x26.1	
E214		M91802045		Nut 9/32 (28) · · · · · · · · · · · · · · · · · · ·	
E910		MG36E0467	シ゛ヨウフ゛スイヘイオクリシ゛ ククミタテ・・	Feed driving shaft complete	1

(251)

F 上部上下送り機構 UPPER FEED LIFTING ROCK SHAFT MECHANISM


Fig.	変更	部品コード	*		使用数
No.	Mod	Parts. No.	部 品 名	Description	Amt. Reg.
					811
F220		MG33A0462	シ゛ヨウフ゛シ゛ヨウケ゛ウテ゛ヒ々゛リ・・・・	Upper feed lifting rock shaft crank	
F221		M90207061		Taper pin 4X20····································	
F222		MG30A0460		Feed lifting rock shaft	
F223		M91108001		Set screw 11/64 (40) X5. 5	
F224		MG33A0833		Feed lifting rock shaft bushing	
F225		MG30A0463		Feed lifting rock shaft crank(right)assy	
F226		M91603003		Screw 1/4(24) X16	
F227		M91572045		U-nut 6x0.75······	
F228		M90601050		Washer 6·····	
F229		M91551015		Hinged screw M6X24·····	
F230		MF60A0700		Spring for felt stopper·····	
F231		MG30B0740		Felt	
F232		M90325065		C-type stop ring 25·····	
F233		MG30A0760		Feed lifting eccentric	
F234		M91606001		Set screw 1/4 (40) x6	
F235		MG33A0956		Feed connecting crank rod······	
F236		M90301064		Spring pin 3X8·····	
F237		M91106004		Screw 11/64 (40) X8 · · · · · · · · · · · · · · · · · ·	
F238		MG33A0765		Bell crank guide bracket·····	
F239		MG10B0411		Bell crank guide bracket block······	
F240		M90507063		Bell crank guide pin·····	
F241		M91210002		Screw 3/16(28) X10	
F242		M91681015		Hinged screw 1/4(40) X12	
F243		MG10B0910		Feed lifting rock shaft link	
F244		MG10B0763		Bell crank	
F245		M91801035		Feed regulating screw 9/32(28)X31·····	
F246		M91802045	ナット・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Nut 9/32 (28) · · · · · · · · · · · · · · · · · · ·	1
F247		MG33A1261	オサエチヨウセツタ゛イ・・・・・・・・	Presser regulating bracket	1 -
F248		MG33A1572	ツルマキハ゛ネ・・・・・・・・・・・	Spring	1
F249		MG33A0154	アンナイカ゛ネクミタテ・・・・・・・・・	Spring guide bar complete	1
F250		MG33A2361	ハ゛ネカケカ゛ネ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Spring holder	1
F251		M90922002	ヒラネシ゛・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Screw 9/64(40) X8	. 3
F252		M93009050		Washer····	
F253		M91112002		Screw 11/64(40)X12·····	
F254		MG30A0296		Walking foot guide bracket	
F255		MG10B0294		Walking foot	
F256		MG33A0295		Walking foot guide link	
F911		MG33E0460	ワェ クミタテ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Feed lifting rock shaft complete	· 1

13 LY2-3319 H



H 糸切り機構 KNIFE ACTUATING MECHANISM


Fig.		部品コード	±17 🗆 🗗	Description	使用数
No.	Mod	Parts. No.	部 品 名	Description	Amt. Reg
H300		MF00A1391	<i>ካ</i> ኑ	· Thread trimmer driving lever·····	1
H301		MF06A1361	カケカ゛ネ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Flexible wire holder	i
1302		M71144015	・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Stud screw 11/64 (40) x5	1
1303		MF36A0750	フ゛ツシュ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Flexible wire presser · · · · · · · · · · · · · · · · · · ·	1
H304		M90802002	とうネシ゛・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Screw 1/8 (44) x7	2
H305		M97082030	トクシュネシ゛・・・・・・・・・・・・・・	Stud screw 15/64(28)x7.5	1
1306		MF00A1729	ヒネリハ゛ネ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Trimming lever spring·····	1
H307		MF00A1352	カラー・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Spring support collar·····	1
H308		M90903002	ピフネン・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Screw 9/64 (40) x6. 5	2
H309 H310		M91118002 M91502045	十四ト・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Screw 11/64(40)x10···································	2
1310 1311		M94008037) / PHラネジ M/v6・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Screw M4x6	3
1312		MF00A1509		Solenoid bracket·····	
1313		-	\p\/\f\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	· Solenoid······	· i
1314		M90703065		E-type stop ring 12·····	
1315		MF01A0397	クツション・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Cushion	. 1
1 316		MF06A0397	クッション・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Cushion·····	1
1 317		M70516050	サ゛カ゛ネ・・・・・・・・・・・・・・	· Washer · · · · · · · · · · · · · · · · · · ·	. 1
1 318		M92074075	ナット M5・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Nut M5····	. 2
1319		M70428060	ٰ >	· Link stud·····	1
1320		M70534065	Eガ タトメワ 4・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	E-type stop ring 4·····	. 2
1321		M91106004	_ プラマイネジ・・・・・・・・・・・・	Screw 11/64(40) x8	. 2
1322		MF06A0780		Holder	
1323		M91373045	プリト M5・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	• Nut M5x4T • • • • • • • • • • • • • • • • • • •	2
1324 1325		MF06A1620 M91106004	1711/N 21 OND-IM	Screw 11/64(40)X8	· 1
1325 1326		MG46E0746	フレセシコ~ルロノヤカミカテ・・・・・・	Flexible wire assy.	1
1327		M91109004	サ゛カ゛ カッキフ゜ ラフノスシ゛・・・・・・	Screw 11/64(40) x8	. 1
1328		M94003099		· Cord holder······	
1329		M91510002	上ラネシ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Screw 15/64(28) x12·····	. 4
1330		M91004080	ゴ゛ムフ゛ッシュ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Rubber plug ϕ 10 · · · · · · · · · · · · · · · · · ·	. j
1331		M91110045	ナット・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	• Nut 9/64(40) • • • • • • • • • • • • • • • • • • •	· 1
1332		M90913001	トメネシ゛・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	- Set screw 9/64(40)x8.5	• 1
1333		MF00A1603	トリツケタ゛イ・・・・・・・・・・	· Bracket for fixed blade·····	• 1
1334		MF00A0180	<u> イトアンナイ・・・・・・・・・・・・・・・・・・・・・・</u>	· Thread finger····	• 1
1335		M90921002	ヒラネシ゛・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Screw 9/64(40) x8·····	• 1
1336		MG52A0838		Fixed blade	
1337		M91102010		Screw 9/64 (40) x4. 1	
H338		M91151010		Screw 11/64(40)x7····································	
1339 1340		MG52A0834 M94006052	# h +	Thrust collar ϕ 28	· 1
1341		M90803010	サーカン・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Screw 1/8(44)x6·····	3
1342		M91111015		Stud screw 11/64(40)x6.2·····	
1343		MF00A8910	- レンサン・ブ・シンコー リング・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Link·····	. 1
1344		MF00A1392		· Knife driving crank·····	
1345		M91117002	マルヒラネシ゛・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Screw 11/64(40)x13	- 1
1346		M91107045	ナット・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Nut 11/64(40) · · · · · · · · · · · · · · · · · · ·	· 2
1347		MF02A0836	メスタ゛イヒタ゛リ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Knife base (left)·····	• 1
348		MF00A1527	ቃ ˇ	· Knife holding bracket saddle····	· 1
349		MG46A0454	メスヨウト゛ウシ゛ク・・・・・・・・	Knife driving shaft	. 1
1350		M91201045		•• Nut 3/16(28) ••••••••••••••••••••••••••••••••••••	
1351		MF01E0411	コロ, コロン <i>りり</i> ミタナ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Cam follower, Shoulder screw assy.	. 2
352		M93003099	こ ンダーミナル (才人)・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Terminal pin(Male)	. 2
353 354		M71018050 M91516002		Rubber washerScrew 15/64(28)x8.5	
355		MF00A0750	レノケノ ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	·· Screw 15/64(28)x8.5····································	·
356		MF00A0730	ツルマキバ・ネ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Coil spring· · · · · · · · · · · · · · · · · · ·	. 1
357		M91606001	トメネジ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Set screw 1/4(40)X6·····	. 1
358		MF06A0477	ストツハ゜クミタテ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Stopper lever assy	. i
359		MF00A0729	上ネリハ ネ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Coil spring· · · · · · · · · · · · · · · · · · ·	·i
360		M91602001	- , , , , , , , , , , , , , , , , , , ,	• Set screw 1/4(40) x4 · · · · · · · · · · · · · · · · · ·	. i
361		MF01E1352	カラークミタテ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Thrust collar assy. · · · · · · · · · · · · · · · · · · ·	. 1
363		M91527001	トメネシ゛・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Set screw 15/64(28) X23·····	• 1
1364		MF00A1477	ストツハ゜イタ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Lever stopper plate · · · · · · · · · · · · · · · · · · ·	• 1
1365		M90401085	0 リンク 1AP4・・・・・・・・	·· 0-ring (1AP4) ·····	• 1
1366		MG46A0476	スペーサ・・・・・	Spacer	• 1
1912		MF06E3519	ソレノイト、トリッケイタクミタテ・・・・・	· Thread trimming solenoid·····	• 1
1913		MF06E0839 MG34E0351	メスタ゛イトリツケタ゛イクミタテ・・・・・	··Knife blaket assy. ···································	• 1
1914					. 1



J タッチバック機構および検出器機構

TOUCH BACK MECHANISM&DETECTOR MECHANISM

	変更 部品コート		.	使用数
No. I	Mod Parts.No.	部 品 名	Description	Amt. Reg
				B1T
J370	M91106004	 】 プラマイネジ・・・・・・・・・・	Screw 11/64(40)x8	9
J371	MG46A060		· Plate assy. · · · · · · · · · · · · · · · · · · ·	
J372	M9030803		· Screw M3X6·····	
J373	M91004080		Rubber plug ¢ 10·····	
J374	M9020103	/ ロー・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Screw 2X4·····	2
J374	M90315050		· Washer M2·····	
J374	M9030605		· Washer M2·····	
J375	MF00A019		· Plate spring·····	
J376	MG75A160		· Bracket for touch switch·····	
J377	MF00A027		· Push button· · · · · · · · · · · · · · · · · · ·	
J378	M7053306		· E-type stop ring 3·····	
J379	MF00A757		· Coil spring······	
J380	M9025103		· Screw M2X8····	
J381	M90208099		·· Micro switch·····	
J382	MF01A050		· Insulator seet·····	
J383	MF06A0620	、 マーノコウット・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Band····	1
J384	MG46A050		· Cord assy. · · · · · · · · · · · · · · · · · · ·	
J385	M9330309) 4° \ 1200Tl	·· Terminal pin·····	4
		7 [/ 13001[·· Connector cap······	4
J386	MG68A036			
J387	M91018099		··Nylon connector 12-pole····································	
J389	MG34E051			
J390	MF01A069		Gasket····	
J391	MG34A088		Arm side cover	
J393	M7053406		E-type stop ring 4·····	
J394	M70428060		· Link stud· · · · · · · · · · · · · · · · · · ·	
J395	M91109004		Screw 11/64 (40) X8 · · · · · · · · · · · · · · · · · ·	
J396	M94003099	3	Cord holder	3
J397	M91111004	↓ ノ フマイネシ ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Screw 11/64(40)X10	1
J398	M9700309	ウェイースセンクミダナ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Groung wire assy.	1
J399	MB60A1620) ナイロンクリツフ AB-8N・・・・・	· Cord holder · · · · · · · · · · · · · · · · · · ·	1
J400	M9151501		· Hinged screw · · · · · · · · · · · · · · · · · · ·	
J401	MN36A041		Rubber cushion	
J402	M9150200		·· Set screw 15/64(28)X12·····	
J403	MG34A068		··Pulley····	
J404	MF01A047		· Spacer A····	
J405	MF01A269	1 ハンシヤハ ン B12・・・・・・・・	Speed command disc B12 (down)	. 1
J406	MF01A169	1 ハンシヤハ ン B21・・・・・・・・	· Speed command disc B21(up)·····	. 1
J407	MF01A147		· Spacer B· · · · · · · · · · · · · · · · · · ·	
J408	MF01A025		· Supporter spring· · · · · · · · · · · · · · · · · · ·	
J409	M9300105		• Washer 30•••••	
J410	M9033006		· Retaining ring-C type 30·····	
J411	MF01A025		· Detector bracket supporter····	
J412	M9300205		·· Washer 12·····	
J915	MG46E053		·· Touch switch assy. ·····	
J916	MB60A240		·· Detector bracket assy. (sensor) ······	
J917	MG34E068	2 プリークミタテ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	· Pulley assy · · · · · · · · · · · · · · · · · ·	. 1




K 給油機構

OIL LUBRICATION MECHANISM

Fig.	変更	部品コード	I CATTON WEG	717717 314	使用数
No.	Mod	Parts. No.	部 品 名	Description	Amt. Reg.
					B11
K420		M90908003		Screw 9/64(40)x6	1
K421		MG33A0138	オイルタンク・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Oil reservoir·····	1
K422		MG33A0740		Felt····	
K423		MG33E0688		Oil pipe & wick complete	
K424		MF06A1620	コテイヨウハ゛ント゛SKB-1M・・・・・	Band SKB-1M·····	2
K425		M90357037		Screw 3x8·····	
K426		M91109004	ザガネツキプラマイネジ・・・・・・	Screw 11/64(40) x8	7
K427	•	MG33A0134	アフ゛ラフタミキ゛・・・・・・・・	Cap for oiler (right) · · · · · · · · · · · · · · · · · · ·	1
K428		MG33A1740		Felt····	
K429		MG33A2740	フェルト・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Felt····	1
K430		MF10E3148		Oil wick·····	
K431		MG33A1138	オイルタンクミキ゛・・・・・・・・・	Oil reservoir (right) · · · · · · · · · · · · · · · · · · ·	1
K432		M90573080	コ゛ムセン・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Rubber plug ϕ 5. 7······	2
K433		M90531037	P ナベネジ 5X14・・・・・・・	Screw M5x14·····	2
K434		MG33A0780	ホルタ゛・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Oil pipe holder·····	1
K435		M91106004	プ [°] ラマイネシ゛・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Screw 11/64(40) x8	1
K436		MG30A0740		Felt····	
K437		MN10A4742		Cap for oiler	
K438		MF10A2740		Felt····	
K439		MG33E0601	トリツケイタヒモクミタテ・・・・・・・	Oil braid fitting plate	. 1
K440		M90939002		Screw 9/64(40)x11	
K441		MG50A0688	パイプ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Oil pipe·····	1
K442		MG36A0731	n° イプ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Oil pipe·····	. 1
K443		M91103045		Nut 11/64(40) · · · · · · · · · · · · · · · · · · ·	
K444		MG42A1689		Pipe holder	
K445		M91104003		Screw 11/64(40)x12	
K446		MG36A0148		Oil wick·····	
K447		MG33A0688	パイプ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Oil pipe·····	· 1
K448	. ,	MG50A2740	フェルト・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Felt	· 1
K449		MG43A0689	センサ゛イクハ゛ネ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Pipe holder	1
K450		MG42A2691	ガ ス ケツト・・・・・	Gasket for oil reservoir·····	· 1
K451		MG50A0139		Oil reservoir cover	
K452		MG50A0257		Plate····	
K918		MG33E0711		Arm shaft bevel gear box complete	
K919		MG33E0712	ハク゛ルマハ゛コシタクミタテ・・・・・・	Hook shaft bevel gear box complete	. 1

21 LY2-3319



L 付属品関係 ACCESSORIES

Fig.	変更	部品コード	-		使用数
No.	Mod	Parts. No.	部品名	Description	${\rm Amt.}\ Reg.$
					B1T
L460		MG33E0128	ハリセット・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Needle set(DPX17#22)·····	
L461		MF25B0123	ボビン・・・・・・	Bobbin····	3
L462		MG33A0130	アブラビン・・・・・・	Oil pot·····	1
L463		MG33A0608	ト゛ライハ゛ー (ダ イ)・・・・・・・・	Screw driver (large) · · · · · · · · · · · · · · · · · · ·	1
L464		MF06A0608	ト゛ライハ゛ー(チュウ)・・・・・・・・	Screw driver (middle) · · · · · · · · · · · · · · · · · · ·	1
L465		MF06A1608	ド ライバー(ショウ)・・・・・・・・	Screw driver(small)	1
L466		MF01A0565	カクト゛チョウセイク゛・・・・・・・・	Speed command disc adjusting plate	1
L467	•	MG51A1419	ボウシンゴム・・・・・・・・	Vibration preventing rubber	2
L468		MG51A0419	ボウシンゴム・・・・・・・・	Vibration preventing rubber	2
L469		MF01E0418	チョウハ゛ンセット・・・・・・・・	Table hinge with rubber cushion	2
L470		MG33A0479		Spanner·····	
L471		MF02A0187	イトトリバ・ネ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Thread take-up spring	. 1
L472		MG33A0137	7ブラサシ 18・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Oil with oiler · · · · · · · · · · · · · · · · · · ·	1
L473		M91109004	ザガネツキプラマイネジ・・・・・・	Screw 11/64 (40) x8	6
L474		M91072004	SW-PWツキPナベネジ・・・・・・	Screw SW-PW M4X0.7X14·····	1
L475		M91508004		Screw 15/64(28) x8	
L476		M90401041	マルモクネシ゛・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Screw 4. 5x20 · · · · · · · · · · · · · · · · · · ·	4
L477		M70517050	ミカ゛キサ゛カ゛ネ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Washer 5·····	4
L478		MF08E0190	イトマキシカケ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Bobbin winder assy	1
L479		MF33E0193	イトタテタ゛イセット・・・・・・・・	Thread stand assy······	1
L480		MQ80A0375	クキ゛ N25・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Nail N25·····	10
L481		MG36E0131	アフ゛ラウケクミタテ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Oil reservoir assy	1
L482		M90412040	サラモクネシ゛ 4、5X25・・・・・・・	Screw 4. 5x25	4
L483	•	MG33A0734	ヒ゛ニールカハ゛ー・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	Vinyl cover·····	1
L920		MG33E0776	へ゛ルトカハ゛ーセツト・・・・・・・・	Belt cover assy	1
L921		MG36E0727	ヒサ゛アケ゛シカケセット・・・・・・・	Knee lifter assy	1

部品コード	ページ	Fig	部品コード	^° ->*	Fig	"十二品部	^° -ジ	Fig
Parts.No.	Page	No.	Parts. No.	Page	No.	Parts. No.	Page	No.
M70428060····	· · · · P17 · · · · ·	H319	M91004080····	· · · · P17 · · · ·	• Н330	M91506001····		
M70428060····	· · · · P19 · · · ·	J394	M91004080···	· · · · P19 · · · ·	· J373	M91506001····		
M70516050····	· · · · P17 · · · ·	H317	M91018099····	····P19····	· J387	M91506001····		
M70517050····	· · · · P23 · · · ·	L477	M91072004 · · ·	· · · · P23 · · · ·	· L474	M91508001····	P3	· A16
M70533065	P19	· J378	M91101046 · · ·	P3	- A09	M91508004····	⋯P23⋯⋯	· L475
M70534065	pg	D157	M91102010 · · ·	· · · · P17 · · · ·	• Н337	M91510002····	P17	· H329
M70534065····	P17	· H320	M91102011	P3	· A37	M91513001····	P5	- B58
M70534065····	· · · · P19 · · · ·	· J393	M91103045	· · · · P21 · · · ·	· K443	M91513001····	P7	· C116
M70535065			M91104003····	· · · · P15 · · · ·	· G288	M91515002····	P9	· D174
M71018050····			M91104003····	· · · · P21 · · · ·	· K445	M91515015····	P19	- J400
M71144015····			M91106003····	P3	· A39	M91516002····	P7	· C113
M71216002····			M91106004···			M91516002····	P9	· D154
M90201037····			M91106004···			M91516002····	· · · P17 · · · ·	· H354
M90204060 · · ·			M91106004···			M91527001	· · · P17 · · · ·	- H363
M90207061 · · ·			M91106004···			M91551015····	· · · P13 · · · ·	• F229
M90208099····			M91106004···			M91572045····		
M90251037····			M91106004			M91601036 · · · ·		
M90301064····			M91106004			M91602001 · · · ·		
M90304053····			M91106004			M91602001		
M90306053····			M91106004			M91602001		
M90308037···			M91106004			M91602020		
M90315050···			M91107002···			M91603003····		
M90315065···			M91107002			M91603003		
M90320065			M91107043			M91603003····		
			M91108001···			M91604045		
M90325065			M91108001···			M91605045···		
M90330065						M91606001 · · ·		
M90357037···			M91109002···			M91606001		
M90401041			M91109004 · · ·			M91606001···		
M90401061 · · ·			M91109004					
M90401085 · · ·			M91109004 · · ·			M91610001 · · ·		
M90402064···			M91109004···			M91615015··· M91620045···		
M90412040 · · ·			M91109004···			M91620045···		
M90421060···			M91110001					
M90507063···			M91110001			M91801035··· M91802006···		
M90531037···			M91110002···			M91802006		
M90534060···			M91110045					
M90573080···			M91111004···			M91802045		
M90601050···			M91111015			M91803015		
M90601050···			M91112002···			M92001016		
M90604002···			M91112002···			M92074075		
M90625053···			M91116002···	• =		M93001050···		
M90703065···			M91117002···			M93002050 · · ·		
M90704063···			M91118002···			M93003099···		
M90720063···			M91118002···			M93009050···		
M90801006···	= =		M91151010···			M93202047···		
M90802002···			M91182080···			M93223035		
M90803010···			M91201045···			M93303099···		
M90806002···	· · · · P7 · · · · ·	· C105	M91203002···			M94003099···		
M90815002···	· · · · P5 · · · · ·	· B56	M91204003···	· · · · P7 · · · ·	· C139	M94003099···		
M90901002···	P3	· A29	M91207003···	P9	· D175	M94006052···		
M90901080···	P3	· A41	M91210002···	· · · · P13 · · ·	· F241	M94008037···	· · · · P17 · · ·	·· H311
M90903002···	· · · · P17 · · · ·	· H308	M91223015···	· · · · P15 · · · ·	· G278	M95003053···	····P9····	· · D172
M90904060···			M91251045···	· · · · P15 · · ·	· G284	M97003095···	····P19···	· · J398
M90908003···			M91305080···			M97082030···	· · · · P17 · · ·	·· H305
M90909003···			M91373045···			MB60A1620···	· · · · P19 · · ·	· · J399
M90910003···			M91501007···			MB60A2406···		
M90913001 · · ·			M91502002···			MF00A0180 · · ·		
M90921002···			M91502002			MF00A0181 · · ·		
M90921002			M91502002			MF00A0192···		
M90922002 · · ·			M91502050···			MF00A0257 · · ·		
M90922002			M91503001 · · ·			MF00A0270 · · ·		
M91000085···			M91505016 · · ·			MF00A0350···	, , , ,	
IIIO 1000000	1 9	טווע	mo 1000010 **	110	4202	m 00/1000	1/	3120

"十二品部	へ゜ーシ゛	Fig	部品コード	^° -ジ	Fig	**品一人*	^° -ジ	Fig
Parts. No.	Page	No.	Parts. No.	Page	No.	Parts. No.	Page	No.
/F00A0453····			MF10A2740			MG30E1594····		
//F00A0729····			MF10E3148 · · · · ·			MG33A0130····		
1F00A0750····			MF20A0229 · · · · ·			MG33A0134····		
1F00A1352····	· · · P17 · · · ·	· H307	MF20A0664	· P5 · · · ·	· B54	MG33A0137	···P23····	· L47
F00A1391	· · · P17 · · · ·	- H300	MF25B0123 · · · · ·	· P7 · · · ·	· C135	MG33A0138		
F00A1392····	· · · P17 · · · ·	H344	MF25B0123 · · · · ·	·P23····	· L461	MG33A0154	· · · P13 · · · ·	· F24
F00A1477	· · · P17 · · · ·	· H364	MF25E1125	· P7 · · · ·	· C908	MG33A0221 · · · ·	· · P15 · · ·	· G27
F00A1509····	· · · P17 · · · ·	· H312	MF26B0101 · · · · ·	· P3 · · · ·	- A36	MG33A0233 · · · ·	P5	· B80
F00A1527····	P17	· H348	MF30A0325	. P5 · · · ·	- B60	MG33A0281 · · · ·	P7	· C10
F00A1603····			MF30A0352	. P7	· C122	MG33A0283		
₩F00A1729····	P17	· H306	MF30A0632	. pg	· D173	MG33A0285 · · · ·	P7	· C10
#F00A1910····			MF30E0280·····			MG33A0295 · · · ·		
1F00A7572····			MF33E0193·····			MG33A0384 · · · ·		
# 00A7372 #F00A8910 · · · ·			MF36A0245			MG33A0426 · · · ·		
F00A9572····			MF36A0750 · · · · ·			MG33A0462····		
F00F0550····			MF36A1180·····			MG33A0479		
MF01A0257····			MF40A0331 · · · · ·			MG33A0530 · · · ·	. •	
MF01A0259····			MF40A0332 · · · · ·			MG33A0571 · · · ·		
F01A0397····			MF40A0333			MG33A0602 · · · ·		
NF01A0476····			MF40A2708 · · · · ·			MG33A0608 · · · ·		
NF01A0502····			MF60A0232	. •		MG33A0688		
1F01A0565····			MF60A0252 · · · · ·			MG33A0729 · · · ·		
1F01A0691····	· · · P19 · · · ·	· J390	MF60A0262 · · · · ·	·P15····	· G267	MG33A0734 · · · ·	· · · P23 · · · ·	· L48
MF01A1476····	· · · P19 · · · ·	- J407	MF60A0633	· P9 · · · ·	- D171	MG33A0740 · · · ·	· · · P21 · · · ·	· K42
MF01A1694····	· · · P19 · · · ·	- J406	MF60A0634	· P9 · · · ·	· D169	MG33A0744 · · · ·	pg	· D15
F01A2694····	· · · P19 · · · ·	· J405	MF60A0663 · · · · ·	·P5····	- B52	MG33A0761 · · · ·	P9	· D15
1F01E0331····	· · · P5 · · · ·	- B905	MF60A0700 · · · · ·	. P5	- B78	MG33A0765	· · · P13 · · · ·	· F23
F01E0332····	P5	- B906	MF60A0700 · · · · ·	· P13····	· F230	MG33A0780····	· · · P21 · · · ·	· K43
1F01E0411 · · · ·	· · · P17 · · · ·	· H351	MF60A0740 · · · · ·			MG33A0833	· · · P13 · · · ·	· F22
NF01E0418 · · · ·	· · · P23 · · · ·	· L469	MF60A0740 · · · · ·	. P7	· C119	MG33A0873	P3	· A01
/F01E1352····			MF60A0742			MG33A0910 · · · ·		
//F02A0187····			MF60A1383 · · · · ·			MG33A0950 · · ·		
//F02A0187····			MF60A1740 · · · · ·			MG33A0956 · · · ·		
MF02A0245····			MF60A2740 · · · · ·			MG33A1138····		
//F02A0553····			MF67B0522·····			MG33A1261		
MF02A0836····			MF70A0277 · · · · ·	. •		MG33A1285····		
MF03A0584····	*.**		MF70E0276 · · · · ·		• • • • • •	MG33A1572····		
1F05A0572····			MF80A0352 · · · · ·			MG33A1740 · · · ·		
#F06A0397····			MF80A0352 · · · · ·			MG33A2361 · · · ·		
MF06A0477····			MF85A0640 · · · · ·			MG33A2740····		
1F06A0608····			MF90A0553			MG33E0128		
¶F06A0620····			MG10B0294 · · · · ·			MG33E0460····		
NF06A0780····	· · · · P17 · · · ·	· H322	MG10B0411 · · · · ·			MG33E0601 · · · ·	· · · P21 · · · ·	· · K43
/F06A0852····	· · · · P9 · · · · ·	· D177	MG10B0763	·P13····	· F244	MG33E0688	· · · P21 · · · ·	· · K42
MF06A0950····	P9	· D181	MG10B0910 · · · · ·	·P13····	· F243	MG33E0711 · · · ·	· · · P21 · · · ·	· · K91
1F06A1361····	· · · P17 · · · ·	· H301	MG30A0154	· P15····	· G276	MG33E0712····	· · · P21 · · · ·	· · K91
NF06A1608····	· · · P23 · · · ·	· L465	MG30A0278	· P7 · · · ·	· C100	MG33E0760····	P5	B90
1F06A1620····	P17	· H324	MG30A0296	·P13····	· F254	MG33E0776 · · · ·	· · · P23 · · · ·	· L92
F06A1620····			MG30A0460			MG34A0291 · · · ·		
#F06A1631····			MG30A0463			MG34A0325 · · · ·		
F06E0839			MG30A0530 · · · · ·			MG34A0530 · · · ·		
1F06E3519····			MG30A0601 · · · · ·			MG34A0682····		
NF08E0190····			MG30A0700 · · · · ·			MG34A0708 · · · ·		
NF10A0104····			MG30A0740 · · · · ·			MG34A0880 · · · ·		
MF10A0267····			MG30A0760 · · · · ·			MG34E0210 · · · ·		
MF10A0332····			MG30A0910····			MG34E0351 · · · ·		
//F10A0471····	P3	· A34	MG30B0464	·P11····	· E204	MG34E0519····	· · · P19 · · ·	· J38
MF10A0555····	Р3	· A24	MG30B0593	·P15····	· G285	MG34E0640 · · · ·	P9	· D90
MF10A0572····	Р9	· D167	MG30B0740	·P13····	· F231	MG34E0682	· · · P19 · · ·	· J91
WF10A0709···	Р3	· A20	MG30B0954	·P11····	· E212	MG35A1830····	P3	· A40
MF10A1555····			MG30E0410 · · · · ·			MG35E0306 · · · ·		
MF10A2740 · · ·	P5	- R51	MG30F0465	·P11····	· F211	MG36A0148	· · · P21 · · ·	· · K44
	hrany of	C IIDA	rior Sowing Mack	tion 0	CHAR	oly LLC - www.su	IDCOW (ann

部品コート	ページ	Fig	ずーに品席	へ゜ーシ゛	Fig	**************************************	^° −ジ	Fig
Parts. No.	Page	No.	Parts. No.	Page	No.	Parts No.	Page	No.
MG36A0230···								
MG36A0265								
MG36A0284···								
MG36A0450···								
MG36A0467···								
MG36A0725								
WG36A0731 · · ·								
MG36A1284··· MG36E0131···								
MG36E0467···								
MG36E0727···								
MG37A0128···								
MG37B0452···								
MG40E0580···								
MG41B0256 · · ·								
MG42A0181 · · ·	· · · · P5 · · · ·	· B55						
MG42A1689···	· · · · P21 · · · ·	· K444						
MG42A2691···	· · · · P21 · · · ·	· K450						
MG43A0181···	Р3	- A15						
MG43A0689···			3					
MG43A1181								
MG44E0662···								
MG46A0454···								
MG46A0476···								
MG46A0508								
MG46A0601 · · ·								
MG46E0534···								
MG46E0746 · · ·								
MG50A0139 · · ·								
MG50A0257 · · · MG50A0451 · · ·								
MG50A0431								
MG50A0572···								
MG50A0660 · · ·								
MG50A0688 · · ·								
MG50A0740 · · ·								
MG50A1740 · · ·								
MG50A2740···	P21	· · K448						
MG51A0419···								
MG51A1419···	P23	· · L467						
MG52A0245	P3	· A26						
MG52A0834···	· · · · P17 · · ·	•• Н339						
MG52A0838···	· · · · P17 · · ·	·· H336						
MG52E0256···								
MG68A0366								
MG75A0120···								
MG75A0841 · · ·								
MG75A1601 · · ·								
MG75E0470 · · ·								
MM11A0556								
MN10A4742 · · ·								
MN15A0708 · · ·								
MN30A0216 · · ·								
MN36A0417 · · ·								
MQ50A0148 · · ·								
MQ50A0181 · · ·								en de gelocidades. La compansión de la compa
MQ70A0521 · · ·								n en
MQ80A0375								
MT60A0802 · · ·								n in english. San nasawa sa
MV01A0259··· MV88A0740···								
MV88A0740···								
mv00AU/4U	FII	LIJI	 					

三菱電機株式会社

お問い合わせは下記へどうぞ

FAシステム事業本部 機器計画部 駆動機器グループ 〒100-8310 東京都千代田区丸の内 2-7-3 (東京ビル) 代表電話番号 (03)3218-6631 代表FAX番号 (03)3218-6823

MITSUBISHI ELECTRIC CORPORATION

FACTORY AUTOMATION SYSTEM GROUP

Tokyo 100-8310, Japan Fax: +81-3-3218-6821