


# C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.1/16




FOR C007J/C007JD/C858J/C858JD

★适用于UTP/CR/CX, UTQ/CR/CX, UTR/CR/CX, UTS/CR/CX车型


10/12/19

# C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.2/16



# C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.3/16

A  
B  
C  
D  
E



**USE FOR C007J**

**MJ37-A**

- SM511
- NM511
- MJ37
- SM432\*2


**USE FOR C007JD**

**MJ137-E**

- SM513
- NM511
- MJ137
- SM432\*2

1 FOR C007JD/C858JD/C007J/C858J 2 3 4 5 10/11/03

# C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.4/16





FOR C007JD/C858JD

☐ FOR H牌馬達 (HVP-20)

10/07/01


# C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.5/16



FOR C007J/C007JD/C858J/C858JD

10/07/01

# C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.6/16




FOR C007J/C007JD/C858J/C858JD

FOR H牌馬達 (HVP-20)

10/07/01

# C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.7/16



FOR C007JD/C858JD

FOR H牌馬達 (HVP-70)

FOR 台灣馬達

10/07/01

# C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.8/16


A

B

C

D

E





C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.9/16


A

B

C

D

E



□ TXXXXX-A

□ TXXXXX-A

1 FOR C007JD/C858JD


2 FOR H牌馬達 (HVP-70)

3 FOR 2牌馬達

10/07/01


C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.10/16

A  
B  
C  
D  
E



□ TXXXXX

# C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.11/16



# C007JD PARTS LIST

FOR

UTQ-J

GROUP

P.12/16

A


B

C

D


E

FOR LEFT SIDE




# C007JD PARTS LIST FOR UTP-J GROUP P.13/16

A  
B  
C  
D  
E





# C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.15/16




1 FOR F007JD/C007JD/F858JD/C858JD

3 FOR H牌馬達 (HVP-70)


5 10/07/01

# C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.16/16





# C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.1/11




FOR C007J/C007JD/ C858J/C858JD

★ 适用于UTP/CR/CX, UTQ/CR/CX, UTR/CR/CX, UTS/CR/CX车型

10/12/19

# C007JDPARTS LIST FOR UTR-J(UTS-J) GROUP P.2/11



1 FOR C007J/C007JD/C858J/C858JD

2 FOR H牌馬達  
 FOR P牌馬達

3 4 5 10/07/01


# C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.3/11

FOR UTR/WP/UTX

FOR UTS/UTY

A

UT776/WP19




UT218J



TO WIPER

UT226D  
WP22(WP)



B

\*SM630

\*CP112

UT534

TO UNDER TRIMMER

C

TO MAIN POWER

UT103E

TO SAFETY S.W

TO SYNCHRONIZER

D


TXXXXX

T999


TO PRESSER FOOT

E

UT230-E  
FOR CL USE



UT810-A1



1

2

3

4

5

FOR C007JD/C858JD/S007KD

FOR H牌馬達 (HVP-20)

\*USE FOR UTR

10/11/24

# C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.3/8

FOR UTR/WP/UTX

FOR UTS/UTY

UT763 /WP19

UT218J

UT226D  
 UT226P  
 WP22(WP)

TO WIPER

\*SM630

\*CP112



UT534

TO UNDER TRIMMER

TO PRESSER FOOT

UT230-E  
FOR CL USE

UT810-A1  
 UT810P-A



1 FOR C007JD/C858JD/S007KD  
 \*USE FOR UTR

3  FOR H牌馬達 (HVP-70)  
 FOR P牌馬達


10/11/24

# C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.4/11


FOR UTR/WP/UTX

FOR UTS/UTY

UT776 /WP19



UT218J



UT226D  
 UT226P  
 WP22(WP)

TO WIPER

\*SM630


\*CP112

UT534


TO UNDER TRIMMER

TO PRESSER FOOT

UT230-E  
FOR CL USE



UT810-A1  
 UT810P-A




1 FOR C007JD/C858JD/S007KD  
 \*USE FOR UTR

2  FOR H牌馬達 (HVP-70)  
 FOR P牌馬達

10/11/24

# C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.5/11

A  
B  
C  
D  
E



**USE FOR C007J**

**MJ37-A**

- SM511
- NM511
- MJ37
- SM432\*2

**USE FOR C007JD**

**MJ137-E**

- SM513
- NM511
- MJ137
- SM432\*2


1 2 3 4 5

FOR H牌馬達

\*USE FOR C007JD/C858JD


10/12/19

# C007JDPARTS LIST FOR UTR-J(UTS-J) GROUP P.6/11



# C007JD PARTS LIST FOR UTS—J GROUP P.7/11


A




B

UTS系列

C



D



E

1 2 3 4 5  
 FOR C007J/C007JD/F007J/F007JD/C858J/C858JD/F858J/F858JD 10/07/01



# C007JD PARTS LIST FOR UTR-J GROUP P.8/11


A

B

C

D

E



1

2

3

4

5

FOR C007J/C007JD/ C858J/C858JD

10/12/19

# C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.9/11


A

B

C

D

E




1 FOR F007JD/C007JD/F858JD/C858JD

2 FOR H牌馬達 (HVP-20)

3 4 5 10/12/19

# C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.10/11




1 FOR F007JD/C007JD/F858JD/C858JD

2 3 4 5  
 □ FOR H牌馬達 (HVP-70)

10/12/19

# C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.11/11



1 FOR F007JD/C007JD/F858JD/C858JD

2 3 FOR P牌馬達

4 5 10/12/19