


# F007JD PARTS LIST FOR UTG(UTH) GROUP P.1/12




UT302-A  
 ☆UT302D-A

FOR F007J/F007JD/ F858J/F858JD

☆USE FOR F007J/F858J/F007JD/F858JD


10/07/01

# F007JD PARTS LIST FOR UTG(UTH) GROUP P.2/12







# F007JD PARTS LIST FOR UTG(UTH) GROUP P.3/12



USE FOR F007J



USE FOR F007JD




FOR F007J/F007JD/F858J/F858JD

\* USE FOR F007JD/F858JD

□ FOR H牌馬達  
○ FOR P牌馬達

10/11/03

# F007JD PARTS LIST FOR UTG(UTH) GROUP P.4/12





# F007JD PARTS LIST FOR UTG(UTH) GROUP P.5/12


A

B

C

D

E



□ TXXXXX-A

□ TXXXXX-A

1 FOR F007JD/F858JD

2 FOR H牌馬達 (HVP-70)

3 FOR 2牌馬達

10/07/01

F007JD PARTS LIST FOR UTG(UTH) GROUP P.6/12


A

B

C

D

E



□TXXXXX

1 FOR F007JD/F858JD

2 □ FOR H牌馬達 (HVP-20)


4

5

10/07/01



# F007JD PARTS LIST FOR UTG(UTH) GROUP P.7/12



F007JD PARTS LIST FOR UTH-J GROUP P.8/12

A


B

C

D


E

FOR LEFT SIDE





# F007JD PARTS LIST FOR UTG-J GROUP P.9/12



# F007JDPARTS LIST FOR UTG(UTH) GROUP P.10/12


A

B

C

D

E




FOR F007JD/C007JD/F858JD/C858JD

FOR H牌馬達 (HVP-20)


10/07/01



# F007JD PARTS LIST FOR UTG(UTH) GROUP P.11/12




# F007JDPARTS LIST FOR UTG(UTH) GROUP P.12/12






# F007JD PARTS LIST FOR UTJ-J(UTK-J) GROUP P.1/12




# F007JD PARTS LIST FOR UTJ-J(UTK-J) GROUP P.2/12





# F007JD PARTS LIST FOR UTJ-J(UTK-J) GROUP P.3/12



1 FOR F007J/F007JD/F858J/F858JD

2 FOR H牌馬達  
3 FOR P牌馬達

4

5

10/07/01

# F007JD PARTS LIST FOR UTJ(UTK) GROUP P.4/12


A

B

C

D

E



FOR F007J/F007JD/F858J/F858JD  
 \*USE FOR F007JD/F858JD

FOR H牌馬達 10/11/03



# F007JD PARTS LIST FOR UTJ(UTK) GROUP P.5/12


A

B

C

D

E



1 FOR F007JD/F858JD  
 2 \*USE FOR UTJ

3  FOR H牌馬達 (HVP-70)  
 FOR P牌馬達

4 5 10/11/25

# F007JD PARTS LIST FOR UTJ(UTK) GROUP P.6/12



A

B

C

D

E




1 FOR F007JD/F858JD  
\*USE FOR UTJ

2 FOR H牌馬達 (HVP-20)  
3 FOR P牌馬達

10/11/25




# F007JD PARTS LIST FOR UTJ-J(UTK-J) GROUP P.7/12



# F007JD PARTS LIST FOR UTJ-J(UTK-J) GROUP P.8/12

A

B




C

D

E

UTK/UTS 系列

UT218J-A1



FOR C007J/C007JD/F007J/F007JD/C858J/C858JD/F858J/F858JD

10/07/01

From the library of: Superior Sewing Machine & Supply LLC



# F007JD PARTS LIST FOR UTJ-J(UTK-J)GROUP P.9/12

A

B

C

D

E

MA04J

UT753-A

UT750

SM4802

WK21  
NM440

SM411

UT752

SM135

WK09

UT756

SM471

UT755

UT757

NM300

UT754

UT753

UT758

SM036

SM031

UT759

UT763

UT232

SM432

UT751

WM400

WV05

WM110

SM135

SM035

UT762

UT761

UT760

SM035

SM001

UT763-A=UT753-A+UT763+UT232+NM300+SM411

# F007JD PARTS LIST FOR UTJ-J(UTK-J) GROUP P.10/12


A

B

C


D

E





# F007JD PARTS LIST FOR UTJ-J(UTK-J) GROUP P.11/12



1 FOR F007JD/C007JD/F858JD/C858JD

3 FOR H牌馬達 (HVP-70)

5 10/07/01

# F007JD PARTS LIST FOR UTJ-J(UTK-J) GROUP P.12/12

