

Outdoor Screens Drape Skirt


120" - 145" Models | User's Guide

Model Number	Length x Height	Compatible Outdoor Screen Products
ZOMS2PL-DK	176.7"x60"	Portable Fast-Folding Screen: 120" – 145" models

^{***} Drape skirt for this model may be longer than the height of the screen

Parts List

Please make sure all parts listed below are included before installation.



Setup Instructions

- 1. Place all plastic clips on the bottom side of the frame, over the screen material. (do not pleat the material)
- 2. Place 4 clips to face the opposite direction as shown here. (2 on each end)



3. Attach the skirt on to the Velcro starting in the middle of the frame and then to the outer edges.



4. Attach any excess material to the clips that are facing the opposite direction. (back of the frame)



5. Reverse steps to dismantle the skirt for storing. Note: Direct sunlight and high temperatures may cause for the adhesive of the Velcro to dissolve. Store the skirt and clips in a cool, dry area.





For more information or technical support,

please visit www.akiascreens.com