Xplova EH-02 Quick Start Manual

Operation




Up Key: change assist level to high
Down Key: change assist level to low
Function Key: change types of distance
USB Port: charging and diagnostic port

Key functions

Key	Action	
	Press	Long Press
Up Key	Assist Level Up	
Down Key	Assist Level Down	Walk Mode
Function Key	ODO/DST/RNG	Power On/Off

Up + Function Key: Press for 10 seconds to reset DST (trip distance)

Information



- ① **Speed**: speed value, unit can be metric (km/h) or imperial (mph), unit of measurement is predefined by manufacturer
- ② **Assist Level**: maximum to⁵, 0 means no assist power mode, maximum assist level depends on motor support
- 3 Odometer: total distance a bike has been ridden
- **④ Trip distance**: current trip distance, will be reset to zero when the bike is powered off
- ⑤ Remaining distance : an estimated distance can be rode with the current battery capacity. The function will be disable if the battery doesn't support this function
- 6 Walk mode : walk mode is enabled

- 8 Bluetooth : Bluetooth is connected
- (9) Battery status: the battery state of charge(10) Value of distance: value of distance, unit is

kilometer or mile

Specification

Diamless Conson	1 41" TN LCD/ LED be aldiabt
Display Screen	1.41" TN LCD w/ LED backlight
Operating temperature	-20°C~ 45°C
Product dimensions	60 x 43 x 51 mm
Water Rating	IP65
Physical Interface	CAN
Wireless Interface	Bluetooth Smart
Power Input	DC 24V/36V/48V
Charging Output	5V/500mA(USB Port)

Declaration

The user manual is for reference only. If any differences between this user manual and the device, please subject to device. We reserve the right to make changes or additions to improve our products without obligation to make prior notice to any person or organization. All rights reserved by Xplova Inc.

Manufacturer: Xplova Inc.

Address: 6F., No. 68, Ruiguang Rd., Neihu Dist., Taipei

City 114, Taiwan

Website: www.xplova.com

