



NOTES:

- ① ALTERNATE RETURN AIR (INTAKE) - LEFT END
- ② ALTERNATE COLD AIR (EXHAUST) - FRONT. THE FRONT GRILL MUST BE REMOVED IF USING THIS VENT OPTION. REPLACE ALL SCREWS AFTER REMOVING GRILL.
- ③ ALTERNATE FRESH AIR (INTAKE) - RIGHT END
- ④ ALTERNATE HOT AIR (EXHAUST) - TOP REAR
- ⑤ ALTERNATE HOT AIR (EXHAUST) - BACK CENTER
- ⑥ TWO MOUNTING BRACKETS SHIP LOOSE WITH UNIT. UNIT HAS MOUNTING BRACKET HOLES FOR INSIDE CELLAR OR ABOVE CELLAR MOUNTING. REFER TO THROUGH CEILING MOUNTING DIAGRAM FOR OTHER MOUNTING OPTIONS.

1800H OVERALL DIMENSIONS AND AIR VENT LOCATIONS

2127B_R03