


# Configuration Options 3200VS / 4200VS


### 1. Wall Mount

# COLD AIR (Exhaust) RETURN AIR (Intake) WINE CELLAR CONDITIONED SPACE or EXTERIOR (VSx Only)


### 2. Front Ducted



# 3. Rear Ducted (VSi Only)



# 4. Front & Rear Ducted (VSi Only)



<sup>\*</sup> Venting to the exterior may require the addition of compressor heater (temps below 40°F) and fan cycling switch (temps below 20°F).