


CE

# HeatMe™ BH

## Bruksanvisning

Norwegian & English



**HEATME™**



# Innhold



## Content

---

Norsk	4
English	13

# Oversikt



## Inkluderte produkter



## Koble til

Koble til en fulladet powerbank til USB-C koblingen.

Legg powerbanken ned i lommen, og knapp igjen.





## Skru på.

Press på knappen. Hold i 2 sekunder.  
Indikatoren vil blinke 3 gange.

## Velg varmegrad.


Press på-knappen til du får ønsket varmegrad.



Nivå	Temperatur	Indikator	Varighet
1	50 °C		3,5 t
2	45 °C		4 t
3	40 °C		4,5 t

## Skru av.

Hold knappen inne  
i 2 sekunder for å skru av.



## Advarsel!

Viktig informasjon



- Ikke la barn leke med BH'en.
- Alle komponenter skal resirkuleres i samsvar med lokale lover og forskrifter.
- Bør ikke brukes av personer som ikke kan føle endringer av temperatur i huden.
- Følg vaske anvisningen til BH'en nøye.
- Ikke bruk skadet/deformert BH. Garantien dekker ikke selvforskyldte skade på produktet.
- Oppbevar ikke BH'en i direkte sollys.
- La BH'en tørke helt etter vask. Ikke skru på fuktig BH.
- La BH'en selvtørke. Ikke bruk tørketrommel!
- Bruk bare BH'en som brystholder ikke bruk BH'en som annen varme kilde.




Sorteres som elektrisk avfall

CE



# HeatMe™ BRA

## User Guide



# Overview

## Included items







# Connect

Connect the fully charged power bank to the USB-C connector.

Put the power bank in the pocket, and close the button.








## Turn on.

Press the button. Hold for 2 seconds.  
The indicator will flash 3 times.

## Select heat level.


Press the button until you  
get desired heat level.



Level	Temperature	Indicator	Duration
1	50 °C		3,5 hours
2	45 °C		4 hours
3	40 °C		4,5 hours

## Turn off.

Press the button  
for 2 seconds to turn off.



## Warning!

Important information



- Do not let children play with the bra.
- All components must be recycled in accordance with local laws and regulations.
- Should not be used by users who cannot feel changes in temperature on the skin.
- Follow the washing instructions for the bra carefully.
- Do not wear a damaged/deformed bra.
- The warranty does not cover self-inflicted damage to the product.
- Do not store the bra in direct sunlight.
- Leave the bra to dry completely after washing, do not turn on a damp bra.
- Only let the bra air dry. Do not tumble dry!
- Only use the bra as a brassiere, do not use the bra as another heat source.



Sort as electrical waste.



| HeatMe™, Kalvahagen 2, 4355 Kverneland, Norway |  
| E-mail: [lisa@heatme.no](mailto:lisa@heatme.no) | Web: [www.heatme.no](http://www.heatme.no) |