


Remove the screws to remove the back cover and top cover.
















Use the Aluminum foil paper to stick the NTC head onto the aluminum back wall.







Push the corner of the Temp control board as shown and remove the Temp control board.



