

Ichi One Pole Tent (L)

T8-200TN (Tan) T8-200-BK (Black)

https://dodoutdoors.com/

Be Outdoors Together.



Thank you for purchasing the Ichi One Pole Tent (L). For your safety, please read over all instructions before use. Keep this manual in a safe place for future reference.

Please use the Ichi One Pole Tent (L) for its intended use. To avoid harm to users, or damage to the tent, please follow all safety guidelines and adhere to precautions described below.

WARNING Failure to follow guidelines and warnings may result in death or serious injury.	
Do not use near fire (inside or outside). Beware of open flame near the tent. This can cause carbon monoxide to build up inside the tent. Keep all fire away from the tent.	Properly ventilate the tent. Too much condensation build up can cause ventilation issues. In rare cases, this can lead to oxygen deficiency resulting in death.
 Set up in places where tent camping is permitted. The tent should not be set up in places known for flooding. Make sure the tent is placed on solid, flat ground, with proper drainage. Make sure to avoid areas where trees, branches, or other objects may fall on your tent. 	Do not set up during dangerous weather conditions. In extreme weather conditions, even if the tent and tarp are secure, they can be crushed or blown away. If this happens repeatedly, please wait for weather conditions to subside.
If any part of this product is found to be defective please discontinue use immediately. Using a defective product may result in an unexpected accident or injury.	Parental supervision is strongly advised when small children use the tent. Assembly is not intended for small children. While the sun is out, the inside temperature of the tent may become excessive. This can be extremely dangerous as high temperatures may result in heat stroke.

Clear all stones, twigs, and

The following may cause damage to the product, or injury to the user.

- Clear all stones, twigs, and other sharp objects from the level ground before proceeding with set-up.
- O Failure to do so may cause damage to the tent.

NOTE


- The tent should be firmly fixed to the ground by use of a stake or rope.
- $\ \bigcirc$ Any slack in the material will cause rainwater to build up and pool.

- To prevent pinching your fingers, it is recommended to wear gloves while assembling, installing, disassembling, or removing any parts of this product.
- O Please be careful as moving parts may cause pinching to your fingers.
- Do not apply excessive force to the product when assembling or disassembling.
- $\ \bigcirc$ This can not only cause damage to the parts, but also potential injury may occur.

CONTENTS:

*Please be sure to check quantities of each part.

Tent body:



Additional accessories:







- 1 Grommet
- 2 Front canopy
- (3) Inner tent
- 4 Fly sheet
- (5) Pole
- **6** Loops

*The front canopy setting poles are not included.

- (7) Stakes x 20
- ® Rope x 8
- Carry bag

PRODUCT SPECIFICATIONS:

Materials:

Tent fabric: Polyester

Pole: Steel Stake: Steel

Rope: Polypropylene Carry bag: Polyester

Made in China

How to set-up



more people to set-up.




You can view detailed methods of assembly and disassembly on the product page of our website.




 Remove the inner tent from the carry bag and place it on stable ground. Please note that placing the tent on hard ground such as concrete may damage the fabric due to friction with the ground. Place stakes at each of the 8 X's marked on the left. This will ensure each side of the inner tent is pulled.

Secure the door (red) rope with a stake.

Drive stakes in at an angle to ensure tightness.






2. Place the fly cover over the inner tent. Make sure to align the fly cover entrance with the tent entrance.





3. Assemble the pole and insert it into the center of the inner tent. Raise the pole so that it is perpendicular to the ground.




4. Adjust the length of the loop and use the stakes and rope to secure the fly cover. You can improve the strength and durability by securing the rope attached to the side with a stake.












- 5. The separately sold tent poles can be passed through the two grommets on the front canopy to bring the front canopy forward as a shade.
- *Do not set up the front canopy in strong wind.




There is a space between the inner tent and the fly cover. This space can be used to store your luggage or shoes.


Disassembly



- 1. Remove all stakes and ropes on the fly cover. Then remove the pole from the tent body and remove the inner tent stakes.
- *The pole may fall and cause injury. Beware of others and surroundings when removing the pole.



2. Spread the fly cover and inner tent on the ground and fold them in half from the center. Continue folding until it will fit into the carry bag.



3. Roll the fly cover and inner tent around the folded pole and store together in the carry bag.

STORAGE METHOD:

■ After use, wipe any dirt off of your tent and dry it completely.

If the tent is stored while still wet, mold, corrosion, or deterioration of the waterproof / water repellent function may occur. To remove dirt, wipe off with a cloth that has been wrung out tightly. Please refrain from using organic solvents such as Benzine when wiping off dirt. These may cause discoloration.

Avoid high temperatures and humidity when storing.

The tarp should be stored in a well-ventilated place out of direct sunlight.

When disposing of a product, follow your local guidelines.

ADDITIONAL INFORMATION



DOD helps you spend better time outdoors with friends and family. DOD is a leading outdoor gear company from Japan, developed for those who favor thoughtfulness of design, style, and quality. Our gear makes camping delightful, whether sleeping, lounging, cooking, or eating. We bring cozy outdoors.

Website: https://dodoutdoors.com/



For general inquiries or questions about your product, please reach out to us!

Email: info@dodoutdoors.com