


Tools Required

Benötigtes Material / Accessoires / Herramientas Strumenti da lavoro / Benodigdheden



Two pairs of hands

pairs of

Identifying Bolts

Spanner and Socket Set

Size	Spanner Size	
м8	13mm	
M10	17mm	
M12	19mm	
M14	22mm	
М16	24mm	
M18	27mm	
M20	30mm	
M24	36mm	

Parts Included

Unterteile / Liste des pièces / Lista de partes Elenco degli elementi / Onderdelen



Bolt, Nut & Washer A (x4) M8 / 70mm



Part 1 Hoop/Ring



Part 2

Before Installation

Check all parts are present!

Our factory takes every effort to make sure everything is packed in its proper place. But just in case a small part has gone astray please make sure you check every piece is present before you begin installing - right down to the nuts and bolts.

Assemble with Care

Installation should be completed by two adults. Please make sure you follow all the instructions carefully. If you have any questions during installation please do not hesitate to contact us on +441865 392439 or email sales@biggamehunters.co.uk and we will be happy to advise.

Please make sure you read all the safety warnings and advice in this instruction manual. Take extra care and attention over the wall fixing instructions as this will make sure your equipment is firmly attached once you have completed the assembly. Make sure you position the backboard somewhere with plenty of space to play.

Using the Basketball Equipment

Improper installation or use of the basketball ring may cause damage to the system or result in serious injury to the user. We would advise that children are supervised at all times when using this product.


Please adhere to the warnings below to ensure proper use of this equipment and ultimately to ensure full enjoyment!

Attaching the Basketball Net

When attaching the net to your basketball hoop, make sure you have the net the correct way up. The wider loops/wider part of the net should be at the top. Slide the loops of the net over the metal loops on the inside of the basketball hoop - from the inside towards the outside (see diagram 1). You can also see here a net that has been assembled correctly and one that has been assembled upside down!

diagram 1








Affachine Your Rine

Fix Ring to Wall


You will need: Ring/Hoop (part 1) 4 x Bolts, Nut & Washers A (M8 x 70mm)

Fix the ring to the wall using four wall anchor Bolts, Nuts and Washers A. Using an equal diameter drill bit to the wall anchor bolts, drill the holes in your wall and insert the bolts with the nuts facing out. Remove the nuts and place the ring onto the bolts. Put the nuts back onto the bolts and tighten them. The anchor bolts will expand as you tighten the nuts, securing the backboard in place.



They should sit in this order once fixed:

Bolt > RIng > Washer > Nut



Warning!

Failure to comply with these warnings can lead to injury and/or damage of the basketball equipment.

- If using a ladder during assembly, use extreme caution.
- Do not allow children to hang from the hoop or any part of the system including the backboard, rim, support braces
- Do not perform 'dunk' moves on this basketball ring as it is not designed for this purpose. During play ensure face does not come close to the rig or net as this could result in injury.
- Make sure you check the ring frequently to ensure it is properly attached to the wall (see the *Inspection and* Maintenance section below).
- Check the system before use to make sure all fixtures and fittings are tight (see Inspection and Maintenance below).
- During play, do not wear jewellery (e.g. rings, watches, necklaces) objects may become entangled in the net.
- Adverse weather conditions, exposure to extremes of weather, corrosive materials such as salt, herbicides or pesticides or misuse of the backboard could cause corrosion and result in the system failing.
- This equipment is intended for home recreational use only and NOT excessive competitive play.

Inspection & Maintenance

We recommend the following inspection and maintenance.

Looking After Your Basketball Backboard and Flex Ring

Your basketball backboard and flex ring - just like any other outdoor play equipment - are designed to be used outside but without proper care and maintenance will not last as long as you might want.


Weekly to monthly / routine visual inspection

Check all nuts and bolts - if any are loose, tighten them where necessary.


1 - 2 times per year / annual inspection


Check for rust and corrosion of nuts and bolts and replace with galvanised steel replacements where necessary.





Install the product in a way to avoid risk of entrapment - with sufficient gap between the product and other surfaces.





iAdvertencia! Exclusivamente para uso doméstico. No conveniente para menores de 3 años / 36 meses - partes pequeñas con riesgo de ingestión o inhalación - riesgo de atragantamiento.. Se utilizará exclusivamente bajo la vigilancia directa de una persona adulta. La instalación de este producto en un juego infantil o otra construcción debe estar hecho asi que peligro para quedarse atascado quede excluido.

Attenzione! Solo per uso domestico. Non adatto ai bambini di età inferiore a 3 anni / 36 mesi - presenza di piccoli elementi suscettibili di ingestione o inalazione - pericolo di soffocamento.. Utilizzare sotto la sorveglianza diretta di un adulto. Effettuare il montaggio in modo che si eviti il rischio di intrappolamento.

Waarschuwing! Allen voor privé gebruik. Niet geschikt voor kinderen jonger dan 3 jaar/ 36 maanden wegens kleine elementenmet het risico op inslikken of inademen - verstikkingsgevaar. Alleen voor privé gebruiken onder toezicht van een volwassene. Het inbouwen van dit product in een speeltoestel of andere constructie dient zodanig te gebeuren dat voor beknelling uitgesloten is.

Bee-Ball® is exclusive to Big Game Hunters: +441865 392439 sales@biggamehunters.co.uk 📵 biggamehunters.co.uk

Please retain for future reference