

# DUOMO WHEEL CART

---

05-000-151



**TROMEN**

# OWNER'S MANUAL



Don't burn plastic that is an oil by-product.



Don't wet in contact with humidity.  
The cart will get rusty.



Choose a dry place to put the cart away,  
keep it away from climatic factors and  
conditions such as rain, dust, etc.

This product was thought to be used outdoors, this is the reason for its rustic design. Bear in mind that as time goes by, the cart's surface will get rusty in search of the desired rusticity. This does not affect the equipment's operation.



# WARRANT

## GARANTÍA

This guarantees the original purchaser of this TROMEN coal grill that this equipment will be free of fault both in its goods as well as in its manufacturing as long as it is assembled and operated following the instructions presented here since the purchase moment and sticking to the following:

PAINT . . . . . 6 months

All the other components. . . . .  
. . . . . 1 year

Once started, this equipment loses its surface protection. TROMEN could request prove of reliable purchase date.

**DUE TO THIS, YOU SHOULD KEEP YOUR PURCHASE RECEIPT AND THE REGISTRATION LABEL OF THE EQUIPMENT.**

This warrant is restricted to the replacement of pieces that may turn faulty under usage and normal service and which under full TROMEN's satisfaction, are found faulty. Once TROMEN verifies the fault and approves the claim, the piece will be replaced free of charge. The components or the equipment replacement will be done in the place where the product was purchased. The reception of the equipment will be agreed between the seller and the purchaser.

In case field supervisions are required for products within the 60 days since the purchase date, this service will be free of charge for the purchaser provided there are manufacturing faults. On the contrary, the expenses will be covered by the purchaser. ocasionados correrán por parte del usuario.

This limited warrant does not cover flaws or operating troubles due to accidents, overuse, mishandling, alteration, wrong use, vandalism, inadequate installment, maintenance or incorrect service or due to lack of normal and regular maintenance. This limited warrant does not cover the decline or damages due to weather conditions such as hail, hurricanes, earthquakes, floods or to the fading due to exposure to chemical substances either directly or because of conditions in the environment.

There is no other express warrant other than the one found here and any other implicit commerce warrants or usability are limited in duration to the time stated in written by this limited warrant.

TROMEN does not take responsibility for any especial indirect damage, emerging, product damages caused by the purchaser or third parties or any other incidental damage.

TROMEN does not authorize any person or company to take over any obligation and responsibility related to the purchase, instalment, usage, withdrawal, refund or replacement of the equipment in TROMEN's name. No representation will be linked to this company. For this reason, this limited warrant doesn't cover deterioration or damage caused by climatic phenomena or conditions.

TO VALIDATE THIS WARRANT, YOU WILL HAVE TO REGISTER ONLINE ON OUR WEBSITE WWW.TROMEN.COM WITHIN THE 10 DAYS AFTER THE EQUIPMENT WAS PURCHASED. OTHERWISE, THIS WARRANT WON'T BE VALID.

REPORT ANY FLAW TO:

SERVICIO TECNICO@TROMEN.COM

# SECURITY INFORMATION



The security symbols will alert you on important information



Read all the security information in this owner's guide before starting the fire in the grill.



Do not use it indoors! This grill is meant to be used only outdoors. If you use it inside your house, smoke and gases will accumulate and this may cause fire, house damages, serious or fatal intoxication.



Never leave babies, kids or pets unsupervised near a hot or lit grill.



Do not try to move the grill when it is hot. Wait until it cools down before moving it.



Do not add start liquid or warm or hot vegetal coal covered in the start liquid.



You have to proceed carefully when using your grill. It will be hot while cooking and never leave it unattended while it is being used.



Do not throw ashes or ember away before they are totally out and the grill is cold.



Keep the grill on a safe and level surface place all the time away from fuel materials.



Do not throw ashes or ember away where they could be stepped on or they can represent fire risk. It is advisable to wait until they get cold.



Do not put the grill away until the ashes and ember are fully out.



Using abrasive cleaning products on the cooking grills or the grill in itself will damage the surfaces termination.






The grill will have to be cleaned on a regular basis.




NOT FOLLOWING THE DANGER AND PRECAUTION WARNINGS DESCRIBED IN THIS OWNER'S GUIDE CAN CAUSE SERIOUS BODY INJURIES OR DEATH, OR FIRE THAT CAN THREATEN LIFE OR CAUSE DAMAGE.

# DIMENSIONS



When assembling and using your TROMEN DUOMO CART bear the following dimensions in mind.




# CHECK LIST

-SCREW 5/16"	QUANTITY : 8
-FLAT WASHER	QUANTITY : 46
-HEXAGONAL SCREW 5/16"	QUANTITY : 38
-CARRO DUOMO GRILL MAN TABLE	QUANTITY : 1
-BASIS	QUANTITY : 2
-FRONT WHEEL SUPPORT SYSTEM	QUANTITY : 1
-REAR WHEEL SUPPORT SYSTEM	QUANTITY : 1
-PERIMETER METAL BANDS	QUANTITY : 4
-REAR WHEEL AXIS SUPPORT	QUANTITY : 2
-REAR WHEEL AXIS	QUANTITY : 1
-REAR WHEEL	QUANTITY : 2
-REAR WHEEL WASHER	QUANTITY : 2
-FRONT WHEEL SUPPORT	QUANTITY : 1
-FRONT WHEEL	QUANTITY : 1
-FRONT WHEEL WASHER	QUANTITY : 2
-FRONT WHEEL AXIS	QUANTITY : 1
-TROMEN HEXAGONAL WRENCH	QUANTITY : 1




TROMEN

# ASSEMBLY INSTRUCTION



2. Place the rear axis wheels, adjust them with the screws provided in the kit, don't forget to place the rear wheel washers.






3. Place the front wheel support system adjusting it with the screws and washers provided in the assembly kit.






4. Place the rear wheels axis support and later, place the rear wheels support system adjusting it with the screws and washers provided in the assembly kit.






5. Place the rear axis making sure that they fit the holes so that you can adjust it with the screws and washers provided in the assembly kit.





6. Place the front wheel support under the threaded rivets, place the screws and washers to adjust it to the basis.






PERIMETER  
METAL BAND

BASIS

7. Place the perimeter metal bands and adjust them with the screws and washers provided in the assembly kit.







8. Place the Duomo on the cart, make sure that the legs are not installed and that the holes are aligned when adjusting. Use the screws and washers provided in the assembly kit.



# THANK YOU FOR CHOOSING US

## SECURITY COUNCIL

-  Wash your hands with hot water and soap before you start to prepare any dish and after having handled meat, birds and fresh fish.
-  Do not defrost meat, fish or birds at room temperature or on the cooking table. Defrost the food in the refrigerator.
-  Do not place cooked meals in the same container in which you placed raw food.
-  Wash with water and soap all the containers and cooking utensils that have been in contact with meat or raw fish and wash them.

NOTES:

---

---

---

---

---

---

---

---

---

---

---

