

## HARMONY #11912FBSB-LED / #11912FBPLN-LED #11924FBSB-LED / #11924FBPLN-LED

## PLEASE READ AND SAVE FOR FUTURE REFERENCE.


## **CAUTION**

- 1. Turn off the main power at the circuit breaker before installing the fixture in order to prevent possible shock.
- 2. All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections, obtain the services of a qualified electrician.

## **GENERAL**

Remove all parts and hardware from the box and make sure that none are missing by referencing the illustrations provided.

LED Inside No Bulbs Required
DO NOT tamper with or attempt to repair LED component of fixture
LED 10 Watt (For #11912 LED Sconce)
LED 20 Watt (For #11924 LED Vanity)



- 1) Outlet Box (not included)
- 2) Supply Ground Wire (not included)
- 3) Fixture Ground Wire
- 4) Black Supply Wire (not included)
- 5) White Supply Wire (not included)
- 6) Wire Connectors
- 7) Ribbed (or White) Fixture Lead Wire

- 8) Smooth (or Black) Fixture Lead Wire
- 9) Anchor (#11912 not included)
- 10) Back Plate
- 11) Anchor Screw (#11912 not included)
- 12) Outlet Box Screws (pre-attached)
- 13) Fixture
- 14) Fixture Screw