


OPERATING MANUAL – RADIANT MODELS

! IMPORTANT FOR END-USERS DO NOT THROW AWAY !
READ AND FOLLOW INCLUDED INSTALLATION GUIDE BEFORE USE

ONCE INSTALLED:

Turn on the unit by pressing the on/off button at the bottom of the vertical bar:



You should start to feel some heat after a few minutes.

Units typically take 10-15 minutes to reach its top temperature.

Leave unit on for at least 1-2 hours to dry and warm your towels.

These units are safe to leave on 24/7

For additional control, a separate programmable or countdown timer can be used with your heated towel rack. In this set-up, leave the on/off switch on the heated towel rack in the 'ON' position and use the timer to control the heated towel rack.


**THESE UNITS ARE DESIGNED TO HOLD 1-2 STANDARD TOWELS MAXIMUM:
OVERLOADING OR EXCESSIVE OVERLAPPING MAY RESULT IN OVERHEATING**

HOW TO FOLD YOUR TOWELS?

Fold your towel in half length-wise or width-wise and then drape over the top bar. For best results, ensure towel covers all bars with minimal overhang. Note - for larger towels, they may need to be folded in thirds to fit.

HOW TO CLEAN YOUR HEATED TOWEL RACK?

For best results, turn off unit and wait for it to return to room temperature, then wet a soft cloth with warm water and mild soap and wipe surface. Dry off with a soft, dry towel. Never use an abrasive cleaning pad or product as this could scratch the finish or paint. Stainless steel cleaner should not be used on any painted finish. Stainless steel cleaners can also be used on any of the stainless finishes.



WIDTH FOLD



LENGTH FOLD