## SAFETY INSTRUCTIONS

## PRIOR TO INSTALLATION

- Make sure that the cold and hot water lines are turned off.
- Wrap all threaded connections with plumber's tape. Always wrap in a clockwise direction.
- Cover your drain to avoid losing parts.
- Do not disassemble the main faucet body, as it has been installed and commissioned correctly and precisely before delivery to the factory.
- To keep the faucet from jamming, flush the water pipe before installation.

Operating conditions: Working pressure at 0.05-1.0 MPa (including cold and hot water pressure) with applicable water temperature: 39.2°F - 194°F.

Water supply line length: 27.5"

Sprayer length: 46.5"

## INSTALLATION PREPARATION

- 1. Shut off the water and let the water in the current faucet drain.
- 2. Assemble needed tools. The tools needed for each installation are included at the beginning of each section.
- 3. Loosen the hardware that keeps the current faucet in place. Remove faucet.

## CARE AND MAINTENANCE

To keep the product clean and shining, follow the steps below:

- 1. Rinse clean with water and dry with a soft cloth.
- 2. Do not clean with soaps, acid, polish, abrasives, or harsh cleaners.
- 3. Do not use cloth with a coarse surface.
- 4. Unscrew the aerator and clean when necessary.
- If soldering the water connections when installing the faucet, remove the O-rings, cartridges, and washers before applying any heat.
- Protect your eyes when cutting or soldering.
- Do not over tighten screws/nuts. Finger tighten, then use a wrench/Philips head screwdriver to tighten the fixing screw/nut until snug.