


TOTO®

Handshower







TRANSITIONAL COLLECTION SERIES A TS200F(L)41 TS200F(L)51 TS200F(L)55 TRADITIONAL COLLECTION SERIES A TS300F(L)41 TS300F(L)51 TS300F(L)55 TRANSITIONAL COLLECTION SERIES B TS400F(L)41 TS400F(L)51 TS400F(L)55

TABLE OF CONTENTS Thanks for choosing TOTO! 2 Care & cleaning. 2 Warnings 2 Before installation 2 Installation procedure 5 Warranty. 6 Rough-in dimensions 9-11

THANKS FOR CHOOSING TOTO!

The mission of TOTO is to provide the world with healthy, hygienic and more comfortable lifestyles. We design every product with the balance of form and function as a guiding principle. Congratulations on your choice.

CARE & CLEANING

Your new handshower is designed for years of trouble-free performance. Keep it looking new by cleaning it periodically with mild soap, rinsing thoroughly with warm water and drying with a clean, soft cloth. Do not use abrasive cleaners, steel wool or harsh chemicals, as these will dull the finish. Failure to follow these instructions may void your warranty.

If any nozzles become clogged with mineral build up, rub gently with finger tips to clean.

WARNINGS

For safe operation of the handshower, please observe the following:

- Recommended operating pressure:
 - Minimum pressure......20 psi (0.14 MPa), dynamic
 - Maximum pressure......80 psi (0.55 MPa), static
- Hot water supply temperature must not exceed 160°F (71°C).
- Do not use steam for hot water supply.
- Do not use the product at an ambient temperature below 32°F (0°C).

BEFORE INSTALLATION


- Observe all local plumbing codes.
- Make sure the water supply is shut off.
- Read these instructions carefully to ensure proper installation.
- TOTO reserves the right to update product design without notice.


INSTALLATION PROCEDURE

Place gasket/sieve in conical nut end of shower hose. Fasten to handshower completely to seal.





ROUGH-IN DIMENSIONS / DIMENSIONES PRELIMINARES / DIMENSIONS BRUTES





ROUGH-IN DIMENSIONS / DIMENSIONES PRELIMINARES / DIMENSIONS BRUTES





ROUGH-IN DIMENSIONS / DIMENSIONES PRELIMINARES / DIMENSIONS BRUTES

