
XRocker Legacy Adapter



<u>Digital to Analogue Audio Converter</u> Need Help?

www.xrockeruk.com/pages/support

IMPORTANT: You must keep your original retail receipt as proof of purchase.

Welcome to X Rocker!


Thank you for purchasing the X Rocker Legacy Adapter!

This adapter will help you connect any **X Rocker** gaming chair to any device that doesn't support analogue audio as standard.

This manual will outline the following connection possibilities. More can be found online at www.XRockerNation.co.uk also!


Table of contents

- 3 Box contents
- Connection Guide: PS4™ and PS4 Pro™ Systems
- 5 Connection Guide: Xbox One™ Systems
- **6** Connection Guide: TV (for all other consoles)
- 7 Connecting your X Rocker to the Legacy adapter



- 1 X Rocker Legacy Adapter
 - 2 Optical Audio Cable
 - 3 USB Power Cable


Connecting the Legacy Adapter to PS4™/PS4 Pro™



Make sure the PS4™ System is switched **OFF**. Insert the USB into the front of your PS4™ and the other end into the DAC adapter. Remove the clear plastic ends of the optical cable. Connect one end to the SPDIF port on the DAC adapter and then the other to the PS4™ system. Connect the audio cables from your X Rocker gaming chair into the headphone socket or RCA of the DAC and then follow the step below. Switch on the PS4™ system.

On the main menu screen select (Settings) > [Sound and Screen] > [Audio Output Settings] > [Primary Output Port] and change this to [Digital Optical]. Navigate the menu until you select [Done] and enjoy!

Connecting the Legacy Adapter to Xbox One™




Make sure the Xbox One™ System is switched **OFF**. Insert the USB into the front of your Xbox One™ and the other end into the DAC adapter. Remove the clear plastic ends of the optical cable. Connect one end to the SPDIF port on the DAC adapter and then the other to the Xbox One™ system.

Connect the audio cables from your X Rocker gaming chair into the headphone socket or RCA of the DAC and then follow the step below.

Switch on the Xbox One™ System. On the menu screen, select (Settings) > [All Settings] > [Display and Sound] > [Audio Output] > under [Digital Audio], Select [Optical Audio] and set it to [Stereo Uncompressed] Navigate the menu until you select [Done] and enjoy!

5


Connecting the Legacy Adapter to a TV Set



Make sure that the TV set is switched **OFF** before connecting. Remove the clear plastic covers from both ends of the Opticalcable. Input one of end of the optical cable into the SPDIF socket on the legacy adapter. Connect the other end to the SPDIF socket on your TV. Connect one end of the USB cable into any available USB socket on your TV or alternative device. Connect the round end into the Legacy adapter.

On your TV, navigate to the settings menu, check for [Audio Output] and switch this to [Digital Optical Out] Please note that this setting is different on each TV. Please check your TV manual for full information on how to switch over the settings.

Connecting your X Rocker to the Legacy Adapter



NB. RCA and 3.5mm audio cables supplied with X Rocker gaming chair. For Wireless/Bluetooth models. Please make sure the channel switch is set to **AUX** or **OFF**.

Need Help? www.xrockeruk.com/pages/support

IMPORTANT: You must keep your original retail receipt as proof of purchase.