

XRocker Assembly Instructions

Maximum platform weight 10kg









WARNING

Please be mindful of product edges to ensure safe construction

16 Ages+

Notice: Keep small bolts and parts away from children

A		2
B		2
C		2
D		4
E		4
F		1
G		4
H		1
I		1
J		1
K		1
L		1
M		4
N		2
O		4
P		1
Q		1
R		1



Need help? Use the Contact Us online form at www.xrockeruk.com/pages/support . you must include all the mandatory fields for efficient service