

vibesonly.com

Vibes Only™

Allison Wonderland

Instruction Manual

Size: 9" x 1.5" shaft width

Finger Loop Width: 1.5" x 1"

Weight: 182g

Materials: Medical-grade silicone

Battery: Lithium Ion

Charging Time: 2.5 hrs

Turn up the heat and go down the rabbit hole...

Enter a world of unparalleled pleasure with Allison Wonderland. The blend of both internal and external stimulation brings your fantasy of a mind-blowing, full-body orgasm to life. With a modern, innovative design created to hit your clit and G-spot simultaneously, your p*ssy will be grinning like a cheshire cat.

Why you'll love the Allison Wonderland rabbit vibrator:

- Connects to the Vibes Only app
- Dual-ended for internal and external stimulation
- Flexible to fit any body, in any position
- Magnetic charging
- 6 levels of clitoral vibration
- 6 shaft pulsations
- Medical-grade silicone
- Water resistant (do not fully submerge metal handle)

Liquid silicone shaft for a divinely soft and squishy feel

Clitoral

- Power
- Vibration

Shaft

- Power
- Vibration

Never lose your grip with our finger loop design



Connect with
Bluetooth




Hope you're ready, this vibe only gets better...

Connect to the Vibes Only app to unlock a whole new world of self-love where you'll handpick your own fantasy and become the main character. Your vibrator will work in tandem with the erotic reverie for a full-blown journey into orgasmic bliss.

And that's not all – get exclusive video content from the pros on sex, dating, pleasure, and more. We hope you'll learn, laugh, and love it.

Get connected

Scan this code to download the Vibes Only app on your phone.



Start vibing

This vibe comes partially charged. To get it all the way up, charge before use.



On your device, hold down each power button for two seconds to turn on.

Your Bluetooth will be enabled when the device turns on. The light will flash to indicate it is discoverable.

The app will detect your device. Select it, and your vibrator is synced!



To adjust intensity and patterns manually:
Click the buttons to enjoy various sensations.

Power your vibrator

Charging instructions


If your vibe is feeling a little lowkey, it may be time for a charge.

Due to the unique design, each Vibes Only model charges slightly differently.

First, plug your USB cord into a standard charging block (high-power charging blocks may damage the battery).

Connect the magnetic charging points to the matching points on your vibrator. The light on your device will flash to indicate that it's charging.

When it is fully gassed up (approx. 2.5 hrs) the light will change to a steady glow.



Care for your vibe ...and it will love you back!

Care instructions

We can't recommend using a water-based lubricant enough, such as Vibes Only Juiced Up. Avoid using a silicone-based lubricant as this could kill your vibrator. If you must use a silicone-based lubricant, perform a patch test first.

After every use, clean with warm water and antibacterial soap or toy cleaner. Dry thoroughly with a clean towel or air dry. Store in a cool, dry place and keep your vibrator away from toys made of other materials. Remember to charge periodically to maintain the battery life.

What not to do

- Refrain from bending the shaft backward.
- Use with oil-based massage oils or lubricants as it may damage the silicone.
- Leave your vibrator in direct sunlight or ever expose it to extreme heat.

Troubleshooting

Your vibe's light does not pulse when the charger is connected? This could be why:

- Battery is fully charged (go off!)
- Battery is drained and will require several minutes to recognize that it is being charged.
- Charger is not properly connected. Check your charging block and charging cable.

Your vibe does not connect with your phone when the button is pressed?

- Battery is drained and your device requires charging.
- Make sure you give Vibes Only permission to access Bluetooth in your phone settings.
- The Bluetooth on your phone is not enabled. Make sure to enable, or reset your phone if needed.
- You have exceeded the 10 seconds required for your vibrator to 'find' a device. Reset both your vibrator and your phone by turning off, waiting 30 seconds, then turning on. Now try again making sure your phone has fully restarted, with the Bluetooth switched on.

If you experience any other problems with your Vibes Only product or have any questions regarding operation, view the website for instructional videos at www.vibesonly.com or please contact: help@vibesonly.com.

What's your vibe?

Discover more:



@VibesOnly



vibesonly.com



Available on the
App Store



GET IT ON
Google Play