

vibesonly.com

Vibes Only™

The Lucy

Instruction Manual

Size: 3" Length x .75" diameter

Weight: 25g

Materials: High-quality ABS with body-safe silicone detail

Battery: Lithium Ion

Charging Time: 2 Hrs

A versatile vibrator to suit your desire

Double your pleasure with two vibes in one – switch up the sleeves on this petite and powerful bullet to hit your sweet spot.

Why you'll love The Lucy bullet:

- Connects to the Vibes Only app
- Discreet size to get off anywhere, any time
- Versatile sleeves for internal or external stimulation
- Unassumingly powerful
- 3 intensity levels
- 3 vibration patterns
- High quality ABS plastic with body-safe silicone
- Water resistant



What's Your Vibe?

Hit the Spot

Curved design for ideal internal stimulation

Designed for targeted stimulation


Can be used for external stimulation



Anchor-style base for easy grip + extra vibration through both tips

Textured pad for extra sensation

Finger loop for better control



Concentrated Stimulation


Hope you're ready, this vibe only gets better...

Connect to the Vibes Only app to unlock a whole new world of self-love where you'll handpick your own fantasy and become the main character. Your vibe will work in tandem with the erotic reverie for a full-blown journey into orgasmic bliss.

And that's not all -- get exclusive video content from the pros on sex, dating, pleasure, and more. We hope you'll learn, laugh, and love it.

Get connected

Scan this code to download the Vibes Only app on your phone.



Start vibing

This vibe comes with a little charge. To get it all the way up, charge before use.



On your vibe, hold down the power button for two seconds to turn on.

Your bluetooth will be enabled when the device turns on. The light will flash to indicate it is discoverable.

The app will detect your device. Select it, and your vibe is synced!



To adjust intensity and patterns manually: Click the button to cycle through the steady speed levels, then the patterns.



Mix it up – use your bullet naked, or slide it into a sleeve to suit your desire.

Power your vibe

Charging instructions

If your vibe is feeling a little lowkey, it may be time for a charge.

Due to the unique design, each Vibes Only model charges slightly differently.

First, plug your USB cord into a standard charging block (high-power charging blocks may damage the battery).

Insert the DC jack (long skinny piece) into the small circle opening (tight hole) on the bottom of your vibe. Be gentle, but firm, until it's in as deep as it can go.

The light on your vibe will flash to indicate that it's charging.

When it is fully gassed up (approx. 2 hrs) the light will change to a steady glow.



Care for your vibe ...and it will love you back!

Care instructions

We can't recommend using a water-based lubricant enough, such as **Vibes Only Juiced Up**. Avoid using a silicone-based lubricant as this could kill your vibe. If you must use a silicone-based lubricant, perform a patch test first.

Remove your sleeve after every use, and wash it with antibacterial soap and water. Wipe down your bullet with soap and a damp washcloth or use a toy cleaner. Wipe with a dry cloth or let air dry. Polish your vibe with the supplied cloth. Store in a cool, dry place and keep your vibe away from toys made of other materials. Remember to charge periodically to maintain the battery life.

What not to do

- Submerge the bullet in water.
- Use with oil-based massage oils or lubricants as it may damage the silicone.
- Leave your vibe in direct sunlight or ever expose it to extreme heat.

Troubleshooting

Your vibe's light does not pulse when the charger is connected? This could be why:

- Battery is fully charged (go off!)
- Battery is drained and will require several minutes to recognize that it is being charged.
- Charger is not properly connected. Check your charging block and charging pin.

Your vibe does not connect with your phone when the button is pressed?

- Battery is drained and your vibe requires charging.
- Make sure your app has been given permission to access bluetooth on your phone settings.
- The bluetooth on your phone is not enabled. Make sure to enable, or reset your phone if needed.
- You have exceeded the 10 seconds required for your vibe to 'find' a device. Reset both your vibe and your phone by turning off, waiting 30 seconds, then turning on. Now try again making sure your phone has fully restarted, with the bluetooth switched on. Open the Vibes Only app and turn your vibe on.

If you experience any other problems with your Vibes Only product or have any questions regarding operation, download the app for instructional videos or please contact help@vibesonly.com.