

TICKERVIEW

BY




TickerMart

USER'S MANUAL



1. Plug the device into any reliable 5V power source.

For example, a computer USB port, a tv USB port, a power bank, or a normal phone adapter...(MUST BE NO HIGHER THAN 5V)



2. Using any Wi-Fi-capable device (Smartphone, PC, Mac) connect to the wireless network named **"Tickerview"**.


If you do not see it, turn off your Wi-Fi and back on again.

3. You will get a pop-up Wi-Fi Setup screen on your device. (If you do not get the pop-up screen in 10 seconds, open a browser, and connect to 192.168.4.1) Then click on Configure Wi-Fi.



4. Choose the Wi-Fi network you would like to use and enter your password.

****Device only works- with a 2.4g network**



5. After pressing the save button, You will see connected on the display.

6. Just after seeing the connected on display, you will see your customize webpage address, which your router generates through which you can feed or change the stocks. Note This will be different for every wifi network



7. Just after seeing the connected and receiving your customised address, Just restart your device. Your device will automatically get connected with your wifi. and visit to the webpage for us its 192.168.1.21

Tickerview by TickerMart.com

Stock Entry page

Enter Custom text (Custom value: Stop or Dividend) Submit

Enter Code 1 (Custom value:Relc, etc) Submit

Enter Code 2 (Custom value:dfb,etc) Submit

Enter Code 3 (Custom value:TCS, etc) Submit

Enter Code 4 (Custom value:HDFC, etc) Submit

Enter Code 5 (Custom value:Tpt, etc) Submit

Enter Code 6 (Custom value:Quant, etc) Submit

Enter Code 7 (Custom value 1) Submit

Enter Code 8 (Custom value 2) Submit

Enter Code 9 (Custom value 3) Submit

Enter Code 10 (Custom value 4) Submit

Enter Code 11 (Custom value 5) Submit


Enter Code 12 (Custom value 6) Submit

Enter Code 13 (Custom value 7) Submit

Enter Code 14 (Custom value 8) Submit

Enter Code 15 (Custom value 9) Submit

Enter Brightness level (From 0-15 Custom value 10) Submit



8. Enter your custom text, As you know your stock data are received from yahoo finance API so enter the stocks name which is on the yahoo finance website in brackets. Here eg "TCS.NS , HDFC.NS". You can customise the LED brightness from 0-15 level.

9. Whenever you want to change the custom text, Ticker name or adjust brightness, Just visit the same IP address generated by your Tickerview device in the browser of the device connected with same wifi network as your Tickerview device.

FAQ

How should I connect to another WIFI network ?

Just turn off the current wifi to which the device is connected, and the device will automatically go to wifi mode and can connect with your phone wifi and connect to new wifi network.

Why isn't my device showing my Stocks?

This could be one of four things:

- 1.** Your device is too far away from your router. -Please ensure your device is in decent range to your router, if it is too far then the device will not be able to connect to Wi-Fi and your device will not show anything.
- 2.** Your Wi-Fi password was entered incorrectly. Regardless of what you enter, the device will save whatever your input is and will not tell you that your password was entered incorrectly. Please make sure your password was properly entered.
- 3.** Your Wi-Fi security is not set properly. -Please make sure that you are connecting to a 2.4g Wi-Fi and that your setting is set to **"WPA2 ONLY"**
- 4.** Your Stocks were spelled incorrectly. - Please refer to ***finance.yahoo.com*** for the correct spellings of your coin(s).

Sometimes coins that are two words have a dot in the middle. For

Example: RELIANCE.NS OR BTC-USD.

FAQ

How do I change my current coins to new ones?

Just restart the device you will see the customize webpage address, Just visit it through your browser and customised your stocks or custom texts.

Why aren't all my lights lighting up?

This may be because of an insufficient power source. Try switching either your cord or the power source itself.

Why my Customise webpage is not getting opened in my browser ?

Their could be one of 4 things:

- 1.** You are not connected to the same wifi network as your Tickerview device is connected.
- 2.** You have to wait 10-15sec after the IP is displayed on the Tickerview screen.
- 3.** Restart the device once and follow the above process.
- 4.** Try opening of any other device like phone or laptop connected with same wifi network.

If none of these suggestions help

Please visit:

tickermart.com/pages/contact

OR

Watch this tutorial video



Follow for more:  [ticker_mart](https://www.instagram.com/ticker_mart)