

VPC-VPS 10 Vertical Pumps



POS.	PARTS NAME
11	Discharge part
12	Chamber, upper
+24	Neck ring
+25	Neck ring retainer
13	Chamber, middle with bearing ring
+24	Neck ring
+25	Neck ring retainer
14	Bearing ring
18	Impeller
27	Clamp
28	Chamber, bottom
+24	Neck ring
+25	Neck ring retainer
30	Strap retainer
36	Pump head (0.5HP)
	Pump head (1HP)
	Pump head (2HP)
	Pump head (4HP)
	Pump head (7.5HP)
	Pump head (15HP)
37	Pump shaft
38	Shaft ring
39	Shaft bushing
40	Lock nut
42	Spacing pipe
42A	Spacing pipe
42B	Spacing pipe
42C	Spacing pipe
43	Coupling Assembly (ψ 14) 0.5~0.75HP
	Coupling Assembly (ψ 19) 1~1.5HP
	Coupling Assembly (ψ 24) 2~3HP
	Coupling Assembly (ψ 28) 4~5.5HP
	Coupling Assembly (ψ 38) 7.5~10HP
	Coupling Assembly (ψ 42) 15~20HP
+72	Shaft pin
+73	Hexagon socket head screw
	Hexagon socket head screw
	Hexagon socket head screw
47	Strap
48	Pump casing
50	Adapter flange (7.5HP)
	Adapter flange (15HP)
54	Coupling guard (0.5HP)
	Coupling guard (2HP)
	Coupling guard (7.5HP)
	Coupling guard (15HP)
56	Pump head cover
57	Shaft seal
+66	O-ring (EPDM)
	O-ring (VITON)
59	Base
	Base (Flange)
61	Base (Victaulic)
	Flange
62	Base plate (Flange)
62	Base plate (Victaulic)
63	Drain plug
64	Air vent screw
65	Plug
69	Hexagon socket head screw
70	Hexagon socket head screw
71	Washer
74	Screw

