

Qwertypewriter® NUMKEY™

INSTRUCTION MANUAL

FN function


Windows: FN+ESC is Number Lock

Mac: No Number lock function

Clear function in **Mac**

Backspace in **Windows**

Power indication LED



USB | Bluetooth | Power off

TYPE-C for charging and USB

Charging Your NUMKEY



The NUMKEY includes a braided 'C to C' cable with 'C to A' adaptor for charging.

Power indication

- A blinking Red LED indicates battery is low.
- A steady Red LED stays lit during charging.
- The Red LED turns off once fully charged.

Connectivity **BT pairing and indication**



A long press and hold  +  +  will start pairing. A short press of these keys is used to select devices.

A Blue LED indicates BT1. A Green LED indicates BT2.

- The Blue LED blinks during pairing and turns off once BT1 pairing has finished. A steady Blue LED shows for 30 seconds during BT device switching
- The Green LED blinks during pairing and turns off once BT2 pairing has finished. A steady Green LED shows for 30 seconds during BT device switching.

The Bluetooth name for the NUMKEY will appear on your devices as: **QT NUMKEY**

Key Functions



System switch indication:

 +  is Windows system.


 +  is Mac system.

- A steady Yellow LED for 30 seconds indicates that the Numkey has changed to a Mac system (MAC is the default system Setting).
- A steady Cyan LED for 30 seconds indicates that the NUMKEY has changed to a Windows system.

Number Lock indication/NUMLOCK:

- A steady Purple LED for 30 seconds indicates number lock is turned on.
- The LED turns off if Number Lock is off.

Factory Default Settings

Press  +  for 3 seconds to reset back to factory default settings.

©2023 Qwerkytoys, Inc.

Designed in California, USA Made in China

All Rights Reserved and other trademarks contained herein are the property of Qwerkytoys, Inc. Product may vary slightly from those pictured.

Protected by U.S. Patent No. D773,473 and D775,136.

www.qwerkywriter.com