



instruction for installation

instrument; tool



Chinese-English





screwdriver

Before Installation

1. Please read these instructions before assembling or installing the product.
NOTE: Installation by a licensed electrician is recommended.
2. Take out the fixture and the mounting package and make sure all parts are included.
If any part is missing or damaged, please contact us.
3. All parts must be used as indicated in these instructions. Do not substitute any parts, leave parts out, or use any parts that are worn out or broken.
4. Do not disassemble the main body, as it has been installed & commissioned correctly &
5. **IMPORTANT:** Turn off the main power at the circuit breaker and place the wall switch or pull
6. Do not use bulbs with wattage greater than specified on this fixture.

No	Material	PCS
A	Suction top plate + hanging plate	1
B	Steel wire	1
C	Intracental glass	1
D	G9 lamp bead	1
E	G9 lamp holder	1
F	Hardware disc	1
G	M10 Hardware pipe	1
H	Electric wire	
I	M12 Hardware pipe	
J	M15 Hardware pipe	



- 1 M12 hardware rod with full teeth to lock the top plate A B H
- 2 The mouth glass and the lamp head can be twisted up
- 3 The wall is played with the hanging plate, the top plate is connected with the overall lamp and can be fastened on A B C D E F G
- 4
- 5

Troubleshooting

Problem	Possible Cause	Corrective Action
Fixture does not light.	<ol style="list-style-type: none"> 1. Fixture may be wired incorrectly. 2. Worn or broken bulb. 3. Lamp socket or LED transformer (if applicable) may go bad. 	<ol style="list-style-type: none"> 1. Check wiring. 2. Replace bulb. 3. Replace lamp socket or LED transformer (if applicable)
Light bulb flickers.	<ol style="list-style-type: none"> 1. Switch Contacts are bad. 2. Wire connections are loose. 	<ol style="list-style-type: none"> 1. Replace the switch 2. Check wire connections 3. Replace the socket.