


instruction for installation

instrument; tool




Chinese-English




screwdriver

Before Installation

1. Please read these instructions before assembling or installing the product.
NOTE: Installation by a licensed electrician is recommended.
2. Take out the fixture and the mounting package and make sure all parts are included.
If any part is missing or damaged, please contact us.
3. All parts must be used as indicated in these instructions. Do not substitute any parts, leave parts out, or use any parts that are worn out or broken.
4. Do not disassemble the main body, as it has been installed & commissioned correctly &
5. IMPORTANT: Turn off the main power at the circuit breaker and place the wall switch or pull
6. Do not use bulbs with wattage greater than specified on this fixture.



No	Material	PCS
A	Hanging plate + suction top plate	1
B	Hardware rod	1
C	Hardware roundabout	1
D	a ball	1
E	Hardware lamp	1
F	E27 lamp cup	1
G		1
H		1
I		1



1 One line hanging plate on the wall and the suction top plate to lock

2 M10 hardware bar The hardware bar is locked with the tooth pair round hardware, and the other end of the hardware bar is locked on the lamp block with the tooth pair B C E

3 The ball is connected and fixed on the hardware round tong can be D C

4

Troubleshooting

Problem	Possible Cause	Corrective Action
Fixture does not light.	<ol style="list-style-type: none"> 1. Fixture may be wired incorrectly. 2. Worn or broken bulb 3. Lamp socket or LED transformer (if applicable) may go bad. 	<ol style="list-style-type: none"> 1. Check wiring. 2. Replace bulb 3. Replace lamp socket or LED transformer (if applicable)
Light bulb flickers.	<ol style="list-style-type: none"> 1. Switch Contacts are bad 2. Wire connections are loose. 3. Light bulb socket may go bad. 	<ol style="list-style-type: none"> 1. Replace the switch 2. Check wire connections. 3. Replace the socket