



A-plus[®] Rolling, Folding, Quick Loading A-frame Sign

USER GUIDE



- Open sign so EZ-Grip Handles touch each other. Flip down Support Arms on both sides of sign and engage clip.
- Message Board signs have the sign panels with tracks pre-installed and Ready 2 Use.
- Ready 4 Graphic model requires the sign panel to be installed as follows:
 - Slip one side of sign panel under side edge.
 - Starting at top or bottom of opposite side, bow the sign panel and slip under the edge.
 - Work your way up until the entire side is secured under the edge.
 - To remove press from back side.
 - NOTE: Sign is designed to use 24" x 36" x 4mm corrugated plastic; horizontal flutes.
- Up to 2 quarts of water can be added to Ballast Ports on inside of each leg for additional stability and wind resistance.
- To move sign simply grip the EZ-Grip Handle(s), Tip the sign on its recessed wheels and Roll the sign in, out or about.
- Sign can be rolled in either folded or open position. It fits through most doorways.
- To fold sign for storage just release the Support Arms on each side and close sign.
- When the sign is in the deployed or stored position it sits on its feet.
- When the sign is tipped the wheels engage and can be rolled.

CAUTION

**A-plus[®] Sign Holders are designed for winds of up to 30 - 40 mph.
In the event of higher winds bring sign inside or add more ballast.**

Manufactured by **Joseph Struhl Company, Inc.**, PO Box N, Garden City Park, NY 11040

1-800-552-0023 • 516-741-3660 • Fax 516-742-3617

www.magicmaster.com