

Halogenerator Installation HaloGX™

Halogenerator Specifications

Dimensions

Height 24.5" (622mm)

Width 8.3" (210mm)

Depth 6.1" (155mm)

Weight 16.75 lbs. (7.6 kg)

Power requirements

110/230 V

50/60 Hz

48W

Different plugs are available for country-specific installation.

Advise during the order process.



How to install your Halogenerator

All professional-grade halogenerators are installed outside the salt room to ensure the flow of fresh air instead of circulating the same air in the room or cabin for 25-40 minutes.

1. Cut a rectangular opening of 2.165 x 4.33 inches (55 x 110 mm) in size into the wall of the salt room approximately 60 inches (1.5m) from the ground.

Use the provided extension sleeve for thicker walls.

2. Position the Halo-GX generator into place and fasten it with (2) Phillips-head Screws

3. Install the scoop on the inner wall of the salt room

4. Connect the plug to an electrical outlet