

# Silver Xtreme Bluetooth Music Controller LED-BLU-MSC-ST-CONT




LED Chord is an APP designed for full color LED controller as a remote controller via Bluetooth.

It provides LED music effects for pixel LED users, it has never been so easy to set up a compact LED light show..


## App Download and Install:

- Both IOS and Android OS versions are available.
- Requires IOS Version 10.0 or later, Android OS version 4.4 or later.
- Scan QR Code to download app or search LED Chord in App Store or Google Play




## How to Set it Up:

- Make sure the bluetooth feature is turned on > Pull- to-refresh device list > Select user device.
- Settings for RGB order and led driver IC type.  
GRB SM16703 for most Gorilla Whips LED Products.




## Rename Device:

- Long press the connected device to change the device's name.



## LED Music Mode:

- View in Strip Mode to adjust color and sensitivity.
- View in Matrix Mode- Dropping dots and pillar colors are adjustable and can be removed by unchecking the color bar.
- Enter or exit automatic loop by clicking icon in the lower right corner.



### Solid vs Auto Color Selection

- 7 Solid color direct press options, adjust brightness, speed, and sensitivity..
- View in Matrix Mode- Dropping dots and pillar colors are adjustable and can be removed by unchecking the color bar.



### Effects and Favorites

- Press right/ left arrows to select effect (180 in total)
- Click a # to mark a favorite effect
- Long press # to see all of your favorite effects by tapping the right/ left arrow. Untapping the heart icon will remove from favorite effects. Tap empty area to exit.

### Troubleshooting Tips:

- Power to the controller is connected to the busbar or key on power?
- Check your internet connection
- Do you have Bluetooth enabled on your phone?
- 1 phone can be connected to the device at a time. Are you connected to your device?
- Check fuses to busbar
- Connect through the LED Chord App, not through phone
- Disconnect power and reconnect
- Drag to refresh device list, choose SP107e
- Check for App updates, restart phone after update
- Uninstall LED Chord App, then Reinstall LED Chord App
- Check for phone updates, restart phone after update

For questions, please email us at [sales@gorillawhips.com](mailto:sales@gorillawhips.com) or call us at 801.899.3513.