

FISHING SEAT ASSEMBLY INSTRUCTIONS



Items needed to assemble the Fishing Seat:

1. Seat of the Chair (x1)
2. Back of the Chair (x1)
3. Quick-Release Skewers (x2)
4. Webbing Straps (x 4)



1. Loosen the straps on the underside of the seat. This will give you easier access to the attachment points.



*Note the white bushings. These are necessary for assembly, do not remove.

2. Fit the Chrome Hinges on either end of the bushings. You may need to manipulate the hinges a little, they're a tight fit.



3. Unscrew the black caps from the quick release skewers and insert them through the chrome hinges and chair frame. Reattach cap. Turn handle of the quick release skewer to tighten as needed and fold down the handle once accomplished.



4. Secure the loop straps from seat to back of chair on both sides.

Your seat is now constructed!



The four additional black straps are used to anchor the chair to the intended D- Rings.