


ASSEMBLY INSTRUCTION: HLT573



HARDWARE

(1) Nut : 4PCS

(2) Washer: 4PCS

(0)

ALLEN KEY: 2PCS



WRENCH SINGLE 17: 1PC

