

BPB24 **Remote Pairing Instructions**









Step 1. Remove the power from the BPB24 by unplugging the main power cable. Wait 30 seconds




Red LED





power cord back in, it is much easier to use two people.



Step 3. Plug the BPB24's main power cable back in. You will see the LEDs on the speaker flash white 3 times. Press and release the putton. The remote is now paired to the BPB24