


How to Use Whetstone Stand (screw-adjusting) No. 32


A whetstone with a thickness of over 20mm can be mounted without spacers.
For a thin whetstone with a thickness of over 5mm,
use spacers to adjust the height and ensure the whetstone is held firmly on the stand.

Standard Size Whetstones

Thickness
Approx.
20-35mm




Length
Approx. 150-230mm



Ensure the whetstone
is fixed firmly
before use.

Thin Whetstones

Thickness
Approx.
5-10mm



Please use spacers to
hold a whetstone
with a thickness of 5-10mm.
Spacers can be rubber,
plastic or wood.

Example


30~50mm

Spacers
(two or three)

80~
100mm

Thickness
5~8mm

* Use spacers of appropriate size
for the whetstone.



Ensure the whetstone
is fixed firmly
before use.