Assembly Instructions



1-877-637-3712

PARTS LIST

- 1. Base with upright arms (x1)
- 2. Casters (x4)
- 3. Hangbar (x2)
- 4. Clamps (x4)
- 5. Screws (x4)
- 6. Washers (x4)

ASSEMBLY INSTRUCTIONS

- 1. Remove rack from carton.
- 2. Place rack on ground and unfold upright arms.
- 3. Insert two hang bars on the four upright arms.
- 4. If NEEDED: Attach 4 clamps to base with supplied screws and washers. These clamps can hold hang rails when not in use.
- 5. Extend pull-out extensions if needed.

Double Collapsible Salesman (666742)





