

# AUDIO KEEPER

*Audio Keeper ICE1*

## Use and Care Instructions

PLEASE READ USE AND CARE INSTRUCTIONS IN ITS ENTIRETY PRIOR TO SETTING UP AND OPERATING YOUR RETROLIFE PRODUCT

*NOTE: As with any electronics maintenance, always unplug the unit from the power outlet to prevent the risk of electrical shock.*

### ICE1 Introduction:

ICE1 is an all-acrylic transparent high-fidelity vinyl turntable that combines modern design and advanced technology to bring users pure music enjoyment. Its transparent appearance showcases a modern aesthetic, while its high-fidelity sound quality immerses users in the most authentic and clear music experience. ICE1 is designed to provide music lovers with ultimate quality and stylish appearance, making it the perfect choice for home music installations.

### ICE1 Use and Care Instructions:

Welcome to choose Audio Keeper ICE1 all-acrylic transparent high-fidelity vinyl turntable! The following are detailed instructions for using and maintaining ICE1:

#### 1. Placement

Please place the ICE1 on a stable flat surface, making sure there are no obstructions around the turntable. Avoid placing the ICE1 in direct sunlight or humid environments to avoid affecting its performance and appearance.

#### 2. Record placement

- Before placing a record, make sure the turntable cover is fully closed and the record pad is properly placed on the turntable.
- Place the record lightly on the turntable and gently press down on the center of the turntable to secure it to the turntable.

#### 3. Playback process

- Switch to open the turntable ICE1, and wait for the turntable to start, gently lift the tone arm, slowly move the cartridge to the record surface, and gently put it down.
- Once you make sure the needle is in contact with the record, the turntable will start spinning and you will start enjoying the music.

#### 4. Bluetooth connection

To use the ICE1's Bluetooth capabilities, press the Bluetooth button on the back of the turntable and follow your device's instructions to connect it to the ICE1.

#### 5. Maintenance and cleaning

- Clean the surface of the ICE1 regularly with a clean, soft cloth to prevent dust and dirt from accumulating.
- Use a soft brush to gently clean the turntable cover and record platter to keep them looking clean.

#### 6. Shut down and store

- When you are not using ICE1, please turn off the power and unplug it to save energy and prevent electrical failure.
- Store ICE1 in a dry, ventilated place away from direct sunlight and moisture.

## 7. Cartridge replacement

If you need to replace the cartridge, follow the instructions provided in the ICEI's user manual to easily install the new cartridge, making sure to adjust the stylus and counterweight correctly.

By following the above usage and care instructions, you will be able to maximize your musical experience with the ICEI and ensure its long-term, stable performance. If you have any questions or require further assistance, please feel free to contact our customer support team via [support@theaudiokeeper.com](mailto:support@theaudiokeeper.com). Thank you for choosing ICEI and wish you a wonderful music journey!

*Audio Keeper offers a product line of various cleaning accessories. Please visit our website at <https://theaudiokeeper.com/collections/vinyl-brush-cleaning-kit> for more information. As products are improved and new products are released, our Use and Care Instructions are regularly updated on corresponding pages and <https://theaudiokeeper.com/pages/user-manual>.*

### SOCIAL MEDIA PLATFORM



Audio Keeper Facebook



Audio Keeper Instagram



Audio Keeper YouTube



Audio Keeper website