


X600 Watch Operating Instructions



A. Function description

1. Alarm function: can set 1 group of alarm, ringing "DD", ringing time for 20 seconds.
2. Perpetual calendar function: button switch display day of the week – month and day of the month.
3. EL backlighting.
4. Stopwatch function: up to 99 minutes and 59 seconds.

B. Button description

[S1] button: switch the function interface, change the setting value in the setting state.

[S2] button: every time you press the button to light up the backlight, long press to enter the setting, short press to change the setting item under the setting state.

C. Operation instructions

1. Toggle interface


In the non-setting state, short press S1 button to cycle through: time interface – stopwatch interface – alarm interface.



2. Time screen

(1) View weekday, month-day:


In the time interface, short press S2 button, light up the backlight for 2 seconds, then switch to display day of the week, and switch to display month-day after one second.



(2) Setting time:


- Long press S2 button for 2 seconds to enter 12H/24H value setting, short press S2 button to switch sequentially: 12/24H – hour – minute – day – month – year – exit setting.
- In the setting state, short press S1 button to change the value.
- 30 seconds without button operation, automatically save and exit the setting state.

3. Stopwatch interface



- Stopwatch screen, press S2 button to start the stopwatch.
- Running seconds state, press the S2 button to pause the running seconds, at this time, long press the S2 button to clear the stopwatch.
- Stopwatch runs to the maximum value of 99 minutes and 59 seconds, the stopwatch stops, long press the S2 button stopwatch zero.

4. Alarm screen



(1) Quickly turn on and off the alarm:

- Under the alarm interface, short press the S2 button to turn on/off the alarm.

(2) Set the alarm:

- Long press S2 button for 2 seconds to enter hour value setting, short press S2 button to switch sequentially: hour-minute-snooze (SLEEP) switch-exit setting.

- Setting state, short press S1 button to change the value.
- 30 seconds without button operation, automatically save and exit the setting state.

• When the alarm marker is switched on, it will be displayed in any status.

(3) Alarm (clock)

- The alarm time of is 20 seconds, the alarm icon will flash in any interface when the alarm rings, and the alarm can be cancelled by pressing any button.
- When SLEEP is turned on, snooze every 7 minutes for a total of 2 snoozes and 3 alarms.

5. Backlight

Each time you press the S2 button, the backlight will light up for 2 seconds.

D. Precautions

1. This device is equipped with removable built-in battery. Do not replace the battery by yourself to avoid damaging the battery or the parts of the movement.
2. Strong static charge interference can make the display screen not display properly and even damage the watch parts inside.
3. Do not press the S1 and S2 buttons hard.
4. It should not be worn when taking a bath or swimming.
5. Do not expose the Watch to a place with high moisture or extremely high or low temperature for a long time.
6. If you need to clean the watch or strap, use a soft dry cloth to wipe with water or a neutral detergent, never use volatile chemicals.
7. The paint on this watch may fade due to strong pressure, collision, abrasion, friction, an so on.
8. When not using this watch, please place it in a dry place.
9. The company reserves the right to modify the contents of this manual without prior notice.