




Important specification	Avoids the deterioration of the cable
Maximum temperature	85°C
Housing	Polyamide
Weight	25 g



Fixing examples


FIX-CAB

FIXING ACCESSORY

For float and tilt level switches

The cable tie is an inexpensive and often overlooked accessory in installations. Its use is strongly recommended for the fixing of all suspended devices in order to avoid the deterioration of the outer sheath of the electric cables.

Easy to mount, the cable tie is used to properly secure the power cable to the desired height and allows precise adjustment at any time.



Dimension